
4x Hardware Manual

Release 1.8

Embention


2024-03-20

CONTENTS

1	Introduction	3
1.1	Applications	4
1.2	Control diagram	4
2	Quick Start	7
2.1	Warnings	8
3	Technical	9
3.1	Variants	9
3.2	General description	9
3.3	Mechanical and Electrical specifications	11
3.3.1	Dimensions	12
3.4	Interfaces	12
3.4.1	Connector layout	12
3.4.2	Mating connectors	14
4	Hardware Installation	15
4.1	Mechanical	15
4.1.1	Pressure lines	15
4.1.2	Location	15
4.1.3	Orientation	16
4.1.4	Vibration Isolation	16
4.2	Damping System	17
4.2.1	Dimensions	17
4.2.2	Assembly steps	18
4.3	Antenna Integration	21
4.4	Electrical	21
4.4.1	Power supply	21
4.4.2	Pinout	22
4.4.2.1	Main Connector pinout	22
4.4.2.2	Arbiter connector pinout	26
4.4.2.3	Connector color code	32
4.4.3	Flight Termination System (FTS)	34
4.4.3.1	Autopilots 1x failure - Voting Stage	34
4.4.3.2	Arbitration failure	35
4.4.4	Electrical diagram of CAN bus	35
5	Software Installation	37
5.1	Connections to computer	37
5.1.1	Internal autopilots	37

5.1.2	Management Board	38
5.2	Software manual	40
6	Operation	41
6.1	Air Communications	42
6.1.1	Line of Sight	42
6.1.1.1	Standard setup	42
6.1.1.2	External radiolink	42
6.1.1.3	Tethered	43
6.1.2	Beyond Line of Sight	44
6.1.2.1	Internal 4G + Veronte Cloud	44
6.1.2.2	External Internet access + Veronte Cloud	44
6.1.2.3	External Satellite communication	44
6.1.2.4	Remote GCS	45
6.2	Ground Communications	45
6.2.1	Serial interface	46
6.2.2	External Radiolink	46
6.2.3	Wifi	47
6.3	Manual Control Layouts	47
6.3.1	PPM to Ground Unit	47
6.3.2	PPM to Air Unit	48
6.3.3	USB to Software	48
6.3.4	Stick Expander	48
6.3.5	Virtual Stick	49
6.4	Point to Multipoint Layouts	49
6.4.1	Point to Point	49
6.4.2	Point to Multipoint with Single Ground Station	50
6.4.3	Multipoint to Point with Multiple Ground Stations	50
7	Maintenance	51
7.1	Preventive maintenance	51
7.2	Software update	51
8	Compatible Devices	53
9	Integration Examples	55
9.1	Connection Examples	56
9.1.1	Ground Stations	56
9.1.2	Aircrafts	60
9.2	Radios	63
9.2.1	Digi radio (as internal radio)	63
9.2.2	Silvus radio (StreamCaster 4200E model)	64
9.2.2.1	System Layout	64
9.2.2.2	Hardware Installation	64
9.2.2.3	Silvus radio configuration	66
9.2.2.3.1	First Steps	67
9.2.2.3.2	Basic radio configuration	72
9.2.2.4	Silvus radio configuration in 1x PDI Builder	78
9.3	External Sensors	78
9.3.1	Temperature sensor LM335	78
9.3.1.1	Hardware installation	78
9.3.1.2	Software installation	80
9.4	Joysticks	80
10	Troubleshooting	85


10.1	Maintenance mode	85
10.2	How to enter in maintenance mode	86
10.2.1	Using software to enter in maintenance mode	86
10.2.2	Using the power supply to enter in maintenance mode	86
10.2.3	Using the I2C pins to enter in maintenance mode	86
11	Hardware Changelog	87
12	Acronyms and Definitions	89
12.1	Acronyms	89
12.2	Definitions	90
13	Contact Data	91



4x | VERONTE
AUTOPILOTS

Veronte Autopilot 4x is a miniaturized avionics system for advanced control of unmanned systems, it includes triple redundancy to assure high reliability.

Warning: Select your version before reading any user manual. The following image shows where to select a version from any Embention user manual.




INTRODUCTION



Fig. 1: Veronte Autopilot 4x

Veronte Autopilot 4x is a miniaturized high reliability avionics system for advanced control of **unmanned systems**. This control system embeds a state-of-the-art suite of sensors and processors together with LOS and BLOS M2M datalink radio, all with reduced size and weight.



The **Veronte Autopilot 1x** is designed to control any unmanned vehicle, either aircraft such as: multirotors, helicopters, airplanes, VTOL, blimps... as well as ground vehicles, surface vehicles or many others. Custom flight phases and control channels provide support for any aircraft layout and performance by using the same software and hardware for: UAS, RPAS, Drone, USV / ASV, UGV...

1.1 Applications

Autopilot 4x allows aircrafts to perform sensitive flight missions and transport valuable payloads with advanced safety conditions and high reliability. By installing a triple redundant core it is possible to extend the mean time between failures in systems. This control module is also suitable for both, fail-safe and fail-operational missions, extending the operability of the system.

1.2 Control diagram

Veronte Autopilot 4x is a **triple redundant** version of **Veronte Autopilot 1x**. It includes three complete Veronte Autopilot modules fully integrated with dissimilar arbiters to detect system failures and select the module in charge of control. In worst case scenario, if arbiters do not emit any control signal, the **Autopilot 1x** number 1 will take the control of the aircraft.

Each **Autopilot 1x** receives all signals, but only the selected one sends information through multiplexed channels. The Arbiters select which **1x** will control the aircraft (and send signals) using watchdog messages. In addition, it is possible to connect an external fourth autopilot.




Fig. 2: General diagram

QUICK START

This user manual covers the *mechanical* and *electric* assembly. This document includes references to *install and configure software*.

Veronte Autopilot 4x is the main element in our FCS for UAV.




Fig. 1: System Overview

Veronte Autopilot 4x contains all electronics and sensors required to properly execute all the UAV functions. A Veronte-based FCS contains the following elements:

- A **Veronte Autopilot 4x** installed in a vehicle to be controlled. This autopilot executes GNC algorithms in real time to accomplish the planned mission and transport the payload.
- **Veronte Ops** - Software dedicated to mission planning, configuration and operation. It allows the user to monitor connected UAS in real time, to interact with them and to replay previous missions for post-flight analysis.
- A BCS or PCS linked between **Veronte Ops** and **Veronte Autopilot 4x**. They support manual and arcade modes with conventional joysticks.

2.1 Warnings

- This user manual includes references to manuals for software applications. Select your software version to read them.
- Power out of range can cause irreversible damage to the system. Please read carefully the manual before powering the system.
- Users **must not power on a Veronte Autopilot 4x** without **a suitable antenna** or **50 Ω load** connected to the DAA SSMA if the unit has an ADS-B and/or 4G module activated.

<p>Danger: This may damage the Autopilot 4x unit.</p>
--

3.1 Variants

Variant name	Reference
W/O DAA	P006984
With remote ID	P006146
With ADS-B	P006147

3.2 General description

Veronte Autopilot 4x is a **triple redundant** version of **Veronte Autopilot 1x**. It includes three complete **Autopilot 1x** modules fully integrated with dissimilar arbiters for detecting system failures and selecting the module in charge of the control. The autopilot selected has the master controls actuators and communications. The following diagrams summarize the connections between autopilots and the elements of the flight control system.




Fig. 1: Internal diagrams

Important: Apart from CAN buses, all communications are established only with arbiter A (I2C, RS-232, RS-485 and ARINC). In addition, only arbiter A controls the autopilots multiplexing.

Each **Veronte Autopilot 4x** contains all the electronics and sensors to properly execute all the functions needed to control the UAV. **Autopilot 4x** executes in real time guidance, navigation and control algorithms for the carrying airframe. It controls propulsion systems and signals processing from different sensors: accelerometers, gyroscopes, magnetometer, static pressure, dynamic pressure, GNSS and externals.

Additional I/O ports are available for connection of an external control system in case it is required (for example another **Autopilot 1x**). In case of using an additional control system, it will be included in the redundant scheme. Veronte systems provide the system full dissimilarity for high demanding environments, as required by civil aviation authorities.

Datalink communications can be also redundant, being possible to install inside the autopilot 3 radios with different frequencies. For example, it allows to have two radios working in the 900 MHz frequency and one in 2.4 GHz, so in

case there is any issue in the 900 MHz bandwidth the module connected to the 2.4 GHz bandwidth will take the control. In addition, an external radio can be controlled as a critical device using the serial port in the redundant connector.

Veronte Autopilot 4x also includes two separate flight termination voting logics, completely dissimilar and implemented with simple hardware, with the purpose of giving the internal three **Veronte Autopilots 1x** a way to decide by consensus if a flight termination signal should be activated or not. This flight termination signal is employed to activate emergency systems, such as parachutes.

All three modules are managed by a **Management Board**; it includes voting algorithms to manage the module in charge of vehicle control. This device compares data from all modules in real time and processes it for discarding any autopilot module with undesired performance.

The arbitration algorithm in **Veronte Autopilot 4x** is based on a scoring system. Each autopilot must send continuously a set of arbitration variables to the arbiters in order to calculate the score for each unit. Then, based on scores and current arbitration mode, the **4x** will use the autopilot with the lowest score.




Fig. 2: Arbitration diagram

3.3 Mechanical and Electrical specifications

All sensors are located inside the **Autopilots 1x**. To know their specifications read the [Sensor Specifications - Technical](#) section of the 1x **Hardware Manual**.

Variable	Value
Weight	W/O DAA: 615 g (± 2 g) With remote ID or ADS-B: 632 g (± 2 g)
Temperature range	-40 °C to 65 °C
Protection Rating	IP67
Power input voltage	6.5 to 36 V
Power consumption	Up to 15 W
Maximum acceleration	32 g

3.3.1 Dimensions




Fig. 3: Veronte Autopilot 4x dimensions (mm)

M3 screws are recommended for mounting. In saline environments such as coastal and oceanic, the screw material should be stainless steel.

3.4 Interfaces

3.4.1 Connector layout

The three inner **Autopilots 1x** are connected to the **MAIN Connector** and the **Management Board** is connected to **Connector 4**. In case of using an **external autopilot**, it must be plugged to the **Connector 4** according to the [Pinout - Hardware Installation](#) section of this manual.

Each inner **Autopilot 1x** has assigned a connector block with its respective number. All blocks have the same connectors with the same functions.




Fig. 4: Veronte Autopilot 4x connectors

- **M2M.** SSMA connector for machine to machine communication.
- **GNSS1.** SSMA connector for global navigation satellite system 1.
- **GNSS2.** SSMA connector for global navigation satellite system 2.
- **DAA.** SSMA connector for ADS-B or remote ID.

Warning: When using ADS-B or remote ID, there must be an adequate antenna or load connected to the DAA SSMA.

- **LOS.** SSMA connector for line of sight communications.
- **PITOT.** Dynamic pressure port of each internal autopilot.
- **STATIC.** Static pressure port for absolute pressure sensor 2 of each internal autopilot.
- **INT Inlet.** Static pressure port for absolute pressure sensors 1. This port is common for all internal autopilots.

Note: Each autopilot employs both static pressure ports for sensor redundancy, then Y tubing connection is strongly recommended.

3.4.2 Mating connectors

SSMA CONNECTORS		
Abbreviation	Autopilot 4x connector	Mating connector
GNSS	SSMA female for GNSS antenna	SSMA male Plug, low-loss cable is recommended. Active Antenna GNSS: <ul style="list-style-type: none"> • Gain min 15 dB (to compensate signal loss in RF Cable) • Gain max 50 dB • Maximum noise figure 1.5 dB • Power supply 3.3 V • Max current 20 mA
DAA	SSMA female for ADS-B or remote ID	SSMA male Plug, low-loss cable is recommended
M2M	SSMA female for M2M antenna	
LOS	SSMA female for RF antenna	

HARNESS CONNECTORS	
Autopilot 4x connector	Compatible harness (Embention reference)
Main Connector	HIL Simulation Cable (P007739)
	Veronte Harness for Autopilot 4x Programming (P007695)

Autopilot 4x connector	Commercial reference
Main Connector	HEW.LM.368.XLNP
Connector 4	HER.LM.368.XLNP

HARDWARE INSTALLATION

4.1 Mechanical

Veronte Autopilot 4x is covered with an aluminium enclosure with enhanced EMI shielding and IP protection, with 750 g as total weight.

4.1.1 Pressure lines

Veronte Autopilot 4x has seven redundant pressure input lines; four for static pressure to determine the absolute pressure and three for pitot in order to determine the dynamic pressure.

For the fittings it is recommended to use a polyurethane tube of 2.5 mm inner diameter and 4 mm outer diameter.

- **Pressure Intake**
 - Pressure intakes must be located in order to prevent clogging.
 - Do not install pressure intakes on the propeller flow.
 - Design pressure tubing path in order to avoid tube constriction.
- **Static Pressure**
 - It is not recommended to use inside fuselage pressure if it is not properly vented.
- **Pitot Tube**
 - Pitot tube must be installed facing the airflow.
 - It is recommended to install it near the aircraft's x axis in order to avoid false measures during manoeuvres.
 - For low-speed aircraft it is recommended at least 6.3 mm tubes to prevent any rain obstruction.

4.1.2 Location

The location of **Veronte Autopilot 4x** has no restrictions. It is only required to configure its relative position respect to the centre of mass of the aircraft and the GNSS antenna. The configuration of the location of each **Autopilot 1x** can be easily configured using [1x PDI Builder](#).

4.1.3 Orientation

The orientation of **Veronte Autopilot 4x** has no restrictions either. It is only required to configure axes respect to the aircraft by means of a rotation matrix or a set of correspondences between axes. The configuration of the orientation can be easily configured using **1x PDI Builder** for each **Autopilot 1x**.

Axes are printed on the **Autopilot 4x** box. Aircraft coordinates are defined by the standard aeronautical conventions, shown in the following figure.





Fig. 1: Aircraft Coordinates (Standard Aeronautical Convention)

4.1.4 Vibration Isolation

Although **Veronte Autopilot 4x** rejects noise and high-frequency modes of vibration with electronic filters and internal mechanical filters, there might be situations where external isolation components might be needed.

Autopilot 4x can be mounted in different ways in order to reject the airframe vibration. The simplest way could be achieved by just using double-sided tape on the bottom side of Veronte. Other ways may use some external structure which could be rigidly attached to the airframe and softly attached to Veronte (e.g. foam, silent blocks, aerogel, etc).



The user should take into account that wiring should be loose enough so vibrations may not be transmitted to **Autopilot 4x**.

In cases where mechanical isolation is not viable, it is possible to use soft engine mounts. It is also recommended when there are other sensible payloads like video cameras or for high vibration engines.

4.2 Damping System

Embention offers a solution to isolate the **Autopilot 4x** from vibrations: the **Damping System**.



Fig. 2: Damping System

Warning: The **Damping System** is designed for version 1.8 of **Autopilot 4x**.

4.2.1 Dimensions




Fig. 3: Damping system dimensions (mm)

4.2.2 Assembly steps

To assembly the Damping System into a vehicle with an **Autopilot 4x**, read the following steps.

1. Remove the six nuts located under the platform.




Fig. 4: Step 1

2. Screw the platform on the aircraft frame. The included screws have M3.




Fig. 5: Step 2

3. Screw the **Autopilot 4x** on the **Damping system**.






Fig. 6: Step 3



Fig. 7: Result

4.3 Antenna Integration

The system uses different kinds of antenna to operate, they must be installed on the airframe. The following table explains a list of advices to obtain the best performance and avoid antenna interferences.

Antenna Installation
Maximize separation between antennas as much as possible.
Keep antennas far away from alternators or other interference generators.
Always isolate the antenna ground panel from the aircraft structure.
Make sure antennas are securely mounted.
Always use high-quality RF wires minimising the wire length.
Always follow the antenna manufacturer manual.
SSMA connections shall be tightened applying 1Nm of torque
For all-weather aircraft, insert SSMA lightning protectors.

GNSS Antenna
Antenna top side must point to the sky.
Install them on a top surface with direct sky view.
Never place wires or parts made of memetal or carbon above the antenna.
It is recommended to install antennas on a small ground plane.
For all-weather aircrafts, insert SSMA lightning protectors.

4.4 Electrical

4.4.1 Power supply

Warning: Power Veronte out of the given range can cause irreversible damage to the system. Please read carefully the manual before powering the system.

Autopilot 4x can use unregulated DC (6.5 V to 36 V) for the internal Veronte autopilots and also for the **Management Board**. All power supply pins are not common. It is possible to supply them with different voltages since they are internally protected with diodes. Nonetheless, all power supply pins must be connected to a power supply, in order to guarantee that **Autopilot 4x** will work in case of failing one of them. These pins are summarized in the following table:

Connector	Name	Number
Main Connector	BAT_0	68
	BAT_1	67
	BAT_2	64
Arbiter Connector	VCC_ARBITER	68

LiPo batteries between 2S and 8S can be used without voltage regulation. Remaining battery can be controlled by the internal voltage sensor and by configuring the voltage warnings on the PC application.

For higher voltage installations, voltage regulators must be used. For dimensioning voltage regulators take into account that a blocked servo can activate regulator thermal protection.

Autopilots and servos can be powered by the same or different batteries. In case there are more than one battery on the system, a single point ground union is needed to ensure a good performance. The ground signal should be isolated from other system ground references (e.g. engines).

It is recommendable to use independent switches for autopilot and motor / actuators. During the system initialization, PWM signal will be fixed to low level (0V), please make sure that actuators / motor connected support this behavior before installing a single switch for the whole system.

4.4.2 Pinout

Warning: Pins can transfer 2 A as maximum current.




Fig. 8: Pinout of Main Connector and Connector 4

4.4.2.1 Main Connector pinout

PIN	SIGNAL	TYPE	INTERNAL POWER DOMAIN	COMMENTS
1	I/O_0_MUXED	I/O	A	MUXED PWM / Digital I/O signal (0-3.3V)
2	I/O_1_MUXED	I/O	B	
3	I/O_2_MUXED	I/O	A	

continues on next page

Table 1 – continued from previous page

PIN	SIGNAL	TYPE	INTERNAL POWER DOMAIN	COMMENTS
4	I/O_3_MUXED	I/O	B	
5	I/O_4_MUXED	I/O	A	
6	I/O_5_MUXED	I/O	B	
7	I/O_6_MUXED	I/O	A	
8	I/O_7_MUXED	I/O	B	
9	GND*	GROUND		Ground pin for signals 1-8
10	I/O_8_MUXED	I/O	A	MUXED PWM / Digital I/O signal (0-3.3V)
11	I/O_9_MUXED	I/O	B	
12	I/O_10_MUXED	I/O	A	
13	I/O_11_MUXED	I/O	B	
14	I/O_12_MUXED	I/O	A	
15	I/O_13_MUXED	I/O	B	
16	I/O_14_MUXED	I/O	A	
17	I/O_15_MUXED	I/O	B	
18	GND*	GROUND		Ground pin for signals 10-17
19	MUXED_RS232_TX	OUTPUT	A	MUXED RS-232 output
20	MUXED_RS232_RX	INPUT	A	REDUNDANT RS-232 input
21	V2_USB_DP	I/O		Autopilot 2 USB positive data line
22	ANALOG_3	INPUT	B	REDUNDANT analog input (0-36V)
23	ANALOG_4	INPUT	B	
24	V2_USB_DN	I/O		Autopilot 2 USB negative data line
25	CANA_ARB_P	I/O	A	CAN-bus interface. It supports data rates up to 1 Mbps. A 120 Ohm Zo is required and twisted pair is recommended.
26	CANA_ARB_N	I/O	A	
27	GND*	GROUND		GROUND pin for buses (except USB)
28	CANB_ARB_P	I/O		CAN-bus interface. It supports data rates up to 1 Mbps. A 120 Ohm Zo is required and twisted pair is recommended
29	CANB_ARB_N	I/O		
30	V2_USB2_GND	GROUND		Autopilot 2 USB ground
31	I2C_CLK	OUTPUT A		MUXED Clock line for I2C bus (0.3V to 3.3V)

continues on next page

Table 1 – continued from previous page

PIN	SIGNAL	TYPE	INTERNAL POWER DOMAIN	COMMENTS
32	I2C_DATA	I/O	A	MUXED data line for I2C bus
33	GND*	GROUND		Ground for 3.3V power supply
34	V1_ARB_TX	OUTPUT		Microcontroller UART transmitter for Autopilot 1
35	V1_ARB_RX	INPUT		Microcontroller UART receiver for Autopilot 1
36	V2_ARB_TX	OUTPUT		Microcontroller UART transmitter for Autopilot 2
37	V2_ARB_RX	INPUT		Microcontroller UART receiver for Autopilot 2
38	ANALOG_0	INPUT	A	REDUNDANT analog input (0-36V)
39	ANALOG_1	INPUT	A	
40	ANALOG_2	INPUT	A	
41	GND*	GROUND		Ground pin
42	V3_USB_DP	I/O		Autopilot 3 USB positive data line
43	V3_USB_DN	I/O		Autopilot 3 USB negative data line
44	GND*	GROUND		Ground pin
45	V3_ARB_TX	OUTPUT		Microcontroller UART transmitter for Autopilot 3
46	V3_ARB_RX	INPUT		Microcontroller UART receiver for Autopilot 3
47	GND*	GROUND		Ground pin
48				
49	V3_USB3_GND	GROUND		Autopilot 3 USB ground
50	OUT_RS485_P	OUTPUT	B	MUXED non-inverted output RS-485 bus
51	OUT_RS485_N	OUTPUT	B	MUXED inverted output RS-485 bus
52	IN_RS485_N	INPUT		REDUNDANT inverted input RS-485 bus
53	IN_RS485_P	INPUT		REDUNDANT non-inverted input RS-485 bus
54	RS485_GND	GROUND		Ground for RS-485 bus

continues on next page

Table 1 – continued from previous page

PIN	SIGNAL	TYPE	INTERNAL POWER DOMAIN	COMMENTS
55	EQEP_A	INPUT	A for autopilots 1 and 2 B for autopilot 3	Encoder quadrature redundant input A (0-5V)
56	EQEP_B	INPUT		Encoder quadrature redundant input B (0-5V)
57	EQEP_S	INPUT		Encoder strobe redundant input (0-5V)
58	EQEP_I	INPUT		Encoder index redundant input (0-5V)
59	GND*	GROUND		Ground pin
60	V1_USB_DP	I/O		Autopilot 1 USB positive data line
61	V1_USB_DN	I/O		Autopilot 1 USB negative data line
62	V1_USB1_GND	GROUND		Autopilot 1 USB ground
63	GND*	GROUND		Ground pin
64	BAT_2	POWER		Autopilot 3 power supply (6.5 to 36V)
65	GND*	GROUND		Ground pin
66				
67	BAT_1	POWER		Autopilot 2 power supply (6.5 to 36V)
68	BAT_0	POWER		Autopilot 1 power supply (6.5 to 36V)

Warning: Common grounds are marked with *.

Note: MUXED (multiplexed) signals are connected to the **Autopilot 1x** decided by the **Management Board**, then only the selected autopilot is connected to MUXED pins.

REDUNDANT signals are connected to the three inner autopilots, so all of them receive the same REDUNDANT signals.

4.4.2.2 Arbiter connector pinout

Although being the same component, **Main Connector** and **Arbiter connector** are polarized differently, but they have different mechanical connections to avoid wiring swapping.

PIN	SIGNAL	TYPE	INTERNAL POWER DOMAIN	COMMENTS
1	I/O_0_EXTERNAL	I/O	A	<p>External MUXED PWM / Digital I/O signal (0-3.3V). In case of employing an additional external autopilot, its pins I/XX must be connected here. Each signal I/O_XX_EXTERNAL will be sent to I/XX of Main Connector if the arbiter commands it.</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p>Warning: Input current must be limited to 25 mA for each I/O EXTERNAL pin.</p> </div>
2	I/O_1_EXTERNAL	I/O	B	
3	I/O_2_EXTERNAL	I/O	A	
4	I/O_3_EXTERNAL	I/O	B	
5	I/O_4_EXTERNAL	I/O	A	
6	I/O_5_EXTERNAL	I/O	B	
7	I/O_6_EXTERNAL	I/O	A	
8	I/O_7_EXTERNAL	I/O	B	
9	I/O_8_EXTERNAL	I/O	A	
10	I/O_9_EXTERNAL	I/O	B	
11	I/O_10_EXTERNAL	I/O	A	
12	I/O_11_EXTERNAL	I/O	B	
13	ARBITER_ANALOG_INPUT			Arbiter analog input (0-36V)
14	EXTERNAL_ANALOG_OUTPUT		A	External analog signal (0-3V). This is the analog signal from ANALOG_1 on Main Connector , which is reduced from 0-36V to 0-3V.
15	EXTERNAL_ANALOG_OUTPUT		A	External analog signal (0-3V). This is the analog signal from ANALOG_2 on Main Connector , which is reduced from 0-36V to 0-3V.

continues on next page

Table 2 – continued from previous page

PIN	SIGNAL	TYPE	INTERNAL POWER DOMAIN	COMMENTS
16	EXTERNAL_ANALOG_3	OUTPUT	A	External analog signal (0-3V). This is the analog signal from ANALOG_3 on Main Connector , which is reduced from 0-36V to 0-3V.
17	EXTERNAL_ANALOG_4	OUTPUT	B	External analog signal (0-3V). This is the analog signal from ANALOG_4 on Main Connector , which is reduced from 0-36V to 0-3V.
18	FTC_VOTING_B	OUTPUT	B	<p>This pin is an open drain output (0 - 48V), which is open or connected to GND depending on the FTS signals of the Autopilots 1x. This logic is implemented at the Voting Stage, explained in detail in the <i>Flight Termination System</i> section of this manual.</p> <p>Use this pin for an emergency device; for example the ground of a relay that activates a parachute.</p> <p>FTC_VOTING_A (pin 53) and FTC_VOTING_B (pin 18) do the same function, but they have dissimilarity.</p>

continues on next page

Table 2 – continued from previous page

PIN	SIGNAL	TYPE	INTERNAL POWER DOMAIN	COMMENTS
19	EXT_RS232_TX	INPUT	A	In case of employing an additional external autopilot, its pin RS 232TX must be connected here. If arbiter decides to multiplex this signal, it will be transmitted to MUXED_RS232_TX on Main Connector with RS232 protocol.
20	EXT_RS232_RX	OUTPUT	A	In case of employing an additional external autopilot, its pin RS 232 RX must be connected here. If arbiter decides to multiplex this signal, it will be transmitted to MUXED_RS232_TX on Main Connector with RS232 protocol.
21	IN_RS485_P	OUTPUT		This pin is connected with IN_RS485_P from Main Connector
22	IN_RS485_N	OUTPUT		This pin is connected with IN_RS485_N from Main Connector

continues on next page

Table 2 – continued from previous page

PIN	SIGNAL	TYPE	INTERNAL POWER DOMAIN	COMMENTS
23	EXT_OUT_RS485_P	INPUT	B	In case of employing an additional external autopilot, its pin OUT_RS485_P must be connected here. If arbiter decides to multiplex this signal and EXT_DETECT of Arbiter Connector is connected to GND, it will be transmitted to OUT_RS485_P on Main Connector with RS232 protocol
24	EXT_OUT_RS485_N	INPUT	B	In case of employing an additional external autopilot, its pin OUT_RS485_N must be connected here. If arbiter decides to multiplex this signal and EXT_DETECT of Arbiter Connector is connected to GND, it will be transmitted to OUT_RS485_N on Main Connector with RS232 protocol
25	CANA_P_ARB_A	I/O		This pin is connected with CANA_ARB_P from Main Connector
26	CANA_N_ARB_A	I/O		This pin is connected with CANA_ARB_N from Main Connector
27	ARBITER_ANALOG	INPUT		Arbiter analog input (0-36V)

continues on next page

Table 2 – continued from previous page

PIN	SIGNAL	TYPE	INTERNAL POWER DOMAIN	COMMENTS
28	CANB_P_ARB_B	I/O		This pin is connected with CANB_ARB_P from Main Connector
29	CANB_N_ARB_B	I/O		This pin is connected with CANB_ARB_N from Main Connector
30	OUT_RS485_ARB_P	OUTPUT	ARBITER	Non-inverted output for arbiter's RS-485 bus
31	OUT_RS485_ARB_N	OUTPUT	ARBITER	Inverted output for arbiter's RS-485 bus
32	IN_RS485_ARB_N	INPUT	ARBITER	Inverted output for arbiter's RS-485 bus
33	IN_RS485_ARB_P	INPUT	ARBITER	Non-inverted input for arbiter's RS-485 bus
34	TX_OUT_P	OUTPUT	ARBITER	Arbiter's ARINC positive output
35	TX_OUT_N	OUTPUT	ARBITER	Arbiter's ARINC negative output
36	RIN1_ARINC_P	INPUT	ARBITER	Arbiter's ARINC positive input
37	RIN1_ARINC_N	INPUT	ARBITER	Arbiter's ARINC negative input
38	GND*	GROUND		Ground pin for buses
39	SCL_A_OUT_ARB	OUTPUT	ARBITER	Clock signal for arbiter's I2C bus
40	SDA_A_OUT_ARB	I/O	ARBITER	Data signal for arbiter's I2C bus
41	DSP_232_RX_B	INPUT	ARBITER	Arbiter RS-232 input B
42	DSP_232_TX_B	OUTPUT	ARBITER	Arbiter RS-232 output B
43	DSP_232_RX_A	INPUT	ARBITER	Arbiter RS-232 input A
44	DSP_232_TX_A	OUTPUT	ARBITER	Arbiter RS-232 output A
45	GND*	GROUND		Ground pin for analog signals
46	ARBITER_ANALOG	INPUT	ARBITER	Arbiter analog input (0-36V)
47	ARBITER_ANALOG	INPUT	ARBITER	
48	ARBITER_ANALOG	INPUT	ARBITER	
49	ARBITER_ANALOG	INPUT	ARBITER	
50	ARBITER_ANALOG	INPUT	ARBITER	
51	ARBITER_ANALOG	INPUT	ARBITER	

continues on next page

Table 2 – continued from previous page

PIN	SIGNAL	TYPE	INTERNAL POWER DOMAIN	COMMENTS
52	ARBITER_ANALOG	INPUT	ARBITER	
53	FTC_VOTING_A	OUTPUT	A	<p>This pin is an open drain output (0 - 48V), which is open or connected to GND depending on the FTS signals of the Autopilots 1x. This logic is implemented at the Voting Stage, explained in detail in <i>the Flight Termination System</i> section of this manual.</p> <p>Use this pin for an emergency device; for example the ground of a relay that activates a parachute.</p> <p>FTC_VOTING_A (pin 53) and FTC_VOTING_B (pin 18) do the same function, but they have dissimilarity.</p>
54	GPIO_8_ARB	I/O	ARBITER	Arbiter's PWM / digital I/O signal (0-3.3V)
55	GPIO_9_ARB	I/O	ARBITER	
56	WD_EXT	INPUT	ARBITER	Watchdog signal from external autopilot to arbiter (0-3.3V)
57	EXT_DETECT	INPUT	ARBITER	Connect to GND if external autopilot is connected, otherwise keep open
58	GND*	GROUND		Ground signal for GPIO
59	GPIO_0_ARB	I/O	A	Arbiter's PWM / digital I/O signal (0-3.3V)
60	GPIO_1_ARB	I/O	A	
61	GPIO_2_ARB	I/O	A	
62	GPIO_3_ARB	I/O	A	
63	GPIO_4_ARB	I/O	A	
64	SEL_AP	OUTPUT	A	CAP signal indicating the AP selected

continues on next page

Table 2 – continued from previous page

PIN	SIGNAL	TYPE	INTERNAL POWER DOMAIN	COMMENTS
65	FTS1_OUT	OUTPUT	A	Deadman signal from comicro
66	FTS2_OUT	OUTPUT	A	System OK bit
67	GND*	GROUND		Management Board ground
68	VCC_ARBITER	POWER		Power supply for Management Board (6.5 to 36 V)

Warning: Common grounds are marked with *.

Important: Apart from CAN buses, all communications are established only with arbiter A (I2C, RS-232, RS-485 and ARINC).

4.4.2.3 Connector color code




Fig. 9: Harness plug

Warning: Check the pin number before connecting. The color code is repeated 3 times due to the amount of pins. First section (yellow) corresponds to pins 1-30, the second section (blue) to pins 31-60 and the third one (red) to pins 61-68. Pin number increases following the black line of the pictures above: counterclockwise for the connector and clockwise for the plug.

PIN	Color code	PIN	Color code
1	White	35	Gray
2	Brown	36	Pink
3	Green	37	Blue
4	Yellow	38	Red
5	Gray	39	Black
6	Pink	40	Violet
7	Blue	41	Gray – Pink
8	Red	42	Red – Blue
9	Black	43	White – Green
10	Violet	44	Brown – Green
11	Gray – Pink	45	White – Yellow
12	Red – Blue	46	Yellow – Brown
13	White – Green	47	White – Gray
14	Brown – Green	48	Gray – Brown
15	White – Yellow	49	White – Pink
16	Yellow – Brown	50	Pink – Brown
17	White – Gray	51	White – Blue
18	Gray – Brown	52	Brown – Blue
19	White – Pink	53	White – Red
20	Pink – Brown	54	Brown – Red
21	White – Blue	55	White – Black
22	Brown – Blue	56	Brown – Black
23	White – Red	57	Gray – Green
24	Brown – Red	58	Yellow – Green
25	White – Black	59	Pink – Green
26	Brown – Black	60	Yellow – Pink
27	Grey – Green	61	White
28	Yellow – Green	62	Brown
29	Pink – Green	63	Green
30	Yellow – Pink	64	Yellow
31	White	65	Grey
32	Brown	66	Pink
33	Green	67	Blue
34	Yellow	68	Red

4.4.3 Flight Termination System (FTS)

The **Flight Termination System** determines the behavior of **Autopilot 4x** in case of severe failure. There are FTS output signals of 4x for failures of **Autopilots 1x** (*FTC_VOTING_A* and *FTC_VOTING_B*) and for failure of the **Arbitration system** (*FTS1_OUT* and *FTS2_OUT*).

4.4.3.1 Autopilots 1x failure - Voting Stage

Autopilot 4x FTS works based on a **Voting Stage**, a simple hardware circuit made of logic gates, which analyzes the FTS signals of each **Autopilot 1x** in order to determine if terminating the mission or not.

The FTS signals of **Autopilots 1x**, which correspond with the voting signals considered in the Voting Stage, are the following:

Fig. 10: Voting System Inputs

- **Pin 63 - FTS_OUT_MPU:** Its output is 0 V when the system is working as expected and 3.3 V when some error is detected.
- **Pin 64 - FTS2_OUT_MPU:** Its output is 0 V when the system is working as expected and 3.3 V when some error is detected.
- **Pin 49 - FTS3_OUT_MPU:** MPU alive voting signal. Its output is a square wave at [100,125] Hz.

Note: For further information regarding these pins, please refer to [Pinout - Hardware Installation](#) section in **1x Hardware Manual**.

The functionality of the **Voting Stage** is to implement the following logic:

- **Isolate internal Flight Termination Units (FTUs) with failure.** When a deadman signal indicates that an internal Veronte FTU has a failure, this FTU will be excluded from the voting scheme.
- If all **three internal FTUs are OK**, then termination will occur if two of three FTUs detect that the vehicle is out of the restricted area.
- If **two FTUs are ok and one is dead**, then termination will occur if one of the remaining FTUs detect that the vehicle is out of the restricted area.
- If **one FTU is ok and two are dead**, then termination will occur if the remaining FTU detects that the vehicle is out of the restricted area.
- If **all three FTUs are dead**, terminate the mission.

In Autopilot 4x, there are **two Voting Systems** available whose output signals are **FTC_VOTING_A** and **FTC_VOTING_B** (pins 53 and 18).

Note: These pins will be **open** in case of **terminating the mission** and **connected to GND** when **continuing the mission**.

4.4.3.2 Arbitration failure

The **Management Board** also includes two FTS pins in the **Arbiter Connector**:

- **Pin 65 - FTS1_OUT:** Deadman signal. Its output is a square wave.
- **Pin 66 - FTS2_OUT:** System OK. Its output will be 3.3 V when an error has been detected and 0V when the arbitration system is working normally.

4.4.4 Electrical diagram of CAN bus

Autopilot 4x requires two termination resistors ($120\ \Omega$) to allow multiple CAN Bus devices to be connected to the same line.

Since there is already an internal $120\ \Omega$ CAN resistor in the Autopilot 4x (connecting the line to CAN A or CAN B), it is only necessary to place an external $120\ \Omega$ resistor at the end of the cable:




Fig. 11: CAN resistor

SOFTWARE INSTALLATION

5.1 Connections to computer

5.1.1 Internal autopilots

Each **Veronte Autopilot 1x** must be connected to a computer individually to configure it. The **Management Board** must also be connected individually.

There are two ways to connect a **Veronte Autopilot 1x** to a computer: USB or serial with RS-232. Both options require power supply for the connected **Autopilot 1x**. Attach the **4x Redundant Harness** to the **Connector 4** to connect a computer and any **Autopilot 1x**.

Note: To use the RS-232 connection with a computer, an USB-RS232 converter is required.




Fig. 1: USB connection to Autopilot 1x




Fig. 2: Serial connection to Autopilot 1x

If there is any doubt about electrical connections, check the *Main Connector pinout* and the *Arbiter Connector pinout* in this manual.

5.1.2 Management Board

Autopilot 4x with hardware version 1.8 has a **Management Board**, which is composed by 2 arbiters. Both arbiters have the external communications separated and both require configuration. Hence, **Management Board** requires two different connections to a computer, each one configuring a different arbiter. Previous hardware versions only had one arbiter, requiring only one connection and configuration.

Arbiter A can be connected to a computer via RS-232 or CAN (through one internal **1x**).

To connect a computer to Arbiter A via RS-232, the connection is as follows:




Fig. 3: Arbiter connection

Another way to connect a computer to arbiter A is to use an **Autopilot 1x** as a CAN tunnel, so messages travel through internal CAN connections. Nonetheless, an **Autopilot 1x** requires a configuration to perform tunnel communications, which is explained in the [Autopilot 4x - Integration examples](#) section of the **1x PDI Builder** user manual.

Arbiter B does not have RS-232 port, hence the only way to connect B with a computer is through CAN, as explained before.




Fig. 4: Arbiter connection via CAN tunnel

Important: Each arbiter will be identified by software applications as a different device.

5.2 Software manual


To configure each **Veronte Autopilot 1x** and the arbiters, read the [4x Software Manual](#) .

OPERATION

Veronte Autopilot 1x allows for a wide variety of communication and control solutions to adapt to each mission and platform specifications. This section summarizes a list of recommended options to operate an **Autopilot 1x** in different situations.

Tip: Most of the following diagrams can be used independently or combined, to create redundant systems or backup solutions.

The following image shows the standard Veronte System Layout for operation.



In the standard layout, an Operator (Internal Pilot) controls the UAV from the Ground Station using **Veronte Ops**.

Additionally, a Safety Pilot (External Pilot) is connected to the Ground Station using a radio controller. The stick commands are read by the Ground Unit and re-routed to the Air Unit. The Safety Pilot is able to take control of the flight at any point using an [automation](#).

While this is the most common setup, there is a wide variety of options, including:


- BLOS communications
- Onboard RC receivers
- Point to Multipoint configurations

6.1 Air Communications

Communication solutions between air and ground devices.


6.1.1 Line of Sight

6.1.1.1 Standard setup




6.1.1.2 External radiolink

For increased range, bandwidth or channels are needed




6.1.1.3 Tethered




6.1.2 Beyond Line of Sight

6.1.2.1 Internal 4G + Veronte Cloud




6.1.2.2 External Internet access + Veronte Cloud

For alternative internet access




6.1.2.3 External Satellite communication

For maximum reliability



6.1.2.4 Remote GCS


For remote solutions with LOS backup operator



6.2 Ground Communications


Communication solutions between the different GS devices

6.2.1 Serial interface




6.2.2 External Radiolink

For modular ground stations.



6.2.3 Wifi

For operation with laptops or tablets.




6.3 Manual Control Layouts

Veronte allows for a wide variety of pilot interface solutions in order to interact with manual flight modes, assisted flight modes (arcade) or payloads.


6.3.1 PPM to Ground Unit

Standard setup. Allows the usage of a single radio channel both for stick, control commands and telemetry, minimizing any potential interferences.




6.3.2 PPM to Air Unit

Allows for a backup manual channel when there is a main channel loss and an emergency manual landing is needed. Recommended for initial development stages where automatic landing phases are not defined yet.




6.3.3 USB to Software

Allows the use of any device that is detected as a remote controller by the operative system



6.3.4 Stick Expander

The **Veronte Stick Expander** allows for the integration of commercial flight station devices and remote controllers. In addition, **Stick Expander** enables the use of USB sticks within the Veronte ecosystem.



6.3.5 Virtual Stick

The Virtual stick feature allows to integrate as a stick controller any device that can interface with **BCS** or Air unit (RS232, RS485, ADC, CAN...) and can provide control reference values.


While the configuration is slightly more complex, this feature allows using a wide variety of devices as flight control interfaces.

6.4 Point to Multipoint Layouts

Due to Veronte's modular configuration, it is possible to integrate several air and ground units within the same network.


6.4.1 Point to Point

Standard multiplatform setup.




6.4.2 Point to Multipoint with Single Ground Station

Managing several platforms with a single radiolink.



6.4.3 Multipoint to Point with Multiple Ground Stations

For long range operations with several LOS stations.



MAINTENANCE

7.1 Preventive maintenance

Apart from cleaning, no extra maintenance is required to guarantee the correct operation of **Veronte Autopilot 4x**.

In order to clean **Veronte Autopilot 4x** properly follow the next recommendations.

- Turn off the device before cleaning.
- Use a clean, soft, damp cloth to clean the unit.
- Do not immerse the unit in water to clean it.

7.2 Software update

To update the software, an additional app is required: [Veronte Updater](#).

Warning: Select your version before reading any user manual for software.
--

Note: The file with the new software version will be shared with the customer in the **Joint Collaboration Framework** when it is requested. For more information about the **Joint Collaboration Framework**, read its [user manual](#).

COMPATIBLE DEVICES

Veronte Autopilot 4X can be integrated with any external sensor that shares communication interface. External sensors can be configured to be considered as part of the sensors fusion. For example, the Magnetometer Honeywell HMR2300-232 can be employed, read the [datasheet](#) to obtain more information.

1x PDI Builder is able to detect USB devices such as joysticks. Buttons and axis of these devices can be read and configured to send stick information to Veronte Autopilot **4x** and **1x**. In addition, virtual sticks can be defined and configured reading the [1x PDI Builder user manual](#).

Since **Autopilot 4X** is based on **Autopilot 1x**, both products have the same compatible devices. To know more, read the [Compatibles Devices](#) section of the **1x Hardware Manual**.

INTEGRATION EXAMPLES

- *Connection Examples*
- *Radios*
- *External Sensors*
- *Joysticks*

9.1 Connection Examples

9.1.1 Ground Stations




Fig. 1: Basic Autopilot 4x Ground Station




Fig. 2: Autopilot 4x PCS Ground Station




Fig. 3: Autopilot 4x Tracker Ground Station




Fig. 4: Autopilot 4x MCS Ground Station

Warning: Veronte Autopilot 4x equipment harnesses have specific pin layouts. Only use their own matting connectors, do NOT mix harnesses: misuse may lead to destruction.

9.1.2 Aircrafts




Fig. 5: HIL Harness




Fig. 6: Multicopter




Fig. 7: Fixed Wing Airplane




Fig. 8: Helicopter

9.2 Radios

9.2.1 Digi radio (as internal radio)

Internal Digi radios can establish communication between Veronte Autopilots.

Each internal **Autopilot 1x** has to be configured one by one with **1x PDI Builder**. The necessary configuration of Digi radios for proper communication between them is described in the [Digi internal radio - Integration examples](#) section of the **1x PDI Builder Manual**.

9.2.2 Silvus radio (StreamCaster 4200E model)

9.2.2.1 System Layout

The following image shows the standard connection between a **BCS** and a **Veronte Autopilot 4x** by two Silvus radios:




Fig. 9: Silvus radio connection

9.2.2.2 Hardware Installation

A wiring configuration of the PRI cable connected to the PRI port of the radio is required, in order to connect to the power supply, ethernet and RS-232.




Fig. 10: PRI port connector (mounted in radio)

- Power supply



Fig. 11: Female DC Power Jack connector

PRI port connector - Silvus radio		Power connector
PIN N°	Signal	Signal
2	GND IN	Power -
3	VCC IN	Power +

- Ethernet




Fig. 12: RJ45 pinout T-568B

PRI port connector - Silvus radio		RJ45 Connector (T-568B)		
PIN N°	Signal	PIN N°	Signal	Color
4	ETH0_MX2N (RX-)	6	RX-	Green
5	ETH0_MX2P (RX+)	3	RX+	Green-White
6	ETH0_MX1P (TX+)	1	TX+	Orange-White
10	ETH0_MX1N (TX-)	2	TX-	Orange

- RS-232

The RS-232 from the PRI cable should be connected to the RS-232 of **Main Connector** with **Veronte Harness Blue 68P**.




Fig. 13: Main connector pinout

PRI port connector - Silvus radio		Veronte Harness Blue 68P - Autopilot 4x		
PIN N°	Signal	PIN N°	Signal	Color
7	RS232_RXD	19	MUXED_RS232_TX	White-Pink
8	RS232_TXD	20	MUXED_RS232_RX	Pink-Brown
9	GND	18	GND	Gray-Brown

9.2.2.3 Silvus radio configuration

This section shows a basic configuration for Silvus radios.

9.2.2.3.1 First Steps

1. Connect antennas (or attenuators) with male TNC ends to 2 RF ports.
2. Connect power supply to power port on PRI cable.
3. Connect non-forked female side of PRI cable to radio's PRI port.




Figure 3 StreamCaster 4200E Ruggedized Enclosure

- 1 RF Channels 1-2 Connectors [TNC Female]
- 2 Power Switch [15-Position Rotating]
- 3 Power (EB Version Only, 9-20V), Ethernet, and Serial Port Connector [ODU GK0YAR-P10UC00-000L]
- 4 Bi-Color Status LED
 - Red – Radio is in the process of booting up
 - Flashing Green – Radio is fully booted but not wirelessly connected to any other radio
 - Green – Radio is wirelessly connected to at least one other radio

Fig. 14: Silvus connectors

4. When looking at the rotary multi position switch from the top, pull the knob towards you while rotating the knob towards the 1 position. This turns radio on. LED indicator will turn to fix red.
5. In order to access the StreamScape graphical user interface (GUI), connect Ethernet (RJ45) connector of PRI cable to Ethernet port of laptop/computer.
6. Make sure computer is set to static IP address on same subnet as radio. The following substeps clarify how to

set the IP address:

6.1. Open network and sharing menu and click **Change adapter settings**.




Fig. 15: Ethernet connection 1

6.2. Select **Local Area Connection**, right click, and select **Properties**.




Fig. 16: Ethernet connection 2

6.3. Select **IPv4** and click **Properties**.




Fig. 17: Ethernet connection 3

6.4. Set **IP address** to 172.20.XX.YY (e.g. if the IP of the radio is 172.20.178.203, set the IP 172.20.178.200) and **Subnet mask** to 255.255.0.0. Click **OK**.




Fig. 18: Ethernet connection 4

7. Wait for LED indicator to turn to blinking green.
8. Access **StreamScape** GUI in web browser. To access, enter IP address of radio into web browser and press enter.

Note: Latest version of Firefox or Google Chrome are preferred. Internet Explorer or others are not recommended.




Fig. 19: Silvus initial menu

9. User manual can be accessed by clicking the book icon in the GUI (Next to **Basic Configuration** in the previous screenshot).

9.2.2.3.2 Basic radio configuration

Once the website has been accessed, follow the steps below which show the parameters that need to be modified for correct operation and pairing of the radios.

Note: After making changes to each window, it is important to click on **Save and apply**.

1. Basic Configuration.




Fig. 20: Basic configuration panel

- **Frequency (MHZ):** This defines the frequency of the signal. There is a drop-down menu for frequency selection. We recommend 2220 MHz.

Warning: Be careful when choosing the frequency. The user may see interference with the Wifi frequency band, consult the radio spectrum.

- **Bandwidth:** This defines the RF bandwidth of the signal. Default value.
- **Network ID:** Network ID allows for clusters of radios to operate in the same channel, but independently. **A radio with a given Network ID will only communicate with other radios with the same Network ID.**
- **Link Distance (meters):** Set to an approximate maximum distance between any two nodes in meters. It is important to set the link distance to allow enough time for packets to propagate over the air. **It is recommended to set the link distance 10-15% greater than the actual maximum distance.**
- **Total Transmit Power (requested):** This defines the total power of the signal (power is divided equally between the radio antenna ports). Set the appropriate power for each application. The power that has been set is small, as it is sufficient for our tests.
- **Routing Mode:** As *Large Network* mode requires a license and is not available outside USA, we set *Legacy* mode.

2. Advanced configuration.




Fig. 21: Advanced configuration panel

- **Transmit/Receive Channels:** Allows user to enable or disable each channel on the radio for TX/RX (each RF port is a channel). We have enabled both channels.

3. Networking. Multicast.




Fig. 22: Multicast panel

- **Default Multicast Algorithm:** Broadcast.
- **Custom Pruning/Augmenting:** Disable.

4. Serial/USB Setup




Fig. 23: RS-232 settings

- **Serial Port Setup:** RS-232.
- **RS-232 Serial Port Settings**
 - The value of the **Baudrate**, **Data Bits**, **Parity** and **Stop Bits** parameters must be the same as those configured in [External radios - Integration examples](#) section of the **1x PDI Builder** user manual.
 - **Software Flow Control:** Disable.
 - **Transport Protocol:** We recommend **UDP**. If no data loss can be tolerated, change this setting to TCP on the radio corresponding to the **Veronte Autopilot 4x**.
 - **Peer IP:** This should be the IP address of the radio on the other end of the RS-232. In this example, we must set the IP address of the radio linked to the **BCS**.

Note: Both radios (the one connected to the BCS and the one connected to the Autopilot 4x), have the same configuration except for the **Peer IP**.




Fig. 24: Peer IP in radio linked to the GND unit

In addition to these settings, different configurations can be stored in the same radio, on the **Multi-Position Switch** panel. The user can select the one that will work, with the radio's switch position.




Fig. 25: Multi-Position Switch panel

In this example only one configuration has been created.

With the above settings the configuration is finished. Furthermore, this configuration can be saved and downloaded in the **Settings Profile** window of the Configuration Profiles section.




Fig. 26: Settings Profile panel

Before downloading the configuration, it is necessary to save it.




Fig. 27: Save settings




Fig. 28: Download settings

After configuring both radios with these settings they should be paired. Therefore, if we connect them to the power supply, when we switch them on, the LED will turn from fix red to fix green, this indicates that it is connected to at least one radio. Also, if we connect only one of them to the computer, we can access the **StreamScope** GUI of both. And, in the **Network Topology** window of the Network Management section, we can see the link between them.




Fig. 29: Connection between radios

9.2.2.4 Silvus radio configuration in 1x PDI Builder

The necessary configuration of Silvus radio in 1x PDI Builder is described in the [External radios - Integration examples](#) section of the **1x PDI Builder** manual.

9.3 External Sensors

9.3.1 Temperature sensor LM335



Fig. 30: LM335 sensor

The **LM335** is an analogical temperature sensor that measures temperatures from -40°C to 100°C.

It changes the voltage according to the temperature measured and therefore the connection to the autopilot is performed using the ADC pins.

9.3.1.1 Hardware installation

The following wiring is necessary to connect a sensor to the autopilot:




Fig. 31: LM335 - 4x wiring

The **LM335** sensor can share voltage supply with the **Autopilot 4x**. However, the impedance of the resistor **R** must vary with the voltage; since the sensor requires a forward current between 0.4 and 5 mA to operate. We recommend to use a resistor as high as possible complying with the following equation:

$$\frac{V_{in} - 2.33}{510^{-3}} < R < \frac{V_{in} - 3.73}{510^{-4}}$$

Where **R** is the value of the resistor (ohms) and **V_{in}** is the supply voltage (V). The following table shows a list of examples of a tested resistor for each voltage supply. Obtaining an error average of 1.5 °C.

V _{in} (V)	R (kohms)
6.5	5
12	16
24	37
36	60

The **Vout** pin has to be connected to an analog input of the **Main connector**.




Fig. 32: Main connector pinout

Analog pins of Main Connector. Use one			LM335 circuit
PIN N°	SIGNAL	COLOR	SIGNAL
22	ANALOG_3	Brown – Blue	Vout
23	ANALOG_4	White – Red	
38	ANALOG_0	Red	
39	ANALOG_1	Black	
40	ANALOG_2	Violet	

Supply voltage of Main connector. Use the corresponding to the autopilot 1x			LM335 circuit
PIN N°	SIGNAL	COLOR	SIGNAL
64	BAT_2	Yellow	V+
67	BAT_1	Blue	
68	BAT_0	Red	

Ground pins of Main Connector. Use one			LM335 circuit
PIN N°	SIGNAL	COLOR	SIGNAL
9	GND	Black	GND
18		Gray – Brown	
27		Grey – Green	
33		Green	
41		Gray – Pink	
44		Brown –Green	
47		White – Gray	
48		Gray – Brown	
59		Pink – Green	
63		Green	
65		Grey	
66		Pink	

9.3.1.2 Software installation

Once connected, the temperature can be monitored in **1x PDI Builder** by using the variables ADC1 to ADC5. The wiring *explained previously* obtains a relationship of Temperature and **Vout** as follows:

$$T = V_{out}100 - 273$$

Where **T** is the measured temperature (in °C, since 273 is subtracted in the formula) and **Vout** the output voltage of the *previous circuit*.

The integration of this device with **1x PDI Builder** is explained in the **LM335 with Autopilot 4x - Integration examples** section of the **1x PDI Builder** manual.

9.4 Joysticks

To control an aircraft with **Veronte Autopilot 4x** using a joystick, it requires a PPM as output signal with 3.3 V. Connect the PPM of the trainer port to a I/O of **Autopilot 4x** and configure that pin as the radio input in **1x PDI Builder**.

Note: EQEP pins can be used to connect a joystick, but I/Os are recommended instead.

PIN	SIGNAL	TYPE	INTERNAL DOMAIN	POWER	COMMENTS
1	I/O_0_MUXED	I/O	A		MUXED PWM / Digital I/O signal (0-3.3V)
2	I/O_1_MUXED	I/O	B		
3	I/O_2_MUXED	I/O	A		
4	I/O_3_MUXED	I/O	B		
5	I/O_4_MUXED	I/O	A		
6	I/O_5_MUXED	I/O	B		
7	I/O_6_MUXED	I/O	A		
8	I/O_7_MUXED	I/O	B		
9	GND*	GROUND			Ground pin for signals 1-8
10	I/O_8_MUXED	I/O	A		MUXED PWM / Digital I/O signal (0-3.3V)
11	I/O_9_MUXED	I/O	B		
12	I/O_10_MUXED	I/O	A		
13	I/O_11_MUXED	I/O	B		
14	I/O_12_MUXED	I/O	A		
15	I/O_13_MUXED	I/O	B		
16	I/O_14_MUXED	I/O	A		
17	I/O_15_MUXED	I/O	B		
18	GND*	GROUND			Ground pin for signals 10-17
55	EQEP_A	INPUT	A for autopilots 1 and 2 B for autopilot 3		Encoder quadrature redundant input A (0-5V)
56	EQEP_B	INPUT			Encoder quadrature redundant input B (0-5V)
57	EQEP_S	INPUT			Encoder strobe redundant input (0-5V)
58	EQEP_I	INPUT			Encoder index redundant input (0-5V)
59	GND*	GROUND			Ground pin

Veronte autopilots **4x** and **1x** are compatible with standard PPM signals, Futaba radios between 8 and 12 channels are recommended.



Fig. 33: Futaba T10 Joystick



Pin	Designation	Connector
SHIELD	GROUND	
1	V_{ENCODER}	
2	PPM_{OUT}	
3	PPM_{IN}	
4	V_{ENC2}	
5	V_{BATTERY}	
6	UNKNOWN	
Pin	Designation	Connector
1	NC	
2	GROUND	
3	PPM_{OUT}	
4	V_{BATTERY}	
5	V_{ENCODER}	
6	PPM_{IN}	

Fig. 34: Futaba T10 pinout




Fig. 35: PPM signal example

As default, channel 8 is reserved for manual / auto switch. High level is used for automatic flight and low level for manual control. This channel can be configured on **1x PDI Builder**.

Warning: Caution!! PPM signal must be into the **Veronte Autopilot 4x** voltage ranges. Some joysticks may need an adaptation board, please ask our team to check compatibility.

Connector for harness is provided with 3.5 mm stereo plug connector as follows:




Fig. 36: PPM pinout





Fig. 37: PPM connector

TROUBLESHOOTING

In case of any issue with an **Autopilot 1x** located in **Autopilot 4x**, read the [Troubleshooting](#) section of the **1x PDI Builder** user manual . Otherwise, in case of any issue with the **Management Board**, read the [Troubleshooting](#) section of the **4x PDI Builder** user manual .

Warning: Select your version before reading any user manual for software. The following image shows where to select a version from any Embention user manual.



10.1 Maintenance mode

Maintenance mode is the main troubleshooting tool that Veronte devices have at the user disposal. While in **maintenance mode**, all communication channels are enabled by default, so it is possible to connect with them through any of its configuration interfaces, no matter its current configuration.

The main use of **maintenance mode** is to solve issues related to the current configuration, mainly related with communication or memory writing issues.

The **maintenance mode** allows to perform actions such as force the load of a new configuration file or to format the SD card.

If at some point the communication with an inner **autopilot 1x** or the **Management Board** is lost, it is possible to use the **maintenance mode** to restore a previous state of the configuration (as long as it was exported previously), format

the SD card to start over or update the unit's firmware.

Tip: It is strongly recommended to always use **maintenance mode** to load a new configuration that is very different from the current one.

10.2 How to enter in maintenance mode

There are three ways to enter in **maintenance mode**: using software, power supply or I2C pins.

10.2.1 Using software to enter in maintenance mode

To establish the state of an inner **Autopilot 1x** as **maintenance mode** with software, read the [Maintenance Mode - Troubleshooting](#) section of the **1x PDI Builder** user manual.

To use the **maintenance mode** for the **Management Board** with software, read the [Maintenance Mode - Troubleshooting](#) section of the **4x PDI Builder** user manual.

10.2.2 Using the power supply to enter in maintenance mode

When communication with the **Autopilot 1x** or the **Management Board** is lost, it is possible to active **maintenance mode** using the power supply input.

In order to active **maintenance mode**, power cycle the **Veronte Autopilot 1x** or the **Management Board** repetively with a period of 1 second. After 30 cycles, the device will enter in **maintenance mode**.

Fig. 1: **How to power cycle an autopilot**

Autopilot 1x and **Management Board** might enter in **maintenance mode** if a problem with the power supply is detected upon boot up (voltage or current is out of range).

10.2.3 Using the I2C pins to enter in maintenance mode

To use a **Management Board** with **maintenance mode** employing I2C, connect both I2C pins each other, then power up the **Management Board** and the three inner autopilots. Both pins are SCL_A_OUT_ARB (number 39) and SDA_A_OUT_ARB (number 40) according to the [Arbiter Connector pinout](#).

Note: It is possible to enter in **maintenance mode** using I2C pins with an inner autopilot; however, it requires to connect both I2C pins and select the desired autopilot with the **Management Board**. This method is not recommended for inner autopilots, since the *software* and *power supply* methods are easier.

HARDWARE CHANGELOG

Hereby are described the main differences between the latest release of the **Veronte Autopilot 4x** hardware (v **1.8**) and the previous commercial version (v **1.2**).

Note: Note that all the technical differences related to **Autopilot 1x** are detailed in the [Hardware Changelog](#) section of the **1x Hardware Manual**.

New functionalities

- Addition of second arbitrator microcontroller
- Enhancement hardware detection mechanism for arbiters A and B
- Implementation of independent power domains for each microcontroller and different peripherals
- USB ID pin has a different functionality, now is the USB shielding connection
- 5V_BUS and 3.3V_BUS removed from Main connector
- Three UARTs (one from each Autopilot 1x) added to the redundant connector

Improvements

- Optimized power supply circuit

ACRONYMS AND DEFINITIONS

12.1 Acronyms

16 VAR	16 Bits variables (Integers)
32 VAR	32 Bits variables (Reals)
ADC	Analog to Digital Converter
AGL	Above Ground Level
AoA	Angle of Attack
ARC	Arcade Mode
AUTO	Automatic Mode
BIT	Bit Variables
BCS	Basic Control Station
CAN	Controller Area Network
CAP	Capture Module
CMB	CliMb Phase
CRU	CRuise Phase
DAA	Detect And Avoid
DC	Direct Current
DGPS	Differential GPS
ECAP	Enhanced CAP
ECEF	Earth Centered – Earth Fixed
EGNOS	European Geostationary Navigation Overlay Service
EKF	Extended Kalman Filter
FCS	Flight Control System
FHSS	Frequency Hopping Spread Spectrum
FLR	Flare Phase
FTS	Flight Termination System
GIS	Geographical Information System
GND	Ground
GNSS	Global Navigation Satellite Systems
GPIO	General Purpose Input Output
GPS	Global Positioning System
GS	Ground Speed
GS	Ground Segment
HLD	Hold Phase
HUM	Hardware User Manual
I2C	Inter-Integrated Circuit
IAS	Indicated Air Speed

continues on next page

Table 1 – continued from previous page

ID	Identification
ISM	Industrial Scientific and Medical
LED	Light-Emitting Diode
LND	Landing Phase
M2M	Machine To Machine
MSL	Mean Sea Level
NC	No Connect
OAT	Outside Air Temperature
PFD	Primary Flight Display
PID	Proportional Integral Derivative
PPM	Pulse Position Modulation
PWM	Pulse Width Modulation
QNH	Barometric atmospheric pressure adjusted to sea level
RC	Radio Control Mode
RF	Radio Frequency
RPAS	Remotely Piloted Aircraft System
RPM	Revolutions Per Minute
RS 232	Recommended Standard 232
RS 485	Recommended Standard 485
RX	Reception
SMA	SubMiniature Version A Connector
SSMA	Miniature-Sized Connector
STB	Standby Phase
SU	Servo-Output matrix
SUM	Software User Manual
TAS	True Air Speed
TKO	TakeOff Phase
TPDR	TransPonDeR
TX	Transmission
UAS	Unmanned Aerial System
UAV	Unmanned Aerial Vehicle
US	Output-Servo matrix
VTOL	Vertical TakeOff and Landing
WGS 84	World Geodetic System 84
WP	Waypoint

12.2 Definitions

- **Control Phase:** The operation is divided into phases in which the UAV has a specific performance. Each of this phases is called a control phase.
- **Control Channel:** It is each of the signals used to control a behavior or action.
- **Control Mode:** It is possible to make a manual control of the UAV by stick, assisted control and fully automatic control.
- **Actuator:** It is a mechanic device to provide force to move or “act” another mechanical device.

CONTACT DATA

You can contact Embention if you need further help and support.

Embention contact data is as follows:

Email: support@embention.com

Telephone: (+34) 965 421 115

Address: [Polígono Industrial Las Atalayas, C/ Chelín, Nº 16, CP 03114, Alicante \(España\).](#)