1x Hardware Manual

Release 4.8/1.2

Embention Sistemas Inteligentes, S.A.

Contents

| Scope of Changes | . 8 |
|--|-----|
| Introduction | . 9 |
| Typical Drone Setup | . 9 |
| Typical eVTOL Setup | 10 |
| Main Features | 10 |
| Quick Start | 12 |
| Basic Connection Diagram | 13 |
| Warnings | 13 |
| Limited Operation | 14 |
| Basic Connection for Operation | 15 |
| Technical | 17 |
| Features | 17 |
| Variants | 18 |
| ADS-B module | 18 |
| RemoteID module | 18 |
| Sensor Specifications | 19 |
| Embedded Communications | 24 |
| LOS module | 24 |
| BLOS module | 25 |
| Mechanical and Electrical Specifications | 25 |
| Dimensions | 26 |
| Interfaces | 27 |
| Connector Layout | 27 |
| Mating Connectors | 28 |
| Hardware Installation | 31 |
| Mechanical | 31 |
| Pressure lines | 31 |
| Location | 32 |
| Orientation | 32 |
| Vibration Isolation | 32 |
| Damping System | 33 |
| Dimensions | 34 |
| Assembly steps | 34 |

| Vibration analysis | 36 |
|---------------------------------------|----|
| Antenna Integration | 37 |
| Electrical | 38 |
| Power | 38 |
| Pinout | 40 |
| Harnesses | 49 |
| Dimensions | 34 |
| Pinout | 40 |
| Veronte Harness Blue 68P | 50 |
| Dev Harness 1x 4.8 | 52 |
| Flight Termination System (FTS) | 54 |
| Software Installation | 55 |
| Operation | 56 |
| Types of operations | 56 |
| Operation Architectures | 57 |
| Onboard Control Setup | 57 |
| Remote Control Setup | 57 |
| Copilot Control Setup | 58 |
| GCS-Vehicle Communications | 58 |
| LOS Communications | 59 |
| BLOS Communications | 59 |
| Wired Communications | 61 |
| GCS Interface | 61 |
| Control Stick Interface | 63 |
| Remote Control Stick | 63 |
| Onboard Control Stick | 64 |
| Virtual Stick | 64 |
| Multiple Drones/GCS - Redundancy | 65 |
| Multiple Drones - Point to Point | 65 |
| Multiple Drones - Point to Multipoint | 65 |
| Multiple GCS | 66 |
| Preparation for operation | 72 |
| Maintenance | 74 |
| Preventive maintenance | 74 |
| Software update | 74 |

| Compatible Devices | 75 |
|----------------------------------|-----|
| Actuators/Servos | 75 |
| ADS-B | 77 |
| Air Data Sensors | 79 |
| Altimeters | 80 |
| Cameras | 82 |
| Control stations | 82 |
| Datalinks | 82 |
| BLOS Communications | 82 |
| LOS Communications | 83 |
| Engines | 84 |
| Jet Engines | 84 |
| Expansion modules | 85 |
| GNSS Receivers | 85 |
| IMUs & Compass | 87 |
| Motor controllers / ESC | 89 |
| Power management units | 90 |
| Transmitters | 91 |
| Integration examples | 92 |
| Wiring connection | 92 |
| RS232 | 92 |
| Point to point | 92 |
| RS485/422 | 93 |
| Point to point | 92 |
| Daisy chain | 94 |
| Full duplex | 94 |
| Half duplex | 94 |
| CAN | 95 |
| Electrical diagram of CAN bus | 95 |
| Point to point | 92 |
| Daisy chain | 94 |
| Backbone with stubs | 97 |
| Serial to Ethernet Converter | 99 |
| Ethernet Connection in Windows 1 | .03 |
| WIZNet software configuration 1 | .05 |

| Veronte Link configuration | 109 |
|---|-----|
| 1x PDI Builder configuration | 109 |
| GPIO Wiring for External Loads | 111 |
| Connection Examples | 113 |
| Ground Stations | 113 |
| Aircrafts | 116 |
| Actuators/Servos | 117 |
| CAN | 118 |
| Pegasus PA-R-135-4 | 118 |
| Ultra Motion | 120 |
| PWM | 123 |
| Serial | 125 |
| Pegasus PA-R-135-4 | 118 |
| Volz DA26 - RS485 | 128 |
| Air Data Sensors | 131 |
| High Speed Pitot Sensor | 131 |
| Required Material | 131 |
| OAT sensor 428 of MGL Avionics | 134 |
| Altimeters | 136 |
| Lidar | 136 |
| Lidar Garmin Lite v3 | 136 |
| Lightware LW20 Lidar | 138 |
| Lightware SF20 Lidar | 140 |
| Radar | 142 |
| Ainstein CAN Radar | 142 |
| Datalinks | 145 |
| LOS | 145 |
| Amount of data sent via radiolink | 145 |
| Digi radio (as internal radio) | 145 |
| DTC (Domo Tactical) radio (SOL8SDR-C model) | 145 |
| System Layout | 145 |
| Hardware Installation | 146 |
| DTC radio configuration | 159 |
| First steps | 159 |
| Point-to-Point configuration | 165 |

| Point-to-Multipoint configuration | 175 |
|---|-----|
| DTC radio configuration in 1x PDI Builder | 180 |
| Microhard pDDL900-ENC external | 180 |
| System Layout | 145 |
| Hardware Installation | 146 |
| Microhard radio configuration | 184 |
| First steps | 159 |
| Basic radio configuration | 187 |
| Connection status radio | 205 |
| Paired radios | 206 |
| Microhard radio configuration in 1x PDI Builder | 208 |
| Microhard radio troubleshooting | 208 |
| Silvus radio (StreamCaster 4200E model) | 211 |
| System Layout | 145 |
| Hardware Installation | 146 |
| Silvus radio configuration | 214 |
| First steps | 159 |
| Basic radio configuration | 187 |
| Silvus radio configuration in 1x PDI Builder | 224 |
| Veronte SDL | 224 |
| GNSS Receivers | 225 |
| NexNav GNSS | 225 |
| IMUs & Compass | 227 |
| IMUs | 227 |
| Vectornav VN-300 | 227 |
| WitMotion HWT905-232 | 229 |
| Magnetometers | 231 |
| Magnetometer Honeywell HMR2300 | 231 |
| RS232 | 232 |
| RS485 | 234 |
| MEX as Magnetometer Honeywell HMR2300 | 235 |
| CAN | 236 |
| RS232 | 232 |
| RS485 | 234 |
| PNI RM3100 | 240 |

| RPM Sensors | 242 |
|---|-----|
| Stick | 244 |
| Veronte products | 247 |
| CEX connection | 248 |
| MC01 connection | 250 |
| MC24 connection | 251 |
| MC110 connection | 254 |
| MEX connection | 256 |
| Troubleshooting | 259 |
| Maintenance mode | 259 |
| How to enter in maintenance mode | 259 |
| Using software to enter in maintenance mode | 259 |
| Forcing maintenance mode | 260 |
| Power supply | 260 |
| I2C pins | 260 |
| Half-duplex servo does not respond | 261 |
| Hardware Changelog | 262 |
| Specifications | 262 |
| Architecture and Computing Power | 267 |
| Line of Sight Communications | 268 |
| New Features | 270 |
| Collaborative Sense & Avoid and UTM | 271 |
| Remote ID | 272 |
| ADS-B | 273 |
| Pinout changes from Autopilot 1x 4.5 | 273 |
| Acronyms and Definitions | 288 |
| Acronyms | 288 |
| Definitions | 294 |
| Contact Data | 295 |

Scope of Changes

- Version 1.0
 - Added:
 - Pegasus Serie servo integration example
 - Pegasus CAN servo integration example
 - Changed:
 - Hours of operation for Target Drone/Loitering Munition Operation in Limited Operation section
- Version 1.1
 - Fixed:
 - Dynamic pressure sensor resolution value
- Version 1.2
 - Added:
 - GPIO Wiring for External Loads integration example

Introduction



Veronte Autopilot 1x


Veronte Autopilot 1x is a sensor-redundant control system designed to control any autonomous vehicle, either aircraft such as multirotors, helicopters, planes, VTOL, blimps, etc., as well as ground vehicles, surface vehicles or many others.

Veronte Autopilot 1x hardware embeds a redundant state-of-the-art suite of sensors, together with LOS and BLOS M2M datalink radio and a DAA module based on Remote ID or ADS-B, all with reduced size and weight.

Veronte Autopilot software tools are specifically designed for the operation and configuration of the **Veronte Autopilot**. **Veronte Ops** is the software employed to operate the autopilot from a user-configurable interface and **1x PDI Builder** permits configuring the autopilot and adapting it to the specific needs of the project.


Typical Drone Setup

Veronte Autopilot is compatible with both LOS and BLOS communications for the remote control of autonomous vehicles. Physical or virtual sticks can be used for taking manual or assisted manual control at any time during the operation.



Typical eVTOL Setup

An onboard display and joystick interface are available for manned eVTOL and aerotaxi applications. Autonomous flight modes and fly-by-ware control can be configured according to the level of autonomy required.



Main Features

- **Highly configurable**: Fully user-configurable; payload, vehicle layout, control phases, control channels, etc.
- Custom routines: User-selectable automatic actions, activated on system events or periodically.
 - Actions: Phase change, activate payload, move servo, go to, onboard log, parachute release, etc.
 - Events: Waypoint arrival, inside/outside polygon, alarm, variable range, button, etc.

• **Telemetry & log**: Customizable telemetry and onboard log compatible with internal or external datalink modules, all with user-defined variables and recording frequency.


- **External sensor**: Support for external sensor connections: magnetometer, radar, LIDAR, RPM, temperature, fuel level, battery level, weather, etc.
- Payload & Peripheral: Transponder, secondary radios, satcom transceivers, camera gimbals, motor drivers, photo cameras, flares, parachute release systems, tracking antennas, pass through RS232, RS485 & CAN tunnel, etc.
- Redundant Configurations: Veronte Autopilot 4x is available for applications requiring redundancy and Veronte Autopilot DRx offers distributed redundancy architectures.

Quick Start

This user manual covers the mechanical and electrical assembly.

The software user manual explains how to configure and use the **Veronte Autopilot 1**x.

Veronte Autopilot 1x is the main element in our Flight Control System for UAS.




System Overview

Veronte Autopilot 1x contains all electronics and sensors required to properly execute all the UAV functions. A Veronte-based FCS contains the following elements:

- A **Veronte Autopilot 1x** installed in a vehicle to control. This autopilot executes GNC algorithms in real time in order to accomplish the planned mission and handle the payload.
- Veronte Ops Software dedicated to mission planning, configuration and operation. It allows the user to monitor connected UAS in real time, to interact with them and to replay previous missions for post-flight analysis.
- An Autopilot 1x GND unit or PCS linked between Veronte Ops and Veronte Autopilot 1x. They support manual and arcade modes with conventional joysticks.

Basic Connection Diagram



For further information on the Dev Harness 1x 4.8 connectors, refer to the Dev Harness 1x 4.8 - Hardware Installation section of the present manual.

Warnings

- This user manual includes references to manuals for software applications. Select your software version to read them.
- Power out of range can cause irreversible damage to the system. Please read carefully the manual before powering the system.
- Each I/O pin withstands a maximum current of 1.65 mA. See pinout for more information.
- If the unit has an ADS-B, Remote ID and/or BLOS module activated, users must **NOT power on a Veronte Autopilot 1x** without **a suitable** antenna or **50** Ω load connected to the SSMA port.

△ Caution

Do not connect this type of termination to the ports for GNSS signals, as it may damage the module.

! Danger

Disobeying this warning may damage the Autopilot 1x unit.

Limited Operation

Veronte Autopilot units are delivered with limited-operation installed and must be updated for enabling unlimited autonomous flight capabilities. **Operation limits** in Veronte Autopilot units can be **checked and unlocked in** Veronte

Ops. For more information about this, see Platform license - Platform section of **Veronte Ops** user manual.

The different operating options available are explained below:

- **Non-Limited-Operation**: Allows fully autonomous operation with no time or distance limitation.
- Limited-Operation:
 - Allows fully autonomous flight performance in LOS (500 m) with no time limitations.
 - For BLOS operations (>500 m), there is a limitation of 30min autonomous flights. After 30min from leaving LOS (500m), only internal navigation is permited and the autopilot can not estimate its position nor fly autonomously. Past this time limit, no changes of navigation source are allowed.

⚠ Caution

External navigation methods such as VectorNav can no longer be used.

 Target Drone/Loitering Munition Operation: Allows fully autonomous flight performance with no time or distance limitation. This is restricted to 25h operation from the first startup. Once the operation time has expired the unit will not be able to restart.

If you have any questions regarding the operation capabilities and limitations please contact us at sales@embention.com.

Basic Connection for Operation

The steps described below cover the basic connection of a **ground unit** necessary for operation:

1. Connect the GNSS antenna to the GNSS 1 port:



Basic connection - Step 1

2. Connect the RF antenna to the **LOS port**:



Basic connection - Step 2

3. Connect the **autopilot harness** and **power it** using the power supply:



Basic connection - Step 3

4. Connect the **harness USB** to the computer and **configure Veronte Link** to detect the Autopilot 1x:

(i) Note

For Veronte Link to detect a Veronte device, the corresponding port must be properly configured. For further information regarding Veronte Link connections, please refer to the Serial connection - Integration examples section of **Veronte Link** user manual.



Basic connection - Step 4

Technical

Features

Communications

- 2 x isolated CAN buses
- 1 x I2C bus
- ∘ 1 x USB port
- 1 x RS 232 bus
- ∘ 1 x RS 485 full duplex bus
- 1 x UART bus
- Over USB, RS 485 or RS 232 firmware update
- ∘ 1 x LOS module
- ∘ 1 x BLOS module

Input / Output

- 16 x configurable input / output signals
- ∘ 5 x analog input signals 0 3.3 V
- 1 x EQEP bus

Power

- 6.5 36 V DC required for input power supply
- 1 x output power with 3.3 V, up to 100 mA
- 1 x output power with 5 V, up to 100 mA

Protection

- EMI shield
- Against inrush current for connecting power supply

(i) Note

The number of communication ports and signals can be increased with Veronte CEX or Veronte MEX.

Variants

The **Veronte Autopilot 1x** has 3 variants:

- W/O DAA
- With Remote ID
- With ADS-B

ADS-B module

| Frequency band | 1090 MHz | |
|---------------------|--|--|
| Current consumption | Averaged 140 mA | |
| Sensitivity | -80 dBm | |
| RF output power | Configurable +30 dBm (1W), +27 dBm (0.5W), +24 dBm (0.25W) | |
| ESD protection | All lines protected | |
| MAVLink (baud) | 115200 bps | |
| AERO (baud) | 115200 bps (AT commands) | |

RemoteID module

| Frequency | WiFi & Bluetooth bands | |
|------------------------|---|--|
| Developed according to | RIN 2120-AL31 Remote identification of Unmanned Aircraft FAA Standard | |
| Parameters | Aircraft ID, position, altitude, and time mark | |
| Compatibility | FAA Remote ID Scanner App | |

Sensor Specifications

| Accelerometers (3-axis each one) | | | |
|----------------------------------|---|---|---|
| Specification | IMU 1 | IMU 2 | IMU 3 |
| Range | 16 g | 24 g | 8 g |
| Maximum shock | 20,000 g for 0.2 ms | 10,000 g/ms | 14,700 m/ sec ² |
| Sensitivity | 16,393 LSB/ (m/ sec ²) | 10,920 LSB/(m/ sec ²) | 26,756,268 LSB/(m/ sec ²) |
| Update Time | | 1 ms | |
| Error | 3 mg (RMS noise) | 190 Z axis 160 X & Y axis µg/Hz (noise density) | 0.000167 X & Y axis 0.000243 Z axis (m/sec ² / Hz) (noise density) |
| Offset | 0 mg | ± 20 mg | 0.0196 m/ sec ² |

| Gyroscopes (3-axis each one) | | | | |
|---------------------------------|--|--|--|--|
| Specification IMU 1 IMU 2 IMU 3 | | | | |
| Range | | | | |

| Gyroscopes (3-axis each one) | | | |
|------------------------------|---------------------------------|----------------------------|---|
| Specification | IMU 1 | IMU 2 | IMU 3 |
| | 125 to 2,000 °/ sec | 125 to 2,000 °/sec | 2,000 °/ sec |
| Sensitivity | 228 to 14.2 LSB/°/ sec | 262 to 16 LSB/ °/sec | 655,360 to 10 LSB/ °/sec |
| Update Time | | 1 ms | |
| RMS noise | 0.075 °/ sec | 0.1 °/ sec | 0.152 °/ sec |
| Offset | 0 °/sec | ±1°/ sec | 0.14 X & Z axis 1.4 Y axis °/sec |

| Magnetometers | | | | |
|---------------|-------------------------|-------------------|----------------|--|
| Specification | Magnetometer 0 | Magnetometer 1 | Magnetometer 2 | |
| Range | 4 G | 8 G | 11 G | |
| Sensitivity | 6,842 to 1,711 LSB/G | 4,096 LSB/G | 0.13 mG | |
| Update Time | 8.3 ms | 12.5 ms | | |
| RMS Noise | | 0.4 mG | 0.3 mG | |

| Magnetometers | | | |
|---------------|---------------------------------|----------------|----------------|
| Specification | Magnetometer 0 | Magnetometer 1 | Magnetometer 2 |
| | 3.2 X & Y axis 4.1 Z axis mG | | |
| Offset | 0 G | 0 G | 0 G |

| Static Pressure | | |
|-----------------|------------------------|------------------------|
| Specification | Sensor 1 (STATIC port) | Sensor 2 (INT port) |
| Range | 1,000 - 120,000 Pa | 30,000 - 120,000 Pa |
| Band Error | 500 Pa | 200 Pa |
| Resolution | 1.2 to 6.5 Pa | 0.5 Pa |
| Update Time | 20 ms | 31.3 ms |
| RMS Noise | 6.5 Pa | 0.35 Pa |

| Dynamic Pressure Sensor | |
|--------------------------------|--|
| Specification Pitot | |
| Range | 3 Pa (5 kt / 8 km/h sea level) to 6,900 Pa (206 kt / 382 km/h sea level) |
| Band Error | 140 Pa |

| Dynamic Pressure Sensor | | |
|--------------------------------|---------|--|
| Specification | Pitot | |
| Resolution | 0.42 Pa | |
| Update Time | 20 ms | |
| Bias | ±7 Pa | |

| GNSS Receivers | | |
|--------------------------|--|--|
| Specification | GNSS 1 & GNSS 2 | |
| Constellations | BeiDou, Galileo, GLONASS, GPS / QZSS | |
| Concurrent GNSS | 4 | |
| Bands | L2OF, L2C, E1 B/C, B2I, E5b, L1 C/A, L1OF, B1I | |
| Position Accuracy RTK | 0.01 m + 1 ppm CEP | |
| Update Rate RTK | Up to 20 Hz | |
| Anti-jamming | Active CW detection and removal, Onboard bandpass filter | |
| Anti-spoofing | Advanced anti-spoofing algorithms | |

| GNSS Receivers | | | |
|-----------------------|---|------------|-----------|
| Specification | GNSS 1 | & GNSS | 2 |
| Advanced Functions | Moving baGNSS-basestimation | ed attitud | |
| Update Time | 250 ms | | |
| Location Accuracy | Vertical 0.01 m | | |
| | Horizontal | SBAS | 1 m |
| | | RTK | 0.01 m |
| Velocity Accuracy | 0.05 m/s | | |

| Temperature | | |
|----------------|---------------------|------|
| Device | Resolution | Bias |
| IMU 1 | 256 LSB/°C (16 bit) | 15°C |
| IMU 2 | 8 LSB/°C | 1°C |
| IMU 3 | 10 LSB/°C | 5°C |
| MPU | - | 15°C |
| Magnetometer 0 | 8 LSB/°C | - |
| Magnetometer 1 | 1.25 LSB/°C | - |

| Temperature | | |
|-------------------|------------|------|
| Device | Resolution | Bias |
| Static pressure 1 | 0.01 °C | - |
| Static pressure 2 | 0.01 °C | - |

(i) Note

An external pressure sensor is required to measure below -20 °C.

Embedded Communications

LOS module

| RF baudrate | 115200 baud |
|-------------------------|---|
| Transmission power | 19 dBm |
| Receiver sensitivity | -103 dBm |
| Frequency band | ISM 2.4 GHz |
| LOS range | Depends on the antenna employed and on the user's setup |

(i) Note

External modules can be used.

BLOS module

| RF baudrate | 115200 baud | |
|-------------------------|---|--|
| Receiver sensitivity | -111 dBm | |
| Frequency band | 800 MHz, 850 MHz, 900 MHz, 1.8 GHz, 1.9 GHz, 2.1 GHz | |
| Network | UMTS/HSPA+, GSM/(E)GPRS | |
| eSIM | Included Note Its activation is optional | |

(i) Note


External BLOS modules, such as satellites, can be used.

Mechanical and Electrical Specifications

| Variable | Value |
|-------------------|---|
| Weight | W/O DAA variant: 198 g With Remote ID or ADS-B: 210 g With Damping System: + 60 g |
| Temperature range | -40 to 65 ºC |
| Protection rating | IP67 |

| Variable | Value |
|----------------------|---|
| Maximum acceleration | 32 g |
| Voltage input | 6.5 V to 36 V |
| Power consumption | 2.2 W in maintenance mode |
| | 2.2 W in normal mode with CPU at 98 %, internal LOS module off and BLOS module off |
| | 2.6 W in normal mode with CPU at 98 %, internal LOS module on and BLOS module on |

Dimensions




Veronte Autopilot 1x dimensions (mm)

M3 screws are recommended for mounting. In saline environments such as coastal and oceanic, the screw material must be stainless steel.

Interfaces

Connector Layout



Connectors

| Index | Connector | |
|-------|---|--|
| 1 | LOS SSMA connector | |
| 2 | GNSS1 SSMA connector | |
| 3 | Static pressure port (Int. D. 2.5 mm x Out. D. 4 mm) for static pressure sensor 2 | |
| 4 | Static pressure port (Int. D. 2.5 mm x Out. D. 4 mm) for static pressure sensor | |
| 5 | Dynamic pressure port (Int. D. 2.5 mm x Out. D. 4 mm) | |
| 6 | ADS-B or remote ID SSMA connector | |
| | Warning When using ADS-B or remote ID, there must be an adequate antenna or load connection to the DAA SMA. | |

| Index | Connector | |
|-------|--|--|
| 7 | GNSS2 SSMA connector | |
| | M2M SSMA connector | |
| 8 | Warning If the BLOS module is enabled, a suitable antenna must be connected to this SSMA port. The 4G Antenna with the Embention reference P000112 is recommended. | |
| 9 | 68-pin connector | |

Both static pressure ports must be used for sensor redundancy (Y tubing connection is strongly recommended).

⚠ Warning

The static pressure port 4 is always used by **Autopilot 1x** to calculate speed (using the difference of pressure between ports 4 and 5), no matter which sensor is selected in configuration.

Mating Connectors

| Index | Autopilot 1x Connector | Mating Connector |
|-------|-------------------------------------|---|
| 1 | RF antenna (SSMA Jack Female) | SSMA male Plug, low- loss cable is recommended. |
| 2, 7 | | SSMA male Plug, low- loss cable is |

| Index | Autopilot 1x Connector | Mating Connector |
|-------|--|--|
| | GNSS antenna (SSMA Jack Female) | recommended. Active Antenna GNSS: Gain min 15dB (to compensate signal loss in RF Cable) Gain max 50 dB Maximum noise figure 1.5dB Power supply 3.3V Max current 20 mA |
| 8 | M2M antenna (SSMA Jack Female) | SSMA male Plug, low- loss cable is recommended. |
| 6 | ADS-B or remote ID (SSMA Jack Female) | SSMA male Plug, low- loss cable is recommended. |
| 9 | Connector HEW.LM. 368.XLNP | Mating connector: FGW.LM.368.XLCT (Embention reference P005550) Mating harnesses available on demand: Dev Harness 1x 4.8 (Embention reference P007043) |

| Index | Autopilot 1x Connector | Mating Connector |
|-------|---------------------------|----------------------|
| | | • Veronte Harness |
| | | Blue 68P |
| | | (Embention |
| | | reference |
| | | P001114) |
| | | • HIL Harness 1x 4.8 |
| | | (Embention |
| | | reference |
| | | P007740) |
| | | |

Hardware Installation

Mechanical

Veronte Autopilot 1x is manufactured using an anodized aluminium enclosure with enhanced EMI shielding and IP protection. A high reliability connector is also provided in this version. The total weight of W/O DAA variant is 198 g and it is 210 g for versions with Remote ID or ADS-B.

Pressure lines

Veronte Autopilot 1x has three pressure input lines, two for static pressure to determine the absolute pressure and one for pitot in order to determine the dynamic pressure.

For the fittings it is recommended to use a polyurethane tube of 2.5 mm inner diameter and 4 mm outer diameter.

Pressure Intake


- Pressure intakes must be located in order to prevent clogging.
- Never install pressure intakes on the propeller flow.
- Design pressure tubing path in order to avoid tube constriction.

Static Pressure

 It is not recommended to use inside fuselage pressure if it is not properly vented.

Pitot Tube

- Pitot tube must be installed facing the airflow.
- It is recommended to install it near the aircraft's x axis in order to avoid false measures during manoeuvres.
- For low-speed aircraft it is recommended at least 6.3mm tubes to prevent any rain obstruction.





(i) Note

In case of not using an input air connector, it is recommended to remove its corresponding nut. Vibrations may move and damage intake connectors with a nut that is not fixed with a tube.


Location

The location of **Veronte Autopilot 1x** has no restrictions. You only need to configure its relative position with respect to the centre of mass of the aircraft and the GNSS antenna. The configuration of the location of **Veronte Autopilot** 1x can be easily configured using 1x PDI Builder.

Orientation

The orientation of **Veronte Autopilot 1x** has no restrictions either. You only need to configure axes with respect to the aircraft body axes by means of a rotation matrix or a set of correspondences between axes. The configuration of the orientation can be easily configured using 1x PDI Builder.

Axes are printed on the **Autopilot 1x** box. Aircraft coordinates are defined by the standard aeronautical conventions (see image below).



Aircraft Coordinates (Standard Aeronautical Convention)

Vibration Isolation

Although **Veronte Autopilot 1x** rejects noise and high-frequency vibration modes with electronic filters, there may be situations where external isolation is needed.

Autopilot 1x can be mounted in different ways in order to reject the airframe vibration, but it is recommend to use the Damping System designed for that porpuse. It covers a wide frequency range of different aircraft types.



The user should take into account that wiring should be loose enough so that vibrations are not transmitted to **Autopilot 1x**.

Damping System

Embention offers the **Damping System** as a solution to isolate **Veronte Autopilot 1x** from vibrations.



Important

Only effective with **Autopilot 1x** in horizontal position.

This damping system weighs 60 g.




Damping System



The **Damping System** is designed for hardware version **4.8** of **Autopilot** 1x.

Dimensions




Damping system dimensions (mm)

Assembly steps


To assembly the Damping System into a vehicle with an **Autopilot 1x**, read the following steps.

1. Remove the three nuts located under the platform.




Step 1

2. Screw the platform on the aircraft frame. The included screws have M3.



Step 2

3. Screw the **Autopilot 1x** on the **Damping system**.



Step 3




Result

Vibration analysis

Transmissibility (Z-axis)


Transmissibility graph, analysis of vibrations received by **Autopilot 1x**, with and without Damping System:



Transmissibility graph

Phase (Z-axis)

Phase graph, analysis of whether vibrations measured by **Autopilot 1x** are in phase or not, with and without Damping System:



Phase graph

Antenna Integration

The system uses different kinds of antennas to operate that must be installed on the airframe. Here you can find some advice for obtaining the best performance and for avoiding antenna interferences.

Antenna Installation

- Maximize separation between antennas as much as possible.
- Keep them far away from alternators or other interference generators.
- Always isolate antenna ground panel from the aircraft structure.
- Make sure the antenna is securely mounted.
- Always use high-quality RF wires minimising the wire length.
- Always follow the antenna manufacturer manual.
- SSMA connections shall be tightened applying 1Nm of torque
- For all-weather aircraft, insert SSMA lightning protectors.

GNSS Antenna

- Antenna top side must point the sky.
- Install it on a top surface with direct sky view.
- Never place metallic / carbon parts or wires above the antenna.
- It is recommended to install it on a small ground plane.
- For all-weather aircraft, insert SSMA lightning protectors.

Recommended specifications for GNSS antennas

| Specifications | Range | |
|--------------------------|--|--|
| Antenna frequency L1 | 1561.098 MHz to 1602 MHz | |
| Antenna frequency L2 | 1207.14 MHz to 1246 MHz | |
| Amplifier gain | 17 dB to 35 dB | |
| | 40 dB | |
| Out-of-band rejection | Note Higher values are preferable. 30 dB is considered the minimum acceptable value. | |
| Polarization | RHCP (Right-Hand Circular Polarization) | |
| Minimum supply voltage | 2.7 V to 3.3 V | |
| Maximum supply current | 50 mA | |

Electrical

Power

Veronte Autopilot 1x can use unregulated DC **(6.5V to 36V)**. Pins used for power and ground are the same for both Ground and Air configurations.

LiPo batteries between 2S and 8S can be used without regulation needs. Remaining battery level can be controlled by the internal voltage sensor and by configuring the voltage warnings by software.

For higher voltage installations, voltage regulators must be used. For dimensioning voltage regulators take into account that a blocked servo can activate regulator thermal protection.


△ Caution

Caution!! Power **Veronte Autopilot 1x** out of range can cause irreversible damage to the system. Please read carefully the manual before powering the system.

Autopilot 1x and servos can be powered by the same or different batteries. In case of having more than one battery on the system, a single point ground union is needed to ensure a good performance. The ground signal should be isolated from other noisy ground references (e.g. engines). If all grounds need to be connected, the connection should be made on the negative pole of the battery.

It is recommendable to use independent switches for autopilot and motor/ actuators. During the system initialization, the PWM signal will be set to low level (0V), please make sure that actuators/motor connected support this behaviour before installing a single switch for the whole system.

Pinout



Connector for Autopilot 1x - HEW.LM.368.XLNP (frontal view)

△ Warning

Check the pin number before connecting. The color code is repeated 3 times due to the amount of pins. First section (yellow) corresponds to pins 1-30, the second section (blue) to pins 31-60 and the third one (red) to pins 61-68. Pin number increases counterclockwise following the black line of the picture above.

| PIN | Signal | Туре | Description | |
|-----|--------|------|-----------------------------|---|
| 1 | I/O 0 | | | |
| 2 | I/O 1 | I/O | Р | Pins for PWM or digital I/O signals (0-3.3V). |
| 3 | I/O 2 | | Protected against ESD | |
| 4 | I/O 3 | | 1/0 | and short circuit. Warning |
| 5 | I/O 4 | | Each pin withstands a | |
| 6 | I/O 5 | | maximum current of 1.65 mA. | |
| 7 | I/O 6 | | | |

| PIN | Signal | Туре | Description |
|-----|----------|--------|---|
| 8 | I/O 7 | | |
| 9 | GND | GROUND | Ground signal for actuators 1-8. |
| 10 | I/O 8 | | |
| 11 | I/O 9 | | Pins for PWM or digital I/O |
| 12 | I/O 10 | | signals (0-3.3V). Protected against ESD |
| 13 | I/O 11 | 1/0 | and short circuit. |
| 14 | I/O 12 | I/O | Warning Each pin withstands a |
| 15 | I/O 13 | | maximum current of |
| 16 | I/O 14 | | 1.65 mA. |
| 17 | I/O 15 | | |
| 18 | GND | GROUND | Ground signal for actuators 9-16. |
| 19 | RS232 TX | Output | RS 232 Output (-13.2V to 13.2V Max, -5.4V to 5.4V Typical). Protected against ESD and short circuit. |
| 20 | RS232 RX | Input | RS 232 Input (-25V to 25V Max, -0.6V Low and 2.4V High Threshold). Protected against ESD and short circuit. |

| PIN | Signal | Туре | Description |
|-----|----------|--------|---|
| 21 | GND | GROUND | Ground signal for buses. |
| 22 | ANALOG_3 | Input | Input 0-3.3V. Protected against ESD and short circuit. |
| 23 | ANALOG_4 | Input | Input 0-3.3V. Protected against ESD and short circuit. |
| 24 | GND | GROUND | Ground signal for buses. |
| 25 | CANA_P | I/O | CANbus interface, up to 1Mbps. Protected against ESD. |
| 26 | CANA_N | I/O | Twisted pair with a 120 ohms Zo recommended. Protected against ESD. |
| 27 | 4XV_WD | I/O | Reserved. Do not connect. |
| 28 | CANB_P | I/O | CANbus interface. It supports data rates up to 1 Mbps. Protected against ESD. |
| 29 | CANB_N | I/O | Twisted pair with a 120 ohms Zo recommended. Protected against ESD. |
| 30 | GND | GROUND | Ground signal for buses. |
| 31 | I2C_CLK | Output | |

| PIN | Signal | Туре | Description |
|-----|----------|--------|---|
| | | | Clock line for I2C bus (0.3V to 3.3V). Protected against ESD and short circuit. |
| 32 | I2C_DATA | I/O | Data line for I2C bus (0.3V to 3.3V). Protected against ESD and short circuit. |
| 33 | GND | GROUND | Ground for 3.3V power supply. |
| 34 | 3.3V | Power | 3.3V - 100mA power supply. Protected against ESD short circuit with 100mA resettable fuse. |
| 35 | GND | GROUND | Ground for 5V power supply. |
| 36 | 5V | Power | 5V - 100mA power supply. Protected against ESD short circuit with 100mA resettable fuse. |
| 37 | GND | GROUND | Ground for analog signals. |
| 38 | ANALOG_0 | Input | Analog input 0-3.3V. Protected against ESD and short circuit. |
| 39 | ANALOG_1 | Input | |

| PIN | Signal | Туре | Description |
|-----|-----------|--------|--|
| | | | Analog input 0-3.3V. Protected against ESD and short circuit. |
| 40 | ANALOG_2 | Input | Analog input 0-3.3V. Protected against ESD and short circuit. |
| 41 | 4XV_A | I/O | Reserved. Do not connect. |
| 42 | FTS1_OUT | Output | Deadman signal from comicro. Protected against ESD and short circuit. |
| 43 | FTS2_OUT | Output | !SystemOK Bit. Protected against ESD and short circuit. |
| 44 | 4XV_B | I/O | Reserved. Do not connect. |
| 45 | UARTA_TX | Output | Microcontroller UART. |
| 46 | UARTA_RX | Input | Microcontroller UART. |
| 47 | GND | GROUND | Ground signal comicro power supply. |
| 48 | V_ARB_VCC | POWER | Veronte comicro power (6.5V to 36V). Protected against ESD and reverse polarity. |

| PIN | Signal | Туре | Description |
|-----|--------------|--------|--|
| 49 | FTS3_OUT_MPU | Output | MPU alive voting signal, to use with 4xVeronte. It is a Square Wave at [100,125] Hz. Protected against ESD and short circuit. |
| 50 | OUT_RS485_P | Output | Non-inverted output from RS485 bus (-7V to 12V Max, -2.3V to 2.3V Typical). Protected against ESD and short circuit. |
| 51 | OUT_RS485_N | Output | Inverted output from RS485 bus (-7V to 12V Max, -2.3V to 2.3V Typical). Protected against ESD and short circuit. |
| 52 | IN_RS485_N | Input | Inverted input from RS485 bus (-7V to 12V Max, -2.3V to 2.3V Typical). Protected against ESD and short circuit. |
| 53 | IN_RS485_P | Input | Non-inverted input from RS485 bus (-7V to 12V Max, -2.3V to 2.3V Typical). Protected against ESD and short circuit. |

| PIN | Signal | Туре | Description | |
|-----|----------|------|--|--|
| 54 | OUT_GND | GND | Ground for RS-485 bus. Warning This is not a common GND pin. | |
| 55 | EQEP_A | I/O | DIGITAL output / DIGITAL input / Encoder quadrature input A (0-3.3V). Protected against ESD and short circuit. | |
| 56 | EQEP B | I/O | DIGITAL output / DIGITAL input / Encoder quadrature input A (0-3.3V). Protected against ESD and short circuit. | |
| 30 | <u> </u> | I/O | ,, - | Warning Only use it as digital I/ O with Veronte units of Hardware version 4.5 or lower. |
| 57 | EQEP_S | I/O | DIGITAL output / DIGITAL input / Encoder quadrature input A (0-3.3V). Protected against ESD and short circuit. | |
| 58 | EQEP_I | I/O | | |

| PIN | Signal | Туре | De | scription |
|-----|----------------|--------|---|---|
| | | | inpu quadr (0-3.3 against | output / DIGITAL it / Encoder ature input A V). Protected ESD and short circuit. |
| 59 | GND | GROUND | Ground | for encoders. |
| 60 | V_USB_DP | I/O | | USB data line. ed against ESD. |
| 61 | V_USB_DN | I/O | | USB data line. ed against ESD. |
| 62 | USB_SHIELD_GND | GROUND | USB ca | ble shielding. |
| 63 | FTS_OUT_MPU | Output | Abort mission voting signal 1 from MPU, to use with 4x Veronte. | Bit Low (0 V) if mission OK. High (3.3V) if mission wants to be terminated. Both pins are protected against ESD |
| | | | | and short circuit. |

Warning

Each pin withstands 2.5 A of maximum current.

| PIN | Signal | Туре | Description |
|-----|--------------|--------|--|
| 64 | FTS2_OUT_MPU | Output | Abort mission voting signal 2 from MPU, to use with 4x Veronte. |
| 65 | GND | GROUND | Veronte ground input. |
| 66 | GND | GROUND | Veronte ground input. |
| 67 | VCC | POWER | Veronte power supply |
| | | | (6.5V to 36V). Protected against ESD and reverse polarity. |
| 68 | VCC | POWER | Warning Both pins are common. They MUST be connected to the same power supply. |

⚠ Warning

Remember!! All GND pins are common. Note that pin 54 is not a common GND pin.

Visit the following sections to know how to wire the **Autopilot 1x** to other devices via:


- RS232
- RS485/422
- CAN

To know the differences between version 4.5 and 4.8 (this one), read the Pinout changes from Autopilot 1x 4.5 - Troubleshooting section of the present manual.

Harnesses

A wire harness is a structured assembly of cables and connectors used to organize and manage wiring in electrical and electronic systems. It is designed to ensure a tidy and secure installation of cables, preventing tangles, electromagnetic interference, and facilitating maintenance.

Veronte Autopilot 1x 4.8 has two compatible harnesses:




Dimensions

• Harness Blue 68P wire gauge: 22 AWG


• Cables length: 52 cm

Harness plug dimensions:



Connector FGW.LM.368.XLCT dimensions (cm)

Pinout



Harness plug - FGW.LM.368.XLCT (frontal view)

Veronte Harness Blue 68P

The pinout of this harness is the same as the Veronte Autopilot 1x pinout above. The **color code** of the harness wires is given below.

Marning

Check the pin number before connecting. The color code is repeated 3 times due to the amount of pins. First section (yellow) corresponds to pins 1-30, the second section (blue) to pins 31-60 and the third one (red) to pins 61-68. Pin number increases following the black line of the pictures above: counterclockwise for the connector and clockwise for the plug.

| PIN | Color Code | PIN | Color Code |
|-----|----------------|-----|----------------|
| 1 | White | 35 | Gray |
| 2 | Brown | 36 | Pink |
| 3 | Green | 37 | Blue |
| 4 | Yellow | 38 | Red |
| 5 | Gray | 39 | Black |
| 6 | Pink | 40 | Violet |
| 7 | Blue | 41 | Gray - Pink |
| 8 | Red | 42 | Red - Blue |
| 9 | Black | 43 | White - Green |
| 10 | Violet | 44 | Brown - Green |
| 11 | Gray - Pink | 45 | White - Yellow |
| 12 | Red - Blue | 46 | Yellow - Brown |
| 13 | White - Green | 47 | White - Gray |
| 14 | Brown - Green | 48 | Gray - Brown |
| 15 | White - Yellow | 49 | White - Pink |
| 16 | Yellow - Brown | 50 | Pink - Brown |
| 17 | White - Gray | 51 | White - Blue |
| 18 | Gray - Brown | 52 | Brown - Blue |
| 19 | White - Pink | 53 | White - Red |


| PIN | Color Code | PIN | Color Code |
|-----|----------------|-----|----------------|
| 20 | Pink - Brown | 54 | Brown - Red |
| 21 | White - Blue | 55 | White - Black |
| 22 | Brown - Blue | 56 | Brown - Black |
| 23 | White - Red | 57 | Gray - Green |
| 24 | Brown - Red | 58 | Yellow - Green |
| 25 | White - Black | 59 | Pink - Green |
| 26 | Brown - Black | 60 | Yellow - Pink |
| 27 | Gray - Green | 61 | White |
| 28 | Yellow - Green | 62 | Brown |
| 29 | Pink - Green | 63 | Green |
| 30 | Yellow - Pink | 64 | Yellow |
| 31 | White | 65 | Gray |
| 32 | Brown | 66 | Pink |
| 33 | Green | 67 | Blue |
| 34 | Yellow | 68 | Red |

Dev Harness 1x 4.8

This harness has some connectors already implemented for easy operation. Below is detailed information on which pins these connectors are connected to:

| Connector | PIN | Signal |
|-----------------------|-----|----------------|
| Main VCC | 65 | GND |
| | 66 | GND |
| | 67 | VCC |
| | 68 | VCC |
| SuC VCC | 47 | GND |
| | 48 | V_ARB_VCC |
| RS232 Connector | 19 | RS 232 TX |
| | 20 | RS 232 RX |
| | 21 | GND |
| Maintenance Button | 31 | I2C_CLK |
| | 32 | I2C_DATA |
| Jack Connector | 18 | GND |
| | 55 | EQEP_A |
| USB | 60 | V_USB_DP |
| | 61 | V_USB_DN |
| | 62 | USB_SHIELD_GND |

Flight Termination System (FTS)



Flight Termination System


Veronte Autopilot 1x integrates two different FTS pins (42 and 43):

FTS1 - Deadman (Pin 42): On this pin, **Autopilot 1x** outputs a square wave with $A = \sim 5$ ms and $B = \sim 5$ ms (3.3V). Its frequency can be higher right after the rebooting (around 300-400Hz), but A and B must be always < 8ms.


FTS2 - !SystemOK (Pin 43): Its output is 0V when the system is working as expected and 3.3V when some error is detected. In detail, pin 43 goes high if A > 8ms or B > 8ms in the deadman signal sent by the Main Processor Unit (MPU).

Software Installation

In order to configure and use **Veronte Autopilot 1x**, there are two ways to connect it to a computer: USB or serial.



USB connection



Serial connection

To install the required software and configure **Veronte Autopilot 1x**, read the 1x Software Manual.

An example of the configuration required for a correct communication between the PC and **Autopilot 1x** can be found in the AP communication with PC - Integration examples section of the **1x PDI Builder** user manual.

Operation

Types of operations

Veronte Autopilot 1x is an advanced system designed to enable the operation of autonomous vehicles, offering three control modes: automatic, assisted, and manual. This versatile autopilot can be used in both uncrewed and manned vehicles, integrating a **FLY-BY-WIRE** system that ensures precise and safe control at all times.

One of the main advantages of the Veronte Autopilot 1x is its configurability, allowing it to be adapted for different operational needs. Depending on the chosen configuration, the system can handle various types of takeoff, such as runway or catapult launches, among others.

Veronte Ops is the Veronte application dedicated to operating the system, providing an intuitive interface for mission management and monitoring. Additionally, for more flexibility, the system can also be operated through VCP (Veronte Communication Protocol), enabling the creation of custom control stations or integration with onboard mission computers for more specific or advanced applications.

In summary, **Autopilot 1x** stands out for its versatility, ease of integration, and customization options, offering a comprehensive solution for a wide range of autonomous vehicle applications.

In addition, for the different types of operations, the user may need to make different connections, configurations and/or integrations with external devices with **Veronte Autopilot 1x**. Therefore:

- Examples of how to make connections to Autopilot 1x such as wiring
 connection via CAN or with a Serial to Ethernet Converter are detailed
 in the Integration examples section of this manual.
- Examples of how to integrate **Autopilot 1x** with external devices such as datalinks are detailed in the Datalinks Integration examples section of the present manual.

Please take a look at these sections for further explanations.

This section summarizes a list of possible options to operate an **Autopilot 1x** in different situations.




Most of the following diagrams can be used independently or combinated, to create redundant systems or backup solutions.

Operation Architectures

Veronte Autopilot 1x allows for a wide variety of communication and control solutions to adapt to each mission and platform specifications.


Onboard Control Setup

1x allows to control aircrafts (such as eVTOLs) by pilots on board in a flight deck. Pilots can use as controller joysticks, computers, tablets or any device able to communicate through PPM, CAN Bus, RS232 or RS485.



Remote Control Setup

The following image shows the standard Veronte System Layout for remote operation.




In the standard remote layout, an Operator (Internal Pilot) controls the UAV from the Ground Station using **Veronte Ops**.

Additionally, a Safety Pilot (External Pilot) is connected to the Ground Station using a radio controller. The stick commands are read by the Ground Unit and re-routed to the Air Unit. The Safety Pilot is able to take control of the flight at any point using an automation.

Copilot Control Setup

Veronte system allows integration with onboard mission computers for more specific or advanced applications.




GCS-Vehicle Communications

The following are some examples and possible solutions for establishing communication between the ground control station and the vehicle.

LOS Communications

The following diagram shows the different options of GCS and in-vehicle solutions to establish correct Line of Sight (LOS) communications between them.



Depending on the requirements and needs of their mission, users can choose as GCS:

- Autopilot 1x with its internal LOS module
- PCS
- Autopilot 1x with an external LOS Datalink
- LOS Datalink

And on the vehicle side:


- Autopilot 1x with its internal LOS module
- Autopilot 1x with an external LOS Datalink

BLOS Communications

Veronte Cloud enables secure and efficient Beyond Line of Sight (BLOS) communication between the autopilot onboard a vehicle and the control station. It supports various communication methods, offering a flexible architecture to suit different operational requirements:

- Autopilot 1x Internal Module: Embedded 4G module within Autopilot
 1x.
- LTE/4G/5G Module: External LTE module for wireless communication.
- **Satcom Module**: Satellite communications device for global coverage.

• Starlink: High-bandwidth, global communications module.



These communication methods can be used both at the **ground control station** and **onboard**, enabling seamless switching between methods or simultaneous use for redundancy and enhanced reliability. They can also be combined to meet specific project requirements.

Control Station Connectivity Options

The control station connects to **Veronte Cloud** through two primary methods:

Option A: Direct PC Internet Connection

The **control station PC** connects directly to the Internet for communication with **Veronte Cloud**. This can be achieved using any available means of Internet communication:

- Ethernet or Wi-Fi
- LTE/4G/5G
- Satellite Communication (Satcom)
- Starlink
- Option B: Connection via Veronte PCS/1x

The **control station PC** connects to the **Veronte PCS/1x module**, which manages the connection to the BLOS datalink module. The **PCS/1x** module supports:

- Its internal 4G module for direct connectivity.
- External communication modules (LTE/4G/5G, Satcom, Starlink, etc.).

This setup enhances communication reliability by leveraging Veronte's dedicated hardware for connection management and enabling the use of additional sensors integrated within the **PCS/1x** module.


Onboard Connectivity Options

For onboard BLOS communications, **Veronte Autopilot 1x** system offers two main methods:

- Option C: Internal 4G Module in Veronte Autopilot 1x
 Autopilot 1x comes equipped with an internal 4G module that connects directly to Veronte Cloud. This option is compact and does not require additional external hardware.
- Option D: External Module Connected to Autopilot 1x
 The autopilot can integrate an external communication module (LTE/4G/5G, Satcom, Starlink, etc.) to enable BLOS communication with
 Veronte Cloud. This provides flexibility and allows for customization based on specific mission or environmental needs.

Wired Communications

For operations where the control station is directly connected to the onboard autopilot by cable.




GCS Interface

This diagram represents some of the many ways to establish communication between the different parts of a Ground Control Station setup.

(i) Note

In a Ground Control Station setup there is usually a PC on one side and an **Autopilot 1x** with its internal LOS module, an **Autopilot 1x** with an **external LOS Datalink** or a **PCS** on the other side.



Direct connection

- The PC can directly connect a PCS via USB, RS, Ethernet or Wifi.
- The PC can directly connect an Autopilot 1x with its internal LOS module or Autopilot 1x with an external LOS Datalink via USB/RS.

Combined connections

Below are different connection methods that enable communication between the **PC** and an **Autopilot 1x** with its internal LOS module, an **Autopilot 1x** with an **external LOS Datalink** or a **PCS** via an additional device:

- PC connected via RS to a LOS Datalink, establishing a datalink connection to the other side of the GCS setup.
- Connection through an Ethernet-to-RS converter, i.e. Ethernet on the PC side and RS on the other side.
- The PC connects via **wifi** and the wifi modem then communicates with the other side of the GCS setup through an **Ethernet-to-RS converter**.


Control Stick Interface

This section presents the different types of manual control from stick to the onboard autopilot.

Veronte allows for a wide variety of pilot interface solutions in order to interact with manual flight modes, assisted flight modes (arcade) or payloads.

Remote Control Stick

A wide variety of controllers can be used to pilot manually aircrafts, such as RC transmitters, pedals, sticks or buttons. Veronte software allows the use of any device that is detected as a remote controller by the operative system.



Although the most common way of control is to directly connect a **stick** via **PPM**, **RS** or **CAN** to a control station (**PCS/1x**) which then communicates with the onboard autopilot,


 It is possible to establish a link connection between a stick and a stick receiver integrated in the vehicle, which is connected via PPM to Autopilot 1x.

This allows for a backup manual channel when there is a main channel loss and an emergency manual landing is needed. Recommended for initial developement stages where automatic landing phases are not defined yet.

- A Veronte Stick allows the connection of USB sticks to a control station (PCS/1x), converting USB to PPM. Then, the GCS communicates with the onboard autopilot for control.
- A USB stick can be connected directly to the PC to establish communication with the onboard autopilot for control.

Onboard Control Stick

In operations with pilots onboard in a flight deck (such as eVTOLs), the sticks can directly control the vehicle's **Autopilot 1x**.




Some examples are:

- To directly connect a stick via **PPM**, **RS** or **CAN** to the autopilot.
- To use a Veronte Stick that converts USB to PPM, allowing connection between USB sticks and the autopilot.
- Connect a **USB stick** to a **PC** which establishes communication with the autopilot.

Virtual Stick

The Virtual stick feature allows to integrate as a stick controller any device that can interface with **Autopilot 1x** (RS232, RS485, ADC, CAN...) and can provide control reference values.

While the configuration is slightly more complex, this feature allows using a wide variety of devices as flight control interfaces.



Multiple Drones/GCS - Redundancy


Due to Veronte's modular configuration, it is possible to integrate several onboard and ground units within the same network.

(i) Note

Users are free to combine the different multiple drones solutions with the multiple GCS solutions.


Multiple Drones - Point to Point

Standard multiplatorm setup.




Multiple Drones - Point to Multipoint

Managing several platforms with a single radiolink.



Multiple GCS

For long range operations with several LOS stations.




For remote solutions with LOS backup operator, **Veronte Cloud** allows the connection between PCs.

To correctly establish communication between the different PCs via **Ethernet** the following steps should be carried out:


- 1. Make the **physical connection** with ethernet cables, the two different types of ethernet cables can be used:
 - Straight-Throught
 Connect each PC to an ethernet switch with its Straight-Through ethernet cable (i.e. users will need 2 cables).
 - Crossover

Connect the PCs directly to each other with a crossover ethernet cable.




Straight-Through vs Crossover cables

- 2. On each PC, change the ethernet adapter settings to a static IP so that both are on the same subnet. To do this:
 - In the **Control Panel**, go to **Network and Internet**.
 - Open Network and Sharing Centre menu and click Change adapter settings.




Ethernet connection 1

Select Local Area Connection, right click, and select Properties.



Ethernet connection 2

Select IPv4 and click Properties.




Ethernet connection 3

 Set IP address to a static IP (e.g. 192.168.0.100) and Subnet mask to 255.255.255.0. Click OK.


Important

If on this PC the IP address is set to 192.168.0.100, on the other PCs, the IP address must be set to **192.168.0.XXX** (e.g. 192.168.8.234), so that they are on the same subnet.



Ethernet connection 4

- 3. Allow **VeronteLink** to go through the Firewall on the PC that will run it, hereafter PC primary. To do so:
 - In the Control Panel, go to System and Security.




Windows Firewall 1

 Open Windows Defender Firewall and click on Allow an app through Windows Defender Firewall.



Windows Firewall 2

• Check that **Veronte Link** app is **allowed**.



Windows Firewall 3


4. On the PC secondary, in **Veronte Ops** change the **Veronte Link Host** option setting to the **IP of the PC primary**. To do this:

- Open Veronte Ops.
- In the Status bar, click the arrow on the right of the bar to display a drop-down menu.




Veronte Ops - Status bar

• In it, open the **Setup** menu.



Veronte Ops - Setup menu

- Next, go to the Veronte Link Host settings.
- Change the IP localhost to the IP of the PC primary.



Veronte Ops - Veronte Link Host settings

For more information on this settings, refer to the Setup - Veronte Ops configuration section of the **Veronte Ops** user manual

5. Finally, Autopilot 1x connected to the PC primary should be seen in the Veronte Ops open on this PC, as well as on the PC secondary.
If users have any problems when trying to connect Veronte Ops to Veronte Link, refer to the Connecting to Veronte Link - Troubleshooting section of the Veronte Ops user manual.

If after following the steps described above users are not able to operate in this way, please contact support team by opening a **Ticket** in your Joint Collaboration Framework.

Preparation for operation

Here the user will find different checklists that the Embention team considers useful to follow as a guideline before performing an operation.

! Important

This is only an **example**, it may vary depending on the operation to be performed and the user's platform.

- 1. Hardware revision
- 2. Software revision
- Functional system test
- 4. Equipment checklist

- 5. Revision and checks pre-flight
- 6. Post-flight revision

Maintenance

Preventive maintenance

Apart from cleaning, no extra maintenance is required to guarantee the correct operation of the **Veronte Autopilot 1x**.

In order to clean **Veronte Autopilot 1x** properly follow the next recommendations.

- Turn off the device before cleaning.
- Use a clean, soft, damp cloth to clean the unit.
- Do not immerse the unit in water to clean it.

Software update

To update the software, an additional app is required: Veronte Updater.


(i) Note

The file with the new software version will be shared with the customer in the **Joint Collaboration Framework** when it is requested.

For more information about the **Joint Collaboration Framework**, read its user manual.

Compatible Devices

Actuators/Servos



| Company | Comments |
|---------------------|--------------|
| | and |
| | redundant. |
| | To know |
| | how to |
| | integrate it |
| | with |
| | Veronte |
| | Autopilot |
| | 1x, read |
| | the |
| | Pegasus |
| | PA-R-135-4 |
| | integration |
| | example |
| | (CAN) or |
| | the |
| | Pegasus |
| | PA-R-135-4 |
| | integration |
| | example |
| | (Serial) |
| | I/O: PWM |
| | and CAN- |
| | BUS |
| | Type: |
| . • • | linear |
| I II TO AN ACTION I | actuator |
| ULTRAMOTION | and servo |
| | To know |
| | how to |
| | integrate it |
| | with |
| | Veronte |

| Company | Comments |
|-------------------------|---|
| | Autopilot 1x, read the Ultra Motion integration example |
| KST BOUND DIGITAL SERVO | I/O: PWM, RS232, RS485 and CAN-BUS |
| SAVÖX | I/O: PWM, RS232, RS485 and CAN-BUS |

Other companies





ADS-B

| Company | Comments |
|---------|-------------|
| | Products: |
| | Ping20S |
| | (ADS-B Out) |

Company Comments uAvioni K Ping1090 (ADS-B IN/ OUT) AII products of the Sagetech following families: MX XΡ **Autopilot** 1x includes an internal ADS-B transceiver. To know how to configure it, read the MBENTION Transponder/ ADS-B -**Devices** section of the 1x PDI **Builder** user manual.

| Company | Comments |
|----------------------|----------|
| APPLIED INTELLIGENCE | |

Air Data Sensors

| Company | Comments |
|-------------------------|--|
| EMBENTION | High Speed Pitot Sensor, read the High Speed Pitot Sensor integration example to know how to integrate it with |
| | Veronte Autopilot 1x. |
| MGL _{AVIONICS} | OAT 428: For detailed information on its integration with Veronte Autopilot |

| Company | Comments |
|---------------------------------------|---|
| | 1x, refer to OAT sensor 428 integration example |
| swiss-airdata www.swiss-airdata.com | |
| AEROPROBE Revolutionary Technology | |

Altimeters

| Company | Comments |
|----------|--|
| /instein | I/O: UD-1 (CAN-bus) To know how to integrate it with Veronte Autopilot 1x, read the Ainstein CAN Radar integration example |
| HEXAGON | I/O: CAN- bus |

| Company | Comments |
|----------------------------|--|
| Ilightware optoelectronics | I/O: I2C and CAN- bus Product: LW20, SF11, SF20 To know how to integrate them with Veronte Autopilot 1x, read the Lightware LW20 Lidar and Lightware SF20 Lidar integration examples |
| GARMIN® | I/O: PWM Product: LIDAR-Lite v3 To know how to integrate it with Veronte Autopilot 1x, read the Lidar |

| Company | Comments |
|---------|----------------------------------|
| | Garmin Lite v3 integration |
| | example |

Cameras

| Company | Comments |
|--|---|
| ○ OCTOPUS | |
| (a) merio | |
| ALJO COMPANIES C | |
| Next Vision | |
| WASOAL SAN | Autopilot 1x reads identified objects by their cameras. |

Control stations

| Company | Comments |
|-----------|-----------|
| | Products: |
| EMBENTION | LCS |
| | PCS |
| | |

Datalinks

BLOS Communications

| Company | Comments |
|---------|----------|
| SKYTRAC | |

| Company | Comments | | |
|-------------------|--|--|--|
| | Broadband UAV Satcom: IMS-350 Midband UAV Datalink and GPS System: DLS-100 | | |
| Ground Control | Satellite Communications: RockBLOCK | | |
| satlink | | | |
| ATMOSPHERE | Requires Veronte COM | | |

LOS Communications

| Company | Comments | | |
|-------------|---|--|--|
| | Antenna: Tracking Systems T28 | | |
| ₹ EMBENTION | Radio module: SDL, read the Veronte SDL integration example to know how to integrate it with Veronte Autopilot 1x XDL | | |
| Management | I/O: RS232 communication tunnel Microhard radio: pDDL900-ENC, read the Microhard integration example to know how to integrate it with Veronte Autopilot 1x | | |
| סדכ | I/O: RS232 communication tunnel DTC radio: SOL8SDR-C, read the DTC integration example to know | | |

| Company | Comments | | |
|------------------------|--|--|--|
| | how to integrate it with Veronte Autopilot 1x | | |
| STLYUS TECHNOLOGIES | I/O: RS232 communication tunnel Streamcaster radio: 4200E, read the Silvus integration example to know how to use it with Veronte Autopilot 1x | | |
| DIGI | Radio: To know how to configure Digi radios, read its user guide and read the Digi integration example to know how to integrate it with Veronte Autopilot 1x | | |

Engines





Jet Engines









Expansion modules

| Company | Comments |
|-----------|--------------|
| | Products: |
| | CEX, read |
| | the CEX |
| | connection |
| | integration |
| | example to |
| | know how |
| | to integrate |
| | it with |
| | Veronte |
| | Autopilot |
| EMBENTION | 1x. |
| EMBENTION | |
| | MEX, read |
| | the MEX |
| | connection |
| | integration |
| | example to |
| | know how |
| | to integrate |
| | it with |
| | Veronte |
| | Autopilot |
| | 1x. |


GNSS Receivers

| Company | Comments |
|---------|-----------------------|
| | GNSS, read the NexNav |





IMUs & Compass



Comments Company **Magnetometer:** MEX To know how to integrate it with EMBENTION Veronte Autopilot 1x, read the MEX integration example **Magnetometer:** HMR2300-232 To know how to integrate it with Honeywell Veronte Autopilot 1x, read the Sensing and Control Magnetometer Honeywell HMR2300 integration example **Magnetometer:** RM3100-CB To know how to integrate it with Veronte Autopilot 1x, read the PNI RM3100 integration example

Motor controllers / ESC

| Veronte products MC110, read the MC110 connection | 5: |
|---|----------|
| MC110, read the MC110 | |
| read the MC110 | |
| MC110 | <u>,</u> |
| | |
| connection | |
| | n |
| integratio | n |
| example t | to |
| know how | N |
| to integra | te |
| it with | |
| Veronte | |
| Autopilo | t |
| 1x. | |
| | |
| EMBENTION MC24, rea | |
| the MC24 | 4 |
| connection | n |
| integratio | n |
| example t | to |
| know how | N |
| to integra | te |
| it with | |
| Veronte | |
| Autopilo | t |
| 1x. | |
| MC01, rea | ٠. م |
| the MCO1, real | |
| | |
| connectio | |
| integratio | 0[] |

| Company | Comments |
|------------------------------|------------------|
| | example to |
| | know how |
| | to integrate |
| | it with |
| | Veronte |
| | Autopilot |
| | 1x. |
| THE SAFEST PROPULSION SYSTEM | I/O: PWM |
| Currawong | I/O: CAN- bus |

| Other Companies | Comments |
|---|--|
| Hacker Brushless Motors Industrial Solutions | |
| C KDE Direct | I/O: PWM, RS232, RS485, and CAN-bus |
| AXi | |

Power management units

| Company | Comments |
|------------------|------------------|
| | Veronte product: |
| EMBENTION | R12S |
| | |
| | |

| Company | Comments |
|-----------------------|----------|
| | R12F |
| | R24F |
| VISION AIR TRONICS | |


Transmitters

| Company | Comments | | |
|------------|--|--|--|
| Futaba | Products: 8J/10J/12K/14SG with 8 channels 12K/14SG with 12 channels T18SZ with 8 channels | | |
| (EMBENTION | Stick | | |


Integration examples

Wiring connection


• Point to point



• Daisy chain




• Backbone with stubs



RS232

Point to point

This connection is recommended to establish with the computer while $\mathbf{1x}$ is commanding via CAN to Veronte MC110 or Veronte MC24, since the USB connection between the PC and the $\mathbf{1x}$ may be lost.



RS-232 connection


(i) Note

Transmitter pin (TX) of one device is connected to the receiver pin (RX) of the other one, and vice versa.

RS485/422

Point to point

This connection is recommended to establish with the computer while **1x** is commanding via CAN to Veronte MC110 or Veronte MC24, since the USB connection between the PC and the **1x** may be lost.



RS-485 connection

(i) Note

Output pin (OUT) of one device is connected to the input pin (IN) of the other one.

Inverted signals (N) are connected each other; in the same way non-inverted signals (P) are linked each other.

Daisy chain


This section details the technical considerations that must be taken into account when connecting the Autopilot 1x to a chain of devices via RS485/422.

Full duplex

Autopilot 1x includes an internal resistor of 120 Ω . A second resistor is required at the end of the line (again 120 Ω) to allow the connection of multiple devices to the same line. This resistor may be placed on cable or PCB.

Full Duplex allows devices on an RS485 network to transmit and receive data **simultaneously**, enabling continuous bidirectional communication. This mode uses **four wires**, two for sending and two for receiving, which facilitates faster and more efficient data transfer.


The following diagram shows how to connect the devices:




Half duplex

Half Duplex allows devices on an RS485 network to transmit and receive data, but **not at the same time**. In this mode, communication alternates between sending and receiving, using only **two wires** for both directions.

The following diagram shows how to connect the devices:






CAN


Electrical diagram of CAN bus

Autopilot 1x includes an internal resistor of 120 Ω . A second resistor is required at the end of the line (again 120 Ω) to allow the connection of multiple CAN Bus devices to the same line. This resistor may be placed on cable or PCB.



CAN assembly example diagram

Point to point



CAN connection

(i) Note


The user has the option to configure either of the two available CAN BUS lines on the Autopilot 1x: **CAN A** or **CAN B**.

The following sections detail the technical considerations to be taken into account when connecting the Autopilot 1x to a chain of devices via CAN.

Daisy chain

The daisy chain connection is the most common and recommended method for interconnecting multiple devices in a CAN system. This procedure involves sequentially connecting the CAN cable from one device to the next, ensuring that the total cable length is minimized to optimize network performance and reduce potential interference.

The following diagram illustrates an example of how to connect devices using this method:





! Important

A resistor has been included in the diagram, which allows the connection of more devices, as explained in the Electrical diagram of CAN bus section.

(i) Note

The standard designation for CAN lines in devices is typically CAN H (High) and CAN L (Low). These designations correspond to those of the Autopilot 1x, where **CAN P (Positive)** and **CAN N (Negative)** represent the **High** and **Low** lines, respectively.

(i) Note


The user has the option to configure either of the two available CAN BUS lines on the Autopilot 1x: CAN A or CAN B.

Backbone with stubs

Another method for connecting devices via CAN is to use a master cable from which the necessary stubs will be made to connect the devices. This connection method allows the creation of stubs from the master cable to integrate each device into the CAN network.

It is important for the user to note that when connecting devices in this topology, the total length of the CAN BUS cable is limited. Exceeding this length may adversaly affect network performance and communication integrity.


The following diagram illustrates an example of how to connect devices using this method:



! Important

To create stub branches from the master line, **T-connectors** or **CAN splitter** are required.

These connectors enable the connection of a device while allowing the main BUS line to continue, facilitating the connection of additional devices.



The CAN protocol specifications limit the distance a device can be placed from the BUS. The following table shows the distance limitations to be considered when setting up the system.

| Bus | Bus | Stub | Node |
|-----------|--------|--------|------------|
| Speed | Length | Length | Distance |
| 1 Mbit/ | 40 | 0.3 | 40 meters |
| Sec | meters | meters | |
| 500 | 100 | 0.3 | 100 meters |
| kbits/Sec | meters | meters | |
| 100 | 500 | 0.3 | 500 meters |
| kbits/Sec | meters | meters | |

| Bus | Bus | Stub | Node |
|-----------|--------|--------|----------|
| Speed | Length | Length | Distance |
| 50 kbits/ | 1000 | 0.3 | 1000 |
| Sec | meters | meters | meters |

△ Warning


If a cable stub (un-terminated cable) or a T-connector is used to connect to the bus line, then the stub distance should not exceed **0.3 meters**.

Serial to Ethernet Converter

This section provides the process to follow to integrate a **Serial to Ethernet Converter**, with **Veronte Autopilot 1x**. In this example, **WIZ108SR** and **WIZ107SR** converters are used.

These protocol converters transmit the data sent by serial equipment as UDP data type, and converts back the UDP data received through the network into serial data to transmit back to the equipment.


• WIZ107SR connection diagram:



WIZ107SR - Autopilot 1x wiring diagram

Important

To ensure correct operation of the device, use an **external power supply** and **not to connect** it to the **3.3** line of **Autopilot 1**x. Please note that it **shares signal ground** with **Autopilot 1**x.




Autopilot 1x harness pinout

| Autopilot 1x Harness | | WIZ107SR Connector | | |
|----------------------|--------------|-----------------------|------------|--------|
| PIN | Signal | Color Code | PIN | Signal |
| 19 | RS 232 TX | White- Pink | 3 | RXD |
| 20 | RS 232 RX | Pink- Brown | 7 | TXD |
| 21 | GND | White- Blue | 11 / 12 | GND |

Marning

Remember!! In **Autopilot 1x**, all GND pins are common. Note that pin 54 is not a common GND pin.


• WIZ108SR connection diagram:



WIZ108SR - Autopilot 1x wiring diagram

! Important

To ensure correct operation of the device, use an **external power supply** and **not to connect** it to the **3.3** line of **Autopilot 1x**. Please note that it **shares signal ground** with **Autopilot 1x**.



Autopilot 1x harness pinout

| Autopilot 1x Harness | | | WIZ108SR Connector | |
|----------------------|-------------|----------------|-----------------------|-----------|
| PIN | Signal | Color Code | PIN | Signal |
| 50 | OUT_RS485_P | Pink- Brown | 3 | 485+_RXD+ |
| 51 | OUT_RS485_N | White- Blue | 5 | 485RXD- |
| 53 | IN_RS485_P | White- Red | 7 | TXD+ |
| 52 | IN_RS485_N | Brown- Blue | 9 | TXD- |
| 54 | OUT_GND | Brown- Red | 11 / 12 | GND |

△ Warning

Note that this pin 54 is not a common GND pin.

(i) Note


This integration is done for the **WIZ108SR**, this is for a connection via **RS485** with **Autopilot 1x**. However, the process for the **WIZ107SR** device is almost the same.

Once the hardware installation is complete, follow the steps below to properly configure the connection and ensure stable communication between the devices.

Ethernet Connection in Windows


First, make sure computer is set to static IP address on same subnet as radio. The following substeps clarify how to set the IP address:

- 1. Connect the Ethernet cable of the WIZNet adapter, powered by 3.3V, to the Ethernet port of the PC.
- Open Network and Sharing Centre menu and click Change adapter settings.




Ethernet connection 1

3. Select **Local Area Connection**, right click, and select **Properties**.




Ethernet connection 2

4. Select IPv4 and click Properties.



Ethernet connection 3


5. Set **IP address** to 192.168.11.X (in this example 192.168.11.8 is entered) and **Subnet mask** to 255.255.255.0. Click **OK**.



Ethernet connection 4


WIZNet software configuration

6. Open the **WIZNet Software** and select the Ethernet port with the IP assigned before in the dropdown menu.



WIZnet software - Ethernet port selected

7. Click on the **Device Search** option to **scan** for the device.



WIZnet software - Scan for device

8. Then, if the module is properly connected to the network, it will appear in the search list. Select the **WIZ108SR** device to access its configuration.


△ Caution

If the module does not appear in the list and it has been previously connected to another PC, **reboot** the module (simply unpower it and power it up again).

This is because when the **WIZ108SR** module establishes a connection to a PC's MAC address, it will only communicate with that PC unless it is rebooted.


The configuration must be as follows:

- In the Basic Settings tab, make sure that the Network Settings parameters are:
 - Local IP: 192.168.11.2
 - Subnet Mask: 255.255.255.0
 - Gateway: 192.168.11.1
- In the **Channel #0** tab:
 - Change the Operation mode to UDP.
 - Set the Local port to 5001 (for example).
 - Set the Remote host to the adapter IP previously configured in step 5 and a Remote Port, in this example port 5002 has been chosen.
 - The Serial options must match those of the **Autopilot 1x**, so set them as follows:
 - Baud rate: 115200
 - Data bit: 8
 - Parity: NONE
 - Stop bit: 1
 - Modify in the Serial data packing condition the size to 255 to send the data in 255 byte packets, so that each send will have more data.



WIZnet software - Device configuration

9. Finally, click **Apply Settings** to save the configuration to the device.



WIZnet software - Apply Settings


Veronte Link configuration

10. Add a new UDP connection in Veronte Link and configure it with the same IP address and port as previously set in the Remote options of the WIZNet settings.

In this example:

• Address: 192.168.11.1

Port: 5002



Veronte Link - Connection settings

For more information on Veronte Link connections, please refer to the UDP connection - Integration examples section of the **Veronte Link** user manual.

1x PDI Builder configuration


11. Go to Input/Output menu \rightarrow **I/O Setup panel**.

Bidirectionally connect the RS485 Producer to a Commgr port

Consumer, in this example it has been linked to Commgr port 3. Then, the same **Commgr port Producer**, in this case Commgr port 3, should be automatically connected to the **RS485 Consumer**:

(i) Note

If the **WIZ107SR** module is used, i.e. a connection is established via **RS232**, bidirectionally connect the **RS232** port to a **Commgr port** and not the RS485 port.



1x PDI Builder - I/O Setup configuration

12. Go to Input/Output menu \rightarrow Serial panel \rightarrow **RS485 tab**.

(i) Note

If using the **WIZ107SR** module, check the **RS232** parameters instead.

Make sure that these parameters are the same as the parameter values previously set in the **WIZNet** software.


• Baudrate: **115200**

Length: 8Stop: 1

Parity: **Disabled**

1x PDI Builder - Serial configuration

Following these steps, **Autopilot 1x** should appear in Veronte Link as follows:



Autopilot 1x connection via UDP

External devices

The step-by-step instructions for the following external devices will be explained in detail in the following sections:


- Connection Examples
- Actuators/Servos
- Air Data Sensors
- Altimeters
- Datalinks
- GNSS Receivers
- IMUs & Compass
- RPM Sensors
- Stick
- Veronte products

GPIO Wiring for External Loads

Besides their use in communication buses, the I/O pins are frequently used as GPIOs to control external devices like relays, lights, or solenoids.

It is important to note that each **I/O pin** has a **maximum current output** of **1.65 mA**, as they are designed for data signals, not for directly powering devices.


Due to this current limitation, an intermediate circuit is required to handle higher-power loads. The solution recommended is to use an N-type MOSFET as an electronic switch. The following diagram shows the recommended circuit for driving a relay:




Circuit for driving a Relay

Connection Examples


Ground Stations




Basic Autopilot 1x Ground Station



Autopilot 1x PCS Ground Station



Autopilot 1x Tracker Ground Station




Autopilot 1x LCS Ground Station


⚠ Warning

Veronte Autopilot 1x equipment harnesses have specific pin layouts. Only use their own matting connectors, do NOT mix harnesses: misuse can lead to destruction.


Aircrafts




HIL Harness



Multicopter



Fixed Wing Airplane



Helicopter

Actuators/Servos

The user can configure any actuator compatible with the communication interfaces.

CAN


Pegasus PA-R-135-4




Pegasus PA-R-135-4 servo

Pegasus PA-R-135-4 micro-low-profile servo is currently the world's smallest professional servo-actuator of its class.


The setup to be performed by the user should be as follows:



Pegasus PA-R-135-4 - Autopilot 1x wiring diagram



Pegasus PA-R-135-4 Tyco MTA100 connector pinout



Autopilot 1x harness pinout

| Autopilot 1x Harness | | | R- Tyco | asus PA- 135-4 MTA100 nnector | |
|----------------------|--------|------------------|------------|--|--|
| PIN | Signal | Color Code | PIN | Signal | |
| 25 | CANA_P | White- Black | 3 | CANUL | |
| 28 | CANB_P | Yellow- Green | 3 | CANH | |
| 26 | CANA_N | Brown- Black | 1 | CANL | |
| 29 | CANB_N | Pink- Green | Τ | CAINL | |
| 30 | GND | Yellow- Pink | 6 | GND | |



CAN A and CAN B buses are equivalent and can be used interchangeably for the integration of this device.

For more information on CAN connection, please visit CAN - Wiring connection section of this manual.

△ Warning

Remember!! In **Autopilot 1x**, all GND pins are common. Note that pin 54 is not a common GND pin.

Once the hardware integration of the device has been completed, it will be necessary to proceed with the **software integration**. To do this, follow the steps detailed in the Pegasus - Integration examples section of the **1x PDI Builder** user manual.

Ultra Motion




Ultra Motion servo


Ultra Motion servo is a high-precision actuator designed for demanding applications, with BLDC electronic control and non-contact absolute position feedback.

This device can be integrated with **Autopilot 1x** via **CAN 2.0B protocol** to ensure robust and efficient communication in the system.


The setup to be performed by the user should be as follows:



Ultra Motion - Autopilot 1x wiring diagram



Ultra Motion - Pinouts for Signal connector on AM series actuators



Autopilot 1x harness pinout

| Autopilot 1x Harness | | | Ultra | Motion Connect | |
|----------------------|--------|------------------|-------|-------------------|---------------|
| PIN | Signal | Color Code | PIN | Signal | Color Code |
| 25 | CANA_P | White- Black | 7 | | Red |
| 28 | CANB_P | Yellow- Green | , | CAN_H | |
| 26 | CANA_N | Brown- Black | 9 | CAN L | White |
| 29 | CANB_N | Pink- Green | 9 | CAN_L | wille |
| 30 | GND | Yellow- Pink | 8 | GND | Black |

(i) Note

CAN A and CAN B buses are equivalent and can be used interchangeably for the integration of this device.

For more information on CAN connection, please visit CAN - Wiring connection section of this manual.

⚠ Warning


Remember!! In **Autopilot 1x**, all GND pins are common. Note that pin 54 is not a common GND pin.

Once the hardware installation has been completed, the user can find the explanataion for the software installation in the Ultra Motion - Integration examples section of the **1x PDI Builder** user manual.

PWM

This section details the process of integrating a **PWM servomotor** with **Autopilot 1x**.

The connection diagram between the two devices should look like this:




PWM - Autopilot 1x wiring diagram

! Important

Note that this servo must be connected to an **external power supply**, **sharing signal ground** with **Autopilot 1**x.

The **PWM servo** must be connected to one of the available I/O pins of **Autopilot 1**x.



Autopilot 1x harness pinout

| _ | Autopilot 1x Harness | | | | |
|-----|----------------------|--------------|--|--|--|
| PIN | Signal | Color Code | | | |
| 1 | 1/00 | White | | | |
| 2 | I/O1 | Brown | | | |
| 3 | 1/02 | Green | | | |
| 4 | 1/03 | Yellow | | | |
| 5 | 1/04 | Gray | | | |
| 6 | 1/05 | Pink | | | |
| 7 | 1/06 | Blue | | | |
| 8 | 1/07 | Red | | | |
| 9 | GND | Black | | | |
| 10 | 1/08 | Violet | | | |
| 11 | 1/09 | Gray-Pink | | | |
| 12 | I/O10 | Red-Blue | | | |
| 13 | I/O11 | White-Green | | | |
| 14 | I/O12 | Brown-Green | | | |
| 15 | I/O13 | White-Yellow | | | |
| 16 | I/O14 | Yellow-Brown | | | |
| 17 | I/O15 | White-Gray | | | |

△ Warning

Remember!! In **Autopilot 1x**, all GND pins are common. Note that pin 54 is not a common GND pin.

Once the hardware connection is made, it is necessary to **configure** the **I/O** pin used. Since these **I/O** pins are **preconfigured** as **GPIO**, they must be set as **PWM**.

To do so, refer to and follow the steps described in the PWM - Integration examples section of the **1x PDI Builder** user manual.

Serial


Pegasus PA-R-135-4




Pegasus PA-R-135-4 servo

Pegasus PA-R-135-4 micro-low-profile servo is currently the world's smallest professional servo-actuator of its class.


The setup to be performed by the user should be as follows:



Pegasus PA-R-135-4 - Autopilot 1x wiring diagram



Pegasus PA-R-135-4 Tyco MTA100 connector pinout



Autopilot 1x harness pinout

| A | utopilot 1x Har | R- Tyco | asus PA- 135-4 MTA100 nnector | | |
|-----|-----------------|----------------|--|--------|--|
| PIN | N Signal Code | | PIN | Signal | |
| 50 | OUT_RS485_P | Pink- Brown | 3 | SINGAL | |
| 53 | IN_RS485_P | White- Red | 3 | А | |
| 51 | OUT_RS485_N | White- Blue | 1 | SIGNAL | |
| 52 | IN_RS485_N | Brown- Blue | T | В | |
| 54 | OUT_GND | Brown- Red | 6 | GND | |


Once the hardware integration of the device has been completed, it will be necessary to proceed with the **software integration**. To do this, follow the steps detailed in the Pegasus - Integration examples section of the **1x PDI Builder** user manual.

Volz DA26 - RS485



Volz DA26

The following wiring connection is recommended for a **RS485 half-duplex** connection between **Volz DA26** servos and **Veronte Autopilot 1x**:





Volz DA26 - Autopilot 1x wiring connection

The above diagram is made for the case where 2 **Volz DA26** servos are connected, however, the connection is the same in case the user wants to connect only one or as many servos as the bus allows.


Important

Note that this servo must be connected to an **external power supply**, **sharing signal ground** with **Autopilot 1**x.





6 7 8 9 Volz DA26 connector pinout



Autopilot 1x harness pinout

| A | utopilot 1x Har | | lz DA26 nnector | |
|-----|-----------------|----------------|--------------------|--------------------------------|
| PIN | Signal | Color Code | | Signal |
| 50 | OUT_RS485_P | Pink- Brown | _ | RS 485 A (Non- |
| 53 | IN_RS485_P | White- Red | 1 | inverting Input/ Output) |

| A | utopilot 1x Har | Volz DA26 Connector | | | |
|-----|-----------------|------------------------|-----|------------------------|--|
| PIN | Signal | Color Code | PIN | Signal | |
| 51 | OUT_RS485_N | White- Blue | 2 | RS 485 B (Inverting | |
| 52 | IN_RS485_N | Brown- Blue | 2 | Input/ Output) | |
| 5.4 | OUT CND | Brown- | 7 | GND (1) | |
| 54 | OUT_GND | Red | 8 | GND (2) | |

⚠ Warning

Note that this pin 54 is not a common GND pin.

(i) Note

If users encounter any problems during wiring, please check the Halfduplex servo does not respond - Troubleshooting section of this manual.

Once the hardware integration of the device has been completed, it will be necessary to proceed with the **software integration**. To do this, follow the steps detailed in the Volz DA26-RS485 - Integration examples section of the **1x PDI Builder** user manual.

Air Data Sensors

High Speed Pitot Sensor



High Speed Pitot Sensor

This section explains how to install the **High Speed Pitot Sensor** with an **Autopilot 1x** and configure it, so **1x** measures the air speed from the electrical signals of **High Speed Pitot Sensor**.

Required Material


- Veronte Autopilot 1x with hardware version 4.8.
- High Speed Pitot Sensor.
- Veronte Harness CS for 1x v4.8 with Embention reference P001114.
- Power supply for 1x (6.5 36 V DC).
- Power supply for **High Speed Pitot Sensor** (5 V DC).
- Pneumatic tubing, with 3 mm of outer diameter and 1 mm of inner. Silicone material is recommended.
- Two T-connectors for the tubing.

Marning


Take caution when connecting the pressure ports. This sensor only measures a positive pressure differential, so the sensor might be damaged if it reverse connected.

Ensure that the upper port is always at an equal or higher pressure than the lower port.

Connect the pneumatic tubes and wires according to the following diagrams:




High Speed Pitot Sensor - Autopilot 1x connections diagram



High Speed Pitot Sensor - Autopilot 1x connections diagram

The analog pin defines which analog variable is used for configuration.



Autopilot 1x harness pinout

| Autopilot 1x Harness | | | | Speed Sensor |
|----------------------|-------------|-----------------|--------|-----------------|
| PIN | Signal Code | | Signal | Color Code |
| 38 | ANALOG_0 | Red | | |
| 39 | ANALOG_1 | Black | | |
| 40 | ANALOG_2 | Pink | DATA | VA/I- i+ - |
| 22 | ANALOG_3 | Brown - Blue | DATA | White |
| 23 | ANALOG_4 | White - Red | | |
| 37 | GND | Blue | GND | Black |

⚠ Warning

Remember!! In **Autopilot 1x**, all GND pins are common. Note that pin 54 is not a common GND pin.

Once the **High Speed Pitot Sensor** is connected, air speed measurements can be monitored with **1x PDI Builder** using the variables ADC0 to ADC4. The integration of this device with **Autopilot 1x** as far as the software is concerned is explained in the High Speed Pitot Sensor - Integration examples section of **1x PDI Builder** user manual.


OAT sensor 428 of MGL Avionics




OAT sensor 428

The **OAT sensor 428** of MGL Avionics is an analogical temperature sensor that measures temperatures from -55°C to 150°C. It changes the voltage according to the temperature measured and therefore the connection to the autopilot is performed using the ADC pins.

The following resistors and wiring are necessary to connect an **OAT sensor 428** to the **Autopilot 1**x:



OAT sensor - Autopilot 1x wiring diagram



Autopilot 1x harness pinout

| Autopilot 1x Harness | | | | | |
|----------------------|----------|--------------|--|--|--|
| PIN | Signal | Color Code | | | |
| 36 | 5V | Pink | | | |
| 37 | GND | Blue | | | |
| 38 | ANALOG_0 | Red | | | |
| 39 | ANALOG_1 | Black | | | |
| 40 | ANALOG_2 | Pink | | | |
| 22 | ANALOG_3 | Brown - Blue | | | |
| 23 | ANALOG_4 | White - Red | | | |

⚠ Warning

Remember!! In **Autopilot 1x**, all GND pins are common. Note that pin 54 is not a common GND pin.

Once connected the **OAT sensor**, the temperature can be monitored with **1x PDI Builder** using the variables ADC0 to ADC4.

The integration of this device with **Autopilot 1x** is explained in the OAT Sensor - Integration examples section of the **1x PDI Builder** user manual.

Altimeters

Lidar


The integration between **Veronte Autopilot 1x** and a lidar is performed using a variety of interfaces depending on the lidar device. The most common interfaces are I2C or analog although serial or CAN bus can also be used if the lidar is compatible.

Lidar Garmin Lite v3



Lidar Garmin Lite v3

Lidar Garmin Lite v3 sensor integrates with **Autopilot 1x** via **I2C** connection.




Lidar Garmin Lite v3 - Autopilot 1x wiring diagram


Important

To ensure correct operation of the device, it is recommended to use an **external power supply** and **not to connect** it to the **3.3-5 V** lines of **Autopilot 1x**.

Please note that it **shares signal ground** with **Autopilot 1x**.



Lidar Garmin Lite v3 connector



Autopilot 1x harness pinout

| Autopilot 1x Harness | | Lidar Garmin L v3 Connecto | | | |
|----------------------|----------|-------------------------------|-----|---------------|---------------|
| PIN | Signal | Color Code | PIN | Signal | Color Code |
| 31 | I2C_CLK | White | 4 | I2C SCL | Green |
| 32 | I2C_DATA | Brown | 5 | I2C SDA | Blue |
| 35 | GND | Gray | 6 | Ground (-) | Black |

△ Warning

Remember!! In **Autopilot 1x**, all GND pins are common. Note that pin 54 is not a common GND pin.


Once the lidar is connected, the user must proceed to its software integration with **Veronte Autopilot 1x** by referring to the Lidar Garmin Lite v3 - Integration examples section of the **1x PDI Builder** user manual.

Lightware LW20 Lidar



Lightware LW20 Lidar

Lightware LW20 Lidar sensor integrates with **Autopilot 1x** via **I2C** connection.




Lightware LW20 Lidar - Autopilot 1x wiring diagram

! Important

To ensure correct operation of the device, it is recommended to use an **external power supply** and **not to connect** it to the **3.3-5 V** lines of **Autopilot 1x**.

Please note that it **shares signal ground** with **Autopilot 1**x.



Embention Sistemas Inteligentes, S.A.

| Autopilot 1x Harness | | Lightware LW20 Lidar | | | |
|----------------------|----------|-------------------------|-----|--------|---------------|
| PIN | Signal | Color Code | PIN | Signal | Color Code |
| 31 | I2C_CLK | White | 2 | SCL | White |
| 32 | I2C_DATA | Brown | 1 | SDA | Yellow |
| 35 | GND | Gray | 8 | GND | Black |

⚠ Warning

Remember!! In **Autopilot 1x**, all GND pins are common. Note that pin 54 is not a common GND pin.


Once **Lightware LW20 Lidar** is connected, the user must proceed to its software installation with **Veronte Autopilot 1x** by referring to the **Lightware** LW20 Lidar - Integration examples section of the **1x PDI Builder** user manual.

Lightware SF20 Lidar



Lightware SF20 Lidar

Lightware SF20 Lidar sensor integrates with **Autopilot 1x** via **I2C** connection.




Lightware SF20 Lidar - Autopilot 1x wiring diagram

! Important

To ensure correct operation of the device, it is recommended to use an **external power supply** and **not to connect** it to the **3.3-5 V** lines of **Autopilot 1x**.

Please note that it **shares signal ground** with **Autopilot 1x**.



Autopilot 1x harness pinout

| Autopilot 1x Harness | | | Lig | jhtware s Lidar | 5F20 |
|----------------------|----------|---------------|-----|--------------------|---------------|
| PIN | Signal | Color Code | PIN | Signal | Color Code |
| 31 | I2C_CLK | White | 2 | SCL | White |
| 32 | I2C_DATA | Brown | 1 | SDA | Yellow |
| 35 | GND | Gray | 8 | GND | Black |

⚠ Warning

Remember!! In Autopilot 1x, all GND pins are common. Note that pin 54 is not a common GND pin.

Once **Lightware SF20 Lidar** is connected, the user must proceed to its software installation with **Veronte Autopilot 1x**. Since this setup is the same as for the Lightware LW20, please refer to the Lightware LW20 Lidar -Integration examples section of the 1x PDI Builder user manual.

Radar


Radar altimeters are common devices on aircrafts.

Ainstein CAN Radar



Ainstein CAN Radar

Ainstein CAN Radar sensor integrates with **Autopilot 1x** via **CAN** connection.




Ainstein CAN Radar - Autopilot 1x wiring diagram

Important

To ensure correct operation of the device, it is recommended to use an **external power supply** and **not to connect** it to the **5 V** line of **Autopilot 1x**.

Please note that it **shares signal ground** with **Autopilot 1**x.



Autopilot 1x harness pinout

| Autopilot 1x Harness | | Ainstein CAN Radar | | | | |
|----------------------|--------|--------------------|------------|---------|---------------|-------|
| PIN | Signal | Color Code | PIN Signal | | Color Code | |
| 25 | CANA_P | White- Black | 2 | CAN LII | Green | |
| 28 | CANB_P | Yellow- Green | 2 | CAN_HI | Green | |
| 26 | CANA_N | Brown- Black | 2 | 3 | CAN LOW | White |
| 29 | CANB_N | Pink- Green | 3 | CAN_LOW | wille | |
| 30 | GND | Yellow- Pink | 4 | Ground | Black | |

(i) Note

CAN A and CAN B buses are equivalent and can be used interchangeably for the integration of this device.

For more information on CAN connection, please visit CAN - Wiring connection section of this manual.

△ Warning

Remember!! In **Autopilot 1x**, all GND pins are common. Note that pin 54 is not a common GND pin.

Once **Ainstein CAN Radar** is connected, the user must proceed to its software installation with **Veronte Autopilot 1x** by referring to the Ainstein CAN Radar - Integration examples section of the **1x PDI Builder** user manual.

Datalinks

LOS

Amount of data sent via radiolink

Regardless of the radio used, the amount of telemetry data that can be sent by radiolink is limited.

Important

Refer to the Data Transmission section of the **1x Software Manual** for information on the amount of data that can be sent.

Digi radio (as internal radio)

Internal Digi radios can establish communication between Veronte Autopilots 1x.

The necessary configuration of Digi radios for proper communication between them and **1x** is described in the Digi internal radio - Integration examples section of the **1x PDI Builder** manual.

DTC (Domo Tactical) radio (SOL8SDR-C model)

System Layout

It is possible to operate DTC radios in two different ways, with or without amplifiers.

DTC

The following image shows the standard connection between **DTC** radios and **Autopilot 1x** for operation:



DTC radios and Autopilot 1x operation

• DTC + Amplifier

(i) Note

Amplifier information: **AMPD5W** model, 5W Linear RF Power Amplifier.

The following image shows the standard connection between **DTC** radios, amplifiers and **Autopilot 1x** for operation:




DTC + amplifier radios and 1x operation

Hardware Installation


Depending on the action to be taken, different hardware installations are possible:

1. To **configure a DTC radio** it is required to carry out the installation of the ethernet and power connection:



DTC D1804 Gecko breakout PCB

• Ethernet



RJ45 pinout T-568B

| J4 (Ethernet) - D1804 Gecko breakout PCB | | RJ45 Connector (T-568B) | | |
|--|-------------------|----------------------------|-----|------------------|
| PIN | Signal | PIN Signal | | Color Code |
| 1 | Ethernet MDIP0 | 1 | TX+ | Orange- White |
| 2 | Ethernet MDIN0 | 2 | TX- | Orange |
| 3 | Ethernet MDIP1 | 3 | RX+ | Green- White |
| 4 | Ethernet MDIN1 | 6 | RX- | Green |


Power supply



Female DC Power Jack connector

| J2 (PWR) - D1804 Gecko breakout PCB | | Power Connector |
|--|-----|--------------------|
| PIN Signal | | Signal |
| 1 | VIN | Power + |
| 2 | VIN | rowel + |
| 3 | GND | Power - |
| 4 | GND | rower - |


The full connection should look like this:



DTC connection - Configuration


2. To **configure a DTC + amplifier radio** it is required to carry out the installation of the ethernet, power and amplifier connection:





DTC D1806 Gecko active breakout PCB

• Ethernet



RJ45 pinout T-568B

| J4 (Ethernet) - D1806 Gecko Active Breakout PCB | | RJ45 Connector (T-568B) | | |
|--|-------------------|----------------------------|-----|------------------|
| PIN | Signal | PIN Signal | | Color Code |
| 1 | Ethernet MDIP0 | 1 | TX+ | Orange- White |
| 2 | Ethernet MDIN0 | 2 | TX- | Orange |
| 3 | Ethernet MDIP1 | 3 | RX+ | Green- White |

| J4 (Ethernet) - D1806 Gecko Active Breakout PCB | | RJ45 Connector (T-568B) | | |
|---|-------------------|----------------------------|--------|---------------|
| PIN | Signal | PIN | Signal | Color Code |
| 4 | Ethernet MDIN1 | 6 | RX- | Green |

Power supply



Female DC Power Jack connector

<

| J2 (PWR) Active E | Power Connector | |
|----------------------|--------------------|-----------------|
| PIN | Signal | Power Signal |
| 1 | VIN | Power + |
| 2 | VIN | |
| 3 | VIN | |
| 4 | VIN | |

| J2 (PWR) Active E | Power Connector | |
|----------------------|--------------------|-----------------|
| PIN | Signal | Power Signal |
| 5 | VIN | |
| 6 | VIN | |

| J9 (GND) Active E | Power Connector | | | |
|----------------------|--------------------|-----------------|--|--|
| PIN Signal | | Power Signal | | |
| 1 | GND | | | |
| 2 | GND | | | |
| 3 | 3 GND | | | |
| 4 | 4 GND | | | |
| 5 GND | | | | |
| 6 GND | | | | |

Amplifier




Amplifier AMPD5W

| J8 (AMP) - D1806 Gecko Active Breakout PCB | | | 1PD5W nnector |
|--|--------|----------------|------------------|
| PIN | Signal | Signal PIN Sig | |
| 1 | 5V_SDA | 6 | 5V_SDA |
| 2 | GND | 3 | GND |
| 4 | 5V_SCL | 5 | 5V_SCL |
| 7 | PA_TDD | 7 | PA_TDD |

| J2 (PWR) - D1806 Gecko Active Breakout PCB | | AMPD5W Connector | |
|--|------------|---------------------|---------|
| PIN | PIN Signal | | Signal |
| 1 | VIN | | |
| 2 | VIN | | |
| 3 | VIN | 1 & | |
| 4 | 4 VIN | | Power + |
| 5 | VIN | | |
| 6 | VIN | | |

| J9 (GND) - D1806 Gecko Active Breakout PCB | | AMPD5W Connector | |
|--|------------|---------------------|---------|
| PIN | PIN Signal | | Signal |
| 1 | GND | | |
| 2 | GND | | |
| 3 | 3 GND | | Power - |
| 4 | GND | 4 | rower - |
| 5 | GND | | |
| 6 | GND | | |


The full connection should look like this:




DTC + amplifier connection - Configuration

3. To **connect a DTC radio to a Veronte Autopilot 1**x the following installation must be carried out:


As, the connection of a **DTC** radio to a **Veronte Autopilot 1x** must be made via **RS-232**, the connection will be the same as in the configuration case (1), but adding the wiring to RS-232 port.






DTC D1804 Gecko breakout PCB - J3 (RS232)

This RS-232 should be connected to the RS-232 of **Autopilot 1x** harness.




J3 (RS232) pinout of female connector



Autopilot 1x harness pinout

| J3 (RS232) - D1804 Gecko Breakout PCB | | Autopilot 1x Harness | | |
|---|----------|----------------------|-------------|----------------|
| PIN Signal | | PIN | Signal | Color Code |
| 2 | RS232 RX | 19 | RS232 TX | White- Pink |
| 1 | RS232 TX | 20 | RS232 RX | Pink- Brown |
| 3 | GND | 21 | GND | White- Blue |


The full connection should look like this:



DTC connection - Veronte Autopilot 1x


4. To **connect a DTC + amplifier radio to a Veronte Autopilot 1x** the following installation must be carried out:

As, the connection of a **DTC** radio to a **Veronte Autopilot 1x** must be made via **RS-232**, the connection will be the same as in the configuration case (2), but adding the wiring to RS-232 port.




DTC D1806 Gecko active breakout PCB - J3 (RS232)

This RS-232 should be connected to the RS-232 of **Autopilot 1x** harness.




J3 (RS232) pinout of female connector



Autopilot 1x harness pinout

| J3 (RS232) - D1806 Gecko Active Breakout PCB | | Auto | pilot 1x I | Harness |
|---|----------|------|-------------|----------------|
| PIN | Signal | PIN | Signal | Color Code |
| 2 | RS232 RX | 19 | RS232 TX | White- Pink |
| 1 | RS232 TX | 20 | RS232 RX | Pink- Brown |
| 3 | GND | 21 | GND | White- Blue |

The full connection should look like this:



DTC + amplifier connection - Veronte Autopilot 1x


△ Caution

It is also possible to **calibrate** the **power output** of **DTC** radios and **DTC** + amplifier radios.

However, the radios are shipped with a factory calibration, it is **strongly** recommended to not modify this calibration. If the user wishes to modify it, please contact the support team (create a ticket in the customer's **Joint Collaboration Framework**; for more information, see Tickets section of the JCF manual).

DTC radio configuration


First steps




DTC ports

DTC without amplifier

- 1. Connect to 1 an SMP to SMA RF cable (this is the default transmit output).
- 2. Connect this SMA RF cable to a 2.4 GHz antenna.
- 3. Connect to 3 the **D1804 Gecko breakout PCB** supplied with the unit.
- 4. Connect J2 (PWR) of the D1804 PCB to 12V power.
- 5. In order to access the web browser control application, connect J4 (**ETHERNET**) of the **D1804 PCB** to a PC or network Ethernet port via CA2856 and D918.




- 6. Make sure computer is set to static IP address on same subnet as radio. The following substeps clarify how to set the IP address in the **Control Panel**:
 - 1. Open **Network and Sharing Centre** menu and click **Change** adapter settings.




Ethernet connection 1

2. Select **Local Area Connection**, right click, and select **Properties**.




Ethernet connection 2

3. Select IPv4 and click Properties.



Ethernet connection 3


4. Set **IP address** to 192.168.8.YY (e.g. if the IP of the radio is 192.168.8.95, set the IP 192.168.8.92) and **Subnet mask** to 255.255.255.0. Click **OK**.



Ethernet connection 4


- 7. First, it is necessary to have the '**Domo Node Finder**' software installed.
- Open **Domo Node Finder** and the connected radios will appear here as SOL8SDR.






Domo Node Finder - Default IP address

9. To configure the IP address, right-click the IP address and select Configure Network to disable the DHCP setting and set the following static IP address:



Domo Node Finder - IP address configuration

To confirm the change, click the icon to update the IP address.




Domo Node Finder - Configured IP address

(i) Note

This IP address, **192.168.8.95**, is related to the radio linked to the **ground unit**. For the radio linked to the **air unit**, the IP address should be **192.168.8.96**.

10. To open the DTC web browser control application, users can right-click the IP address and select WEB Interface (HTTP port 80), double-click on the IP address or enter the IP address of the SOL8SDR-C on the address bar of a web browser.




Domo Node Finder - Open Web Browser Application



Although the application should work with any web browser, **DTC** recommends the use of Internet Explorer, Google Chrome or Firefox.

11. An authentication required dialogue box will open. Leave the **Username blank** and enter the **Password** as **Eastwood**.



Domo Node Finder - Open Web Browser Application


12. Click **Login** and the web browser control application will open.

DTC with amplifier

- 1. Connect to 1 an SMP to SMA RF cable (this is the default transmit output).
- 2. Connect this **SMA RF cable** to the amplifier **RF IN port**.
- 3. Connect a 2.4 GHz antenna to the amplifier RF OUT port.
- 4. Connect to 3 the **D1806 Gecko active breakout PCB**.

5. Connect J4 (**ETHERNET**) of the **D1806 PCB** to a PC or network Ethernet port via CA2856 and D918.

- 6. Connect J2 (PWR) and J9 (GND) of the D1806 PCB to 12V power.
- 7. Connect J8 (**AMP**) of the **D1806 PCB** to the control cable from the amplifier connector.



8. Now the steps to follow are the same as from step 6. of a DTC without amplifier, described above.


Point-to-Point configuration

Basic radio configuration


Once the website has been accessed, follow the steps below which show the parameters that need to be modified for a correct operation and pairing of the radios.

(i) Note


This is an example of the radio configuration linked to a **ground** unit.



 Global Setup → General Settings: To easily identify each radio in a mesh, the user can rename the radio as desired:



General settings configuration




2. Presets.

Mesh Settings: Some of the parameters configured in this menu are always displayed at the top of the application.

△ Caution

It is recommended that software for all devices in a Mesh network should be at the same version to avoid potential compatibility issues.



Mesh settings configuration

- Operation mode: Select Single Mesh.
- Mesh ID: The Mesh ID must be the same on all units in the Mesh network. The Mesh ID tells the unit which network it belongs to, for example, all NETNodes on Mesh ID 1 will communicate with each other. The Mesh ID must be set to a non-zero value.
- Node Id: The node ID must be unique in the Mesh network for each device.

(i) Note

A node can automatically reassign its Node ID at power up if it finds a conflict with an existing node.

- **Operating range**: A larger range allows the Mesh network to operate over a bigger distance at the expense of bitrate.
- Enable transmitter: Set the checkbox to switch the RF power on.
- Frequency: Set the desired transmission frequency. 2450
 MHz recommended.


△ Warning

Be careful when choosing the frequency. The user may see interference with the Wifi frequency band, consult the radio spectrum.

- **Channel bandwith**: Select the desired bandwidth from the drop-down list. Lower bandwidths provide greater range at the expense of data throughput. **10 MHz is recommended**.
- Output attenuation: The level of attenuation in dB that is applied to the output (from 0 to 32). O dB of attenuation is recommended
- RF output port: The transmitter has two COFDM antennas, A and B. A is selected as the output antenna by default, but the user can select A or both if required.
- PA linearity: High linearity improves the COFDM shoulder performance at the expense of power consumption.
 Usually used when working with power amplifiers which must have excellent shoulder performance to operate, or for improved adjacent channel performance.

△ Warning


To ensure proper communication between the two radios, the radio linked to the **air unit must have these same 'Mesh settings' except for the Node Id**, as each node in the mesh has its own Id (starting with Id 0):



Mesh settings air configuration

Moreover, there are up to **16 different preset configurations that** can be setup.

All these settings are made for preset 1, which is highlighted with a blue background in the 'Mesh settings' tab to indicate that it is active. In addition, a 'preset indicator' with the current present is always displayed at the top right of the application, as shown in the figure below.




Current preset configuration

Unit Settings:


External Power Enable: There is an external power output which can be used to supply 12VDC (1A) to an external device.

This could be a camera, GNSS antenna or other device.



Unit settings configuration

3. **Data** → **RS232 #1**: In this menu the parameters of the RS232 port and the network settings are configured:




RS232 #1 configuration


- **Data mode**: **UDP** option is recommended. UDP packets are sent out and the system does not expect a reply. There is no way that the sending device can tell if the data arrived at the destination.
- The value of the Baud rate, Parity and Stop Bits parameters must be the same as those configured in 1x PDI Builder.
 - (i) Note

The data is assumed to be 8 bits.

- Low latency: Low latency will minimise delay at the expense of bitrate, so if set, data transfer will be less prone to bursts. Yes is recommended.
- IP address: This should be the address of the radio receiving the data on the other end of the RS-232.
 In this case, as the radio connected to the ground unit is being
 - configured, the **IP of the radio linked to the air unit will be set**.
- **IP port**: This set an IP port to and from which the data will be transferred. It must be **the same for both radios**.



 System → Maintenance: This menu allows to import and export radio configurations.




Maintenance configuration

To **import** a configuration into the radio, it is first necessarry to choose a configuration from the local storage by clicking on the icon.

Then, the 'import button' will already be available (colored in blue) to

click on and consequently import the selected configuration. An example is shown below:




Configuration selected

Paired radios

Once both radios have been configured with these settings, they should be paired. Therefore, if we connect them to the power supply and only one of them to the computer, we can access the Domo Node Finder software or directly the Web Browser control application to check if they are correctly paired.

Domo Node Finder software

When 2 radios are paired, they will both appear here:




Domo Node Finder - Radios paired

As can be seen in the figure above, the connection type of each radio is indicated with different icons:

- Region for the radio that is wiredly connected to the PC.
- (•) icon for the radio that is connected by link.

Web Browser control application


When two radios are paired, this can be seen/checked directly in the 'Dashboard' of both radios.



Radios paired - Dashboard

Furthermore, it can be seen that the above figure is related to the radio that is connected by link, as it is indicated at the top of the application with the label Over radio link.

• Apps → Tactical Display: Here the user can check the connection and the quality of the signal connection of both radios:



Radios paired - Tactical Display

Map display: The color of the link between nodes indicates
the quality of the signal. The colors range from green (reliable
link) to red (unreliable link). If no link is displayed, it means
that communication has been lost.

• **TX info**: TX info should be selected to check the quality of the signal connection.

Token Tx retries: In a Mesh network, transmission is arbitrated by passing a token between nodes. This tab displays the number of token retries that have been needed for each node. It must be 0 with occasional 1 for a proper communication.

△ Caution

Higher values will have an undesirable effect on system performance. If problems occur, check for interference and that there is no other Mesh system operating on the same or adjacent frequency.

Point-to-Multipoint configuration

It is possible that the user wants to make a point-to-multipoint radio connection, i.e. there will be one radio sending commands to several radios, so there will be at least 3 radios.

The following is the configuration required for this type of connection.


Radio configuration

The modifications to be made to the basic configuration explained above for the point-to-point application are detailed below.


(i) Note

This example has been made with 3 radios (3 nodes in a mesh).


 Presets → Mesh Settings: The Node ID must be different for each node in the mesh.



Mesh settings ground configuration




Mesh settings air configuration



Mesh settings base configuration

In the figures above, the user can see that the node ID is displayed at the top of the application at all times.

2. Data → RS232 #1: The Multicast data mode must be configured. This data mode allows a single node to send RS232/RS485 data to multiple nodes in the system. And it also creates a unicast data return channel. The radio linked to the ground unit is configured as the 'Point' that sends the commands.




RS232 #1 ground configuration


- Data mode: Multicast source must be selected.
- **IP address**: To send the data to all receivers the IP address must set to **255.255.255.255**.
- Multicast address: It must be the same for all radios, avoiding the 244.0.0.X address range.

The address must be different from any multicast streaming and data channels.

Then, the **radios linked to the air and base units** receive those commands:



RS232 #1 air unit configuration



RS232 #1 base unit configuration

- Data mode: Multicast sink must be selected.
- IP address: The IP address of the radio linked to the ground unit is set.
- Multicast address: It must be the same for all radios, avoiding the 244.0.0.X address range.

The address must be different from any multicast streaming and data channels.


Paired radios

Once the radios have been configured with these settings, they should be paired. Therefore, if we connect them to the power supply and only one of them to the computer, we can access the Domo Node Finder software or

directly the Web Browser control application to check if they are correctly paired.

Domo Node Finder software

When 3 radios are paired, they will appear here:




Domo Node Finder - 3 radios paired

As can be seen in the figure above, there is 1 radio wiredly connected to the PC and 2 radios connected by link.

Web Browser control application


When 3 radios are paired, this can be seen/checked directly in the '**Dashboard**' of the three radios.



Radios paired - Dashboard

Furthermore, it can be seen that the above figure is related to a radio that is connected by link, as it is indicated at the top of the application with the label Over radio link.

 Apps → Tactical Display: Here the user can check the connection and the quality of the signal connection of the radios:



Radios paired - Tactical Display

For more information on the configuration of **DTC** radios, please refer to the **DTC** documentation.

DTC radio configuration in 1x PDI Builder

The necessary configuration of **DTC** radio in **1x PDI Builder** is described in the External radios - Integration examples section of the **1x PDI Builder** manual.

Microhard pDDL900-ENC external

System Layout

It is possible to operate Microhard radios in two different ways, with or without amplifiers.

Microhard

The following image shows the standard connection between **Microhard** radios and **Autopilot 1x** for operation:



Microhard radios and Autopilot 1x operation

Microhard + Amplifier

(i) Note

Amplifier information: **DDL900 Amplifier** model, 10W Linear Amplifier.

The following image shows the standard connection between **Microhard** radios, amplifiers and **Autopilot 1x** for operation:



Microhard + amplifier radios and Autopilot 1x operation

Hardware Installation

First, it is necessary to carry out the wiring of the **power** connector with the **4- pin power cable** supplied with the **Microhard** radio and with the power connector of the amplifier:




Female DC Power Jack connector

| | | | Power Jack Connector | |
|-----------|-------|---------------|----------------------|--|
| | PIN | Signal | Signal | |
| RADIO | RED | Vin+ 9-30V | Power + | |
| AMPLIFIER | 1 | DC 24-30V | rowel T | |
| RADIO | BLACK | Vin- | Power - | |
| AMPLIFIER | 2 | GND | | |


① Danger

The specified supply voltage range for **Microhard** radios + amplifier is different from that of just **Microhard** radios. Please take this into account when powering.

Then, to physically connect the **Microhard** radio to **Veronte Autopilot 1x** for **operation**, connect an **RS-232** connector between the RS-232 port of the radio and the RS-232 of **Autopilot 1x** harness.



Serial port of Microhard radio



Autopilot 1x harness pinout

| Serial port - Microhard radio | | Autopilot 1x Harness | | |
|----------------------------------|--------|----------------------|--------------|----------------|
| PIN | Signal | PIN | Signal | Color Code |
| 2 | RXD | 20 | RS 232 RX | Pink- Brown |
| 3 | TXD | 19 | RS 232 TX | White- Pink |
| 5 | GND | 21 | GND | White- Blue |

Microhard radio configuration

First steps




Microhard ports

Microhard without amplifier

- 1. Connect a suitable 900 MHz antenna to the ANT1/MAIN connector.
- Connect to the 4-pin molex power connector the 4-pin power cable supplied with the unit.
- 3. Connect the power connector that has been previously wired with the cable to either 12V or 24V power.
 - Then, once the radio is fully booted, the **Power LED** indicator (the one next to the power symbol) will be **solid blue**.
- 4. To access the radio's WebUI for configuration, connect the **LAN** port (**not the WAN port**) to a PC, using an Ethernet cable.

The connections should look like this:




First steps connection

5. To open the **Microhard** WebUI, open a browser and enter the IP address of the radio into the address bar.

(i) Note


If users have problems accessing the **Microhard** radio WebUI, it may be because the PC's network connection settings (IP address and subnet of the adapter) are not configured properly. For further details, consult Microhard radio troubleshooting section below.

- 6. The website will then ask for a **Username** and **Password**. Enter the factory defaults:
 - Username: admin
 - Password: admin



Open WebUI

- 7. Click **Sign In** and the WebUI will open.
- 8. Once successfully logged in for the first time, the WebUI will force a password change.
- Microhard with amplifier



Amplifier ports

- 1. Connect to the ANT1/MAIN connector of the radio a SMA RF cable.
- 2. Connect this **SMA RF cable** to the amplifier **RADIO** port. Connect a suitable 900 MHz **antenna** to the amplifier **ANTENNA** port.
- 3. Connect to the **4-pin molex power connector** of the radio the **4-pin power cable** supplied with the unit.
- 4. Plug to the **POWER** port of the amplifier, the power connector supplied with it.
- 5. Connect the power connector that has been previously wired with the radio cable and the amplifier connector to 24V power.
 Then, once the radio is fully booted, the Power LED indicator (the one next to the power symbol) will be solid blue.
- 6. Now the steps to follow are the same as **from step 4. of a Microhard without amplifier**, described above.

The connections should look like this:



First steps connection + amplifier

For more information on the configuration of **Microhard** radios, please refer to the **Microhard** documentation.


Basic radio configuration

Once the website has been accessed, follow the steps below which show the parameters that need to be modified for a correct **point-to-point** configuration and pairing of the radios.

! Important

This example describes the parameters to be entered for both the radio linked to the 1x ground unit and the radio linked to the 1x air unit.

If the values are common to both radios configurations, only one of them will be detailed.



Submit or Cancel changes

Current Date(yyyy-mm-dd)
Current Time(hh:mm:ss)

Date and Time Setting Mode

Date (yyyy-mm-dd) Time (hh:mm:ss) 2022-09-22

15:07:46 ● Local Time ○ NTP

2022-09-22

15:07:46

1. System


 Maintenance: From this menu, users can export (backup) and import (restore) configurations.

Submit « Cancel «

- Backup Configurations: The radio configuration can be backed up to a file at any time using the Backup Configuration feature.
- Restore Configurations: Using this option, a previously 'backed up' configuration can be uploaded to the radio.

(i) Note


A password can be added to backup and restore files. If the password is lost, files that have been backed up with a password cannot be restored.



System Maintenance


To **import** (restore) a configuration into the radio, it is first necessary to choose a configuration from the local storage by clicking on Choose File.

Then, once the configuration is loaded, click on the Check Configuration File button.




System Maintenance - Restore Configuration 1

After that, if the file is correct, a new window will appear to restore this configuration.



System Maintenance - Restore Configuration 2

Finally, the WebUI will reloaded to applied the configuration.




System Maintenance - Restore Configuration 3

① Error

If the restored configuration has a different IP address assigned to the radio, users may have to change again the **adapter settings** on the PC to be able to access the WebUI with the new IP address of the radio.


 Summary: This screen is displayed immediately after the initial login, showing a summary and status of all radio functions on a single display.

This information includes system status, LAN network information and settings, version information, radio connection status, etc.




System Information

 Settings: To easily identify each radio in a mesh, the user can rename the radio as desired by configuring the Host Name and Description parameters:




System Settings - GND unit



System Settings - Air unit

 Network → LAN: Ethernet LAN port of the radio is for connecting devices to a local network.


By default, this port has a static IP address, and also, it is running a DHCP server to provide IP addresses to devices that are connected to the physical LAN port (directly or through a switch).




LAN Interfaces Settings

By selecting the **Edit** or **Add** buttons, the LAN network interface can be configured or additional LAN interfaces can be created.

LAN Configuration:



LAN Configuration - Ground unit



LAN Configuration - Air unit

 Connection Type: To determine whether the radio will obtain an IP address from a DHCP server on the connected network or whether a static IP address will be entered. Select the Static IP option for this point-to-point configuration.

Since the Static IP option has been chosen, the following fields must also be entered.


- IP Address: A valid IPv4 address for the network used must be entered in this field.
 - For the radio linked to the **ground** unit \Rightarrow **192.168.8.4** has been entered.
 - For the radio linked to the **air** unit \Rightarrow **192.168.8.5** has been entered.
- Netmask: The Network Mask for the network must be entered. The default netmask 255.255.255.0 is normally left.
- Default Gateway: If the radio is integrated into a network that has a
 defined gateway, then, as with other hosts on the network, the IP
 address of this gateway will be entered in this field.
 - In case the user is using a **PCS**, **192.168.8.1** should be set here.
- Default Route: This parameter allows the user to set this interface as the default route in the routing table.

In cases where the LAN is the primary connection, this would be set to **Yes**.

! Important

Once the IP Address has been changed, users will have to type the new address in the browser in order to continue with the configuration.

LAN DHCP: A radio can be configured to provide Dynamic Host Control Protocol (DHCP) service to all connected devices (wired or wireless).




LAN DHCP

 DHCP Server: Enables/Disables the DHCP service for devices connected to the LAN port. Therefore, devices that are connected to the physical Ethernet LAN ports will be assigned an IP by the radio.

△ Caution

Before enabling this service, check that there are no other devices, either wired or wireless, with an active DHCP Server service.



Start IP Address: Select the starting DHCP address from which IP addresses will be assigned. The first octets of the subnet will be pre-set based on the LAN IP configuration, and cannot be changed. We enter here 192.168.8.100.

Adapter settings - IP address automatically


 Number of Address: Set the maximum number of IP addresses that can be assigned by the radio. By default, 150 (this is an integer value).

 Lease Time (in minutes): The DHCP lease time is the amount of time before a new request for a network address must be made to the DHCP Server. Defaults to 720 minutes.


3. **Wireless** \rightarrow **RF**: Allows to configure the radio module.

! Important

Ensure that the **RF Band**, **Channel Bandwidth** and **Frequency-Channel** are set the same on each module.



Wireless Configuration - Ground unit



Wireless Configuration - Air unit

RF Configuration:

- Radio: Turns the radio module on/off.
- RF Band: Select the desired RF band to work, 900 MHz or 2.4 GHz. In this case, we select 900 MHz.
- Channel Bandwidth: Select the channel bandwidth from the list.
 Generally a larger channel has higher throughput, at the cost of sensitivity, while a smaller channel tends to be more robust, but at the cost of throughput. 1 MHz is recommended.

△ Caution

Refer to the radio specifications (**Microhard** documentation) in order to see the relationship and performance between channel bandwidth, throughput and sensitivity.

900 MHz Channel: Set the Channel-Frequency. The frequency displayed is the center frequency and is available in 1 MHz increments. The values shown will vary with the Channel Bandwidth selected above. 13-915 MHz is recommended.

Important

This value must be **the same on each unit in a network**.

 The noise floor of the specified channel will dramatically affect the link quality, it is essential to select the cleanest channel for superior performance.

 Tx Power: This setting establishes the transmit power level that will be presented to the antenna connector of the radio. Select 30 dbm here.

△ Caution

For bench or proximity testing, it is best to use a lower power setting to avoid RF saturation.

- Wireless Distance: This parameter allows users to set the expected distance the wireless signal should travel.
 - The radio sets various internal timeouts to account for this travel time. Longer distances will require a higher setting, and shorter distances may work better if the setting is reduced. **3000 m** is set.
- Operation Mode: A radio in Master mode can provide a wireless data connection to multiple slaves/remotes.
 - And, in **Slave** mode, it can maintain a wireless connection, i.e. to a Master.
 - For the radio linked to the **ground** unit ⇒ Master mode must be selected.
 - For the radio linked to the air unit ⇒ Slave mode must be selected.
- TX Rate: This setting determines the type of modulation and, in turn, the rate at which the data will be transferred wirelessly.
 - The default and **recommended** setting for both Master and Slave units is 'Auto'.
 - In 'Auto', the unit will transfer data at the highest possible rate depending on the receiving signal strength (RSSI).
- Network ID: Each radio module network must have a unique Network
 ID. In this case, pDDL has been entered.


! Important

This Network ID must be configured the same in each unit on the network.


RF Serial Port Configuration:

- Serial Port TX Rate: When using Ethernet and Serial data,
 - If the volume of **serial data** is high ⇒ Normal Rate (default option)
 - If the volume of **Ethernet data** is high \Rightarrow High Rate (compressed).
- 4. Serial → Settings: This menu allows configuring the serial device server for the serial communications port. Data from the serial device can be brought into the IP network via TCP, UDP or multicast; it can also come out of the radio network on another radio serial port.

Port Configuration:



Port Configuration - Ground unit



Port Configuration - Air unit

- Port status: Select the operating state of the serial port. By default,
 Data.
- Port Mode: RS232 must be selected.
- Data Baud Rate: The serial baud rate is the rate at which the modem should communicate with the connected local asynchronous device.

Important

It must match the one configured in the 1x PDI Builder software

- **→ 115200**.
- Data Format: This setting determines the format of the data on the serial port. It is the set of Data Bits, Parity and Stop Bits parameters.

Important

It must match those configured in the 1x PDI Builder software

→ **8N1** (8 data bits, No parity, and 1 Stop bit).


- Data Mode: This setting defines the framing of the serial output data.
 - In Transparent mode (default), the received data will exit the radio quickly.
 - In Seamless mode, the serial port server will add a gap between data frames to comply with a specified protocol.

In this case, **Transparent** mode is selected.

- Character Timeout: Defaults to 24 characters.
- Maximum Packet Size: Defines the size of the buffer that the serial server will use to receive data from the serial port.
 When the server detects that the Character Timeout criterion has been met, or the buffer is full, it packs the received frame and transmits it.
 It must be 266, as this is the maximum packet size supported by Veronte Communication Protocol (VCP).
- **IP Protocol Config**: This setting determines which protocol the serial server will use to transmit serial port data over the radio network.
 - For the radio linked to the **ground** unit \Rightarrow **TCP Server**.
 - For the radio linked to the **air** unit \Rightarrow **TCP Client**.

TCP Configuration: The protocol selected in the IP Protocol Config field will determine which configuration options appear in this configuration menu.

- In the TCP Server mode, the radio series will not initiate a session, but will wait for a Client to request a session. The unit will 'listen' on a specific TCP port.
 - If a **session** is **established**, data will flow from the Client to the Server, and, if present, from the Server to the Client.
 - If a **session** is **not established**, both Client serial data and Server serial data, if present, will be discarded.




TCP Configuration - Ground unit

- Server Mode: Monitor is recommended.
- Local Listening port: The TCP port on which the server listens.
 Allows a TCP Client to create a TCP connection to transport data from the serial port. 20002 should be set.
- Incoming Connection Timeout (seconds): Establishes when the TCP Server will terminate the TCP connection if the connection is in an idle state. It is recommended 5 seconds.
- When TCP Client mode is selected and data is received on its serial port, the radio takes the initiative to find and connect to a remote TCP server.

The TCP session is terminated by this same unit when the data exchange session is completed and the connection timeout has expired.

If a TCP connection cannot be established, data is discarded from the serial port.



TCP Configuration - Air unit

• Remote Server IP Address: Enter an IP address of a TCP server which is ready to accept serial port data over a TCP connection.
Users must set the IP adddress of the radio defined as Master, in this case, the IP address of the radio linked to the ground unit ⇒
192.168.8.4.

Connection status radio

- Network → Status: Provides an overview of the currently configured network interfaces, including the Connection Type (Static/DHCP), IP Address, Net Mask, Default Gateway, DNS, and IPv4 Routing Table.
- Wireless → Status → General Status: Shows the MAC address
 of the current radio, the Operating Mode (Master, Slave etc), the Network
 ID being used, Channel Bandwidth and Frequency information and the type
 of security used.
- Serial → Status: This window displays a number of status items that help to visualize the operation, statistics and troubleshooting of the RS232 port.

(i) Note

That is, the connection status with **Veronte Autopilot 1x**.

 Port Status: Shows whether the RS232 port has been enabled in the configuration.

- Baud Rate: The current baud rate used to interact with the connected device.
- Connect As: This shows the type of IP Protocol Config chosen (TCP, UDP, SMTP, PPP, etc).
- Connect Status: Shows if there is a current connection / if the port is active.
- Receive bytes/packets
- Transmit bytes/packets

In addition, to check the connection status between the **Autopilot 1x** and the radio, users can simply look at the LED indicators on the radio:

- When the **TX LED** turns **red**, that indicates that the modem is transmitting data over the radio.
- When the **RX LED** turns **green**, it indicates that the moden is synchronized and has received valid packets.

Paired radios

Once both radios are configured with these settings, they should be paired.


Therefore, by connecting both to the power supply, users can check that they are paired by simply observing the **RSSI LEDs**, they should be in a **solid green**. The more LEDs ilumitated \Rightarrow the stronger the link.

Moreover, users can access the radio's WebUI to check it in the following menu:

(i) Note

If they are correctly linked, by connecting only one of the radios to the PC, users will be able to access the WebUI of both radios.


Wireless → **Status**: The Status window provides an overview of all wireless or radio settings and connections.



Wireless Status

- Traffic Status shows statistics on transmitted and received data.
- Connection Info displays information about all wireless connections.

 The MAC address, TX & RX Modulation, Signal to Noise ratio (SNR), Signal Strength (RSSI), and a graphical representation of the signal level or quality, as well as a RSSI Graph Link. By clicking on , a new window with the RSSI Graph Link will be displayed:



Wireless Status - RSSI Graph Link

Microhard radio configuration in 1x PDI Builder


The necessary configuration of **Microhard** radio in **1x PDI Builder** is described in the External radios - Integration examples section of the **1x PDI Builder** manual.

Microhard radio troubleshooting

If the user has problems accessing the radio's WebUI, try setting the computer to the static IP address on the same subnet as the radio.


The following steps clarify how to set the IP address in the **Control Panel**:

1. Open **Network and Sharing Centre** menu and click **Change adapter settings**.




Ethernet connection 1

2. Select Local Area Connection, right click, and select Properties.




Ethernet connection 2

3. Select IPv4 and click Properties.



Ethernet connection 3

4. Set **IP address** to 192.168.168.YY (e.g. if the IP of the radio is 192.168.168.1, set the IP 192.168.168.10) and **Subnet mask** to 255.255.255.0. Click **OK**.



Ethernet connection 4

Silvus radio (StreamCaster 4200E model)

System Layout


The following image shows the standard connection between **Silvus** radios and **Autopilot 1x** for operation:



Silvus and 1x connection

Hardware Installation

A wiring configuration of the PRI cable connected to the PRI port of the radio is required, in order to connect to the power supply, ethernet and RS-232.



PRI port connector (mounted in radio)


Power supply



Female DC Power Jack connector

| PRI port Connector - Silvus Radio | | Power Connector |
|---|--------|--------------------|
| PIN | Signal | Signal |
| 2 | GND IN | Power - |
| 3 | VCC IN | Power + |

Ethernet




RJ45 pinout T-568B

| PRI port Connector - Silvus Radio | | RJ45 Connector (T-568B) | | |
|---|--------------------|----------------------------|--------|------------------|
| PIN | Signal | PIN | Signal | Color Code |
| 4 | ETH0_MX2N (RX-) | 6 | RX- | Green |
| 5 | ETHO_MX2P (RX+) | 3 | RX+ | Green- White |
| 6 | ETHO_MX1P (TX+) | 1 | TX+ | Orange- White |
| 10 | ETH0_MX1N (TX-) | 2 | TX- | Orange |

• RS-232

The RS-232 from the PRI cable should be connected to the RS-232 of **Autopilot 1x** harness.



Autopilot 1x harness pinout


| PRI port Connector - Silvus Radio | | Autopilot 1x Harness | | |
|---|-----------|----------------------|--------------|----------------|
| PIN | Signal | PIN | Signal | Color Code |
| 7 | RS232_RXD | 19 | RS 232 TX | White- Pink |
| 8 | RS232_TXD | 20 | RS 232 RX | Pink- Brown |
| 9 | GND | 21 | GND | White- Blue |

Silvus radio configuration

This section shows a basic configuration of the **Silvus** radio.

First steps

- 1. Connect antennas (or attenuators) with male TNC ends to 2 RF ports.
- 2. Connect power supply to power port on PRI cable.
- 3. Connect non-forked female side of PRI cable to radio's PRI port.




Silvus connectors

4. When looking at the rotary multi position switch from the top, pull the knob towards you while rotating the knob towards the 1 position.

This turns radio on. LED indicator will turn to fix red.


- 5. In order to access the StreamScape graphical user interface (GUI), connect Ethernet (RJ45) connector of PRI cable to Ethernet port of laptop/computer.
- 6. Make sure computer is set to static IP address on same subnet as radio.

 The following substeps clarify how to set the IP address:
 - 1. Open **Network and Sharing Centre** menu and click **Change** adapter settings.




Ethernet connection 1

2. Select Local Area Connection, right click, and select Properties.




Ethernet connection 2

3. Select IPv4 and click Properties.




Ethernet connection 3

4. Set **IP address** to 172.20.XX.YY (e.g. if the IP of the radio is 172.20.178.203, set the IP 172.20.178.200) and **Subnet mask** to 255.255.0.0. Click **OK**.



Ethernet connection 4

- 7. Wait for LED indicator to turn to blinking green.
- 8. Access **StreamScape** GUI in web browser. To access, enter IP address of radio into web browser and press enter.



Silvus initial menu

9. User manual can be accessed by clicking the book icon in the GUI (Next to **Basic Configuration** in the previous screenshot).

Basic radio configuration

Once the website has been accessed, follow the steps below which show the parameters that need to be modified for correct operation and pairing of the radios.


(i) Note

This is an example of the radio configuration linked to a 1x air unit.

(i) Note

After making changes to each window, it is important to click on "Save and apply".

1. Basic Configuration.



Basic configuration panel

 Frequency (MHZ): This defines the frequency of the signal. There is a drop-down menu for frequency selection. We recommend 2220 MHz.

⚠ Warning


Be careful when choosing the frequency. The user may see interference with the Wifi frequency band, consult the radio spectrum.

• **Bandwith**: This defines the RF bandwidth of the signal. Default value.

 Network ID: Network ID allows for clusters of radios to operate in the same channel, but remain independent.


A radio with a given Network ID will only communicate with other radios with the same Network ID.

- Link Distance (meters): Set to an approximate maximum distance between any two nodes in meters. It is important to set the link distance to allow enough time for packets to propagate over the air. It is recommended to set the link distance 10-15% greater than the actual maximum distance.
- Total Transmit Power (requested): This defines the total power of the signal (power is divided equally between the radio antenna ports).
 Set the appropriate power for each application. The power that has been set is small, as it is sufficient for our tests.
- Routing Mode: As Large Network mode requires a license and is not available outside USA, we set Legacy mode.
- 2. Advanced configuration.




Advanced configuration panel

- Transmit/Receive Channels: Allows user to enable or disable each channel on the radio for TX/RX (each RF port is a channel).
 We have enabled both channels.
- 3. Networking. Multicast.



Multicast panel


- **Default Multicast Algorithm**: Broadcast.
- Custom Pruning/Augmenting: Disable.
- 4. Serial/USB Setup




RS-232 settings

- Serial Port Setup: RS-232.
- RS-232 Serial Port Settings
 - The value of the Baudrate, Data Bits, Parity and Stop Bits parameters must be the same as those configured in 1x PDI Builder.
 - Software Flow Control: Disable.
 - **Transport Protocol**: We recommend **UDP**. If no data loss can be tolerated, change this setting to TCP on the radio corresponding to the 1x **air** unit.

• **Peer IP**: This should be the IP address of the radio on the other end of the RS-232. In this example, we must set the IP address of the radio linked to the ground unit.




In addition to these settings, different configurations can be stored in the same radio, on the **Multi-Position Switch** panel. The user can select the one that will work, with the radio's switch position.



Multi-Position Switch panel


In this example only one configuration has been created.

With the above settings the configuration is finished. Furthermore, this configuration can be saved and downloaded in the **Settings Profile** window of the Configuration Profiles section.




Settings Profile panel

Before downloading the configuration, it is necessary to save it.




Save settings



Download settings

After configuring both radios with these settings they should be paired. Therefore, if we connect them to the power supply, when we switch them on, the LED will turn from fix red to fix green, this indicates that it is connected to at least one radio. Also, if we connect only one of them to the computer, we can access the **StreamScape** GUI of both.

And, in the **Network Topology** window of the Network Management section, we can see the link between them.



Connection between radios

Silvus radio configuration in 1x PDI Builder

The necessary configuration of **Silvus** radio in **1x PDI Builder** is described in the External radios - Integration examples section of the **1x PDI Builder** manual.

Veronte SDL

SDL radio module has its own user manual, click here to read it.

This section shows how to connect and configure a **SDL** (any variant) with an **Autopilot 1x air unit** and an **Autopilot 1x ground unit**. The following diagram summarizes the flight communication system between a 1x ground unit and a 1x air unit installed on an aircraft.




Operation diagram

First of all, **Autopilots 1x** and **SDL** require software configuration:

- To configure **Autopilots 1x**, use **1x PDI Builder** by reading **External radios**
 - Integration examples section of the **1x PDI Builder** user manual.
- To configure **SDL**, read the following sections of the **SDL** user manual:
 - To know the basics and start configuring it: Software Installation.
 - To configure according to the application requirements: Veronte Autopilot 1x - Integration examples.

Once all devices have been configured, the electrical connections can be established with the following figure, which shows the required connections according to 1x pinout, and SDL pinout.



Connections diagram


GNSS Receivers

NexNav GNSS



NexNav GNSS


NexNav GNSS sensor integrates with Autopilot 1x via RS232 connection.




NexNav GNSS - Autopilot 1x wiring diagram

Important

Note that it must be connected to an external power supply, sharing **signal ground** with **Autopilot 1x**.



NexNav GNSS connector pinout



Autopilot 1x harness pinout

| Autopilot 1x Harness | | NexNav GNSS Connector | | |
|----------------------|--------------|-----------------------|-----|----------------------|
| PIN | Signal | Color Code | PIN | Signal |
| 19 | RS 232 TX | White- Pink | 20 | RS-232 RX, Port 1 |
| 20 | RS 232 RX | Pink- Brown | 7 | RS-232 TX, Port 1 |
| 21 | GND | | 10 | |

| Aut | opilot 1x | Harness | | xNav GNSS connector |
|-----|-----------|----------------|-----|------------------------|
| PIN | Signal | Color Code | PIN | Signal |
| | | White- Blue | | RS-232 Ground |

⚠ Warning

Remember!! In **Autopilot 1x**, all GND pins are common. Note that pin 54 is not a common GND pin.

The software installation of this device with **Autopilot 1x** is explained in the NexNav GNSS - Integration examples section of the **1x PDI Builder** user manual.

IMUs & Compass


IMUs

Vectornav VN-300



Vectornay VN-300


Vectornav VN-300 is an **external IMU** that can be connected via **RS-232** (serial interface) to **Veronte Autopilot 1x**.




Vectornav VN-300 - Autopilot 1x wiring diagram

Important

Note that it must be connected to an **external power supply**, **sharing signal ground** with **Autopilot 1**x.



Vectornav VN-300 connector pinout



Autopilot 1x harness pinout

| Autopilot 1x Harness | | VectorNav VN-300 Connector | | |
|----------------------|--------------|-------------------------------|-----|--------|
| PIN | Signal | Color Code | PIN | Signal |
| 19 | RS 232 TX | White- Pink | 1 | RX1 |
| 20 | RS 232 RX | Pink- Brown | 2 | TX1 |
| 21 | GND | White- Blue | 5 | GND |

⚠ Warning

Remember!! In **Autopilot 1x**, all GND pins are common. Note that pin 54 is not a common GND pin.


Once the IMU is connected, the user must proceed to its software integration with **Veronte Autopilot 1x** by referring to the Vectornav VN-300 - Integration examples of the **1x PDI Builder** user manual.

WitMotion HWT905-232



WitMotion HWT905-232


Vectornav VN-300 is an **external IMU** that can be connected via **RS-232** (serial interface) to **Veronte Autopilot 1x**.




WitMotion HWT905-232 - Autopilot 1x wiring diagram

Important

Note that it must be connected to an **external power supply**, **sharing signal ground** with **Autopilot 1**x.



WitMotion HWT905-232 connector pinout



Autopilot 1x harness pinout

| | Autopilot 1x Harness | | | WitMotion HWT905-232 Connector | | |
|-----|-------------------------|----------------|-----|--------------------------------------|---------------|--|
| PIN | Signal | Color Code | PIN | Signal | Color Code | |
| 19 | RS 232 TX | White- Pink | 2 | RX | Green | |
| 20 | RS 232 RX | Pink- Brown | 3 | TX | Yellow | |
| 21 | GND | White- Blue | 4 | GND | Black | |

△ Warning

Remember!! In **Autopilot 1x**, all GND pins are common. Note that pin 54 is not a common GND pin.

Once the IMU is connected, the user must proceed to its software integration with **Veronte Autopilot 1x** by referring to the WitMotion HWT905-232 - Integration examples of the **1x PDI Builder** user manual.


Magnetometers

Magnetometer Honeywell HMR2300




Magnetometer Honeywell HMR2300

Magnetometer Honeywell HMR2300 is an external magnetometer that can be connected to Veronte Autopilot 1x via RS232 or RS485 (serial interfaces).




Magnetometer Honeywell HMR2300 connector pinout



Autopilot 1x harness pinout

Connections via RS232 and RS485 interfaces are explained separately.

RS232



Magnetometer Honeywell HMR2300 (RS232) - Autopilot 1x wiring diagram

For proper operation via **RS232**, the connection between **Magnetometer Honeywell HMR2300** and **Autopilot 1x** pins should be like this:


| Autopilot 1x Harness | | Magnetometer Honeywell HMR2300 Connector | | |
|----------------------|--------------|--|-----|--------|
| PIN | Signal | Color Code | PIN | Signal |
| 19 | RS 232 TX | White- Pink | 3 | RD |
| 20 | RS 232 RX | Pink- Brown | 2 | TD |
| 21 | GND | White- Blue | 5 | GND |

△ Warning

Remember!! In **Autopilot 1x**, all GND pins are common. Note that pin 54 is not a common GND pin.

Once the **Magnetometer Honeywell HMR2300** is connected, the user must proceed to its software installation with **Veronte Autopilot 1x** by referring to the **Magnetometer Honeywell HMR2300** (RS232) - Integration examples of the **1x PDI Builder** user manual.

RS485



Magnetometer Honeywell HMR2300 (RS485) - Autopilot 1x wiring diagram

For proper operation via **RS485**, the connection between **Magnetometer Honeywell HMR2300** and **Autopilot 1x** pins should be like this:

| Autopilot 1x Harness | | Magnetomete Honeywell HMR2300 Connector | | |
|----------------------|-------------|---|-----|-------------------------|
| PIN | Signal | Color Code | PIN | Signal |
| 50 | OUT_RS485_P | Pink- Brown | 2 | TD (B) Transmit |
| 53 | IN_RS485_P | White- Red | 2 | Data, RS-485 (B+) |
| 51 | OUT_RS485_N | White- Blue | 3 | RD (A) Receive |
| | | | | Data, |

| Autopilot 1x Harness | | | Ho | netometer neywell MR2300 nnector |
|----------------------|------------|----------------|-----|---|
| PIN | Signal | Color Code | PIN | Signal |
| 52 | IN_RS485_N | Brown- Blue | | RS-485 (A-) |
| 54 | OUT_GND | Brown- Red | 5 | GND |

⚠ Warning


Note that this pin 54 is not a common GND pin.

(i) Note


If users encounter any problems during wiring, please check the Halfduplex servo does not respond - Troubleshooting section of this manual.

Once the **Magnetometer Honeywell HMR2300** is connected, the user must proceed to its software installation with **Veronte Autopilot 1x** by referring to the Magnetometer Honeywell HMR2300 (RS485) - Integration examples of the **1x PDI Builder** user manual.

MEX as Magnetometer Honeywell HMR2300



MEX connector pinout



Autopilot 1x harness pinout

MEX can be used as an **external magnetometer Honeywell HMR2300** connected to **Veronte Autopilot 1x** via **serial** (RS232/RS485) or **CAN** interfaces.

Connections via CAN, RS232 and RS485 interfaces are explained separately.

CAN

For proper operation via **CAN**, the connection between **MEX** and **Autopilot 1x** pins should be like this:

| A | Autopilot 1x Harness | | MEX Connector | |
|-----|----------------------|------------------|------------------|-----------|
| PIN | Signal | Color Code | PIN | Signal |
| 25 | CANA_P | White-Black | 22 | CAN A (P) |
| 26 | CANA_N | Brown-Black | 23 | CAN A (N) |
| 28 | CANB_P | Yellow- Green | 20 | CAN B (P) |
| 29 | CANB_N | Pink-Green | 21 | CAN B (N) |

| Autopilot 1x Harness | | | Co | MEX nnector |
|----------------------|--------|-------------|-----|----------------|
| PIN | Signal | Color Code | PIN | Signal |
| 30 | GND | Yellow-Pink | 24 | CAN GND |

(i) Note

If only CAN A or CAN B has been configured in the software for communications, only the corresponding pins must be connected.

For more information on CAN connection, please visit CAN - Wiring connection section of this manual.

△ Warning

Remember!! In **Autopilot 1x**, all GND pins are common. Note that pin 54 is not a common GND pin.

! Important

Integration is also possible by connecting CAN A of the **Autopilot 1x** to CAN B of the **MEX** and vice versa, i.e. it does not necessarily have to be CAN A-CAN A or CAN B-CAN B.

However, any connections made must be **consistent** with the **configuration** made at software level in 1x PDI Builder and MEX PDI Builder.

RS232

For proper operation via **RS232**, the connection between **MEX** and **Autopilot 1x** pins should be like this:

| Autopilot 1x Harness | | MEX Connector | | |
|----------------------|---------|----------------|------------------|------------------|
| PIN | Signal | Color Code | PIN | Signal |
| 10 | RS 232 | White- | 16 | RS-232 (A) RX |
| 19 | TX Pink | 19 | RS-232 (B) RX | |
| 20 | RS 232 | Pink- Brown | 15 | RS-232 (A) TX |
| 20 | RX | | 18 | RS-232 (B) TX |
| 21 | GND | White- Blue | 17 | GND |

△ Warning

Remember!! In **Autopilot 1x**, all GND pins are common. Note that pin 54 is not a common GND pin.

Important

Integration is possible by connecting the RS-232(A) or RS-232(B) from **MEX** to the RS232 of **Autopilot 1x**.

However, any connections made must be **consistent** with the **configuration** made at software level in 1x PDI Builder and MEX PDI Builder.

RS485

For proper operation via **RS485**, the connection between **MEX** and **Autopilot 1x** pins should be like this:

| Au | Autopilot 1x Harness | | | MEX Connector | |
|-----|----------------------|----------------|-----|----------------------|--|
| PIN | Signal | Color Code | PIN | Signal | |
| 50 | OUT RS485_P | Pink- Brown | 33 | IN RS-485 (P) | |
| 51 | OUT RS485_N | White- Blue | 31 | IN RS-485 (N) | |
| 52 | IN RS485_N | Brown- Blue | 32 | OUT RS-485 (N) | |
| 53 | IN RS485_P | White- Red | 30 | OUT RS-485 (P) | |
| 54 | OUT_GND | Brown- Red | 34 | RS-485 GND | |

△ Warning

Note that, in **Autopilot 1x**, this pin 54 is not a common GND pin.

Important

Any connections made must be **consistent** with the **configuration** made at software level in 1x PDI Builder and MEX PDI Builder.

PNI RM3100




PNI RM3100-CB


PNI RM3100-CB magnetometer must be connected to Autopilot 1x via I2C.

! Important

This integration example is described for the **RM3100-CB**.



PNI RM3100-CB - Autopilot 1x wiring diagram



Autopilot 1x harness pinout

| Autopilot 1x Harness | | PNI RM3100-CB Connector | | | | |
|----------------------|----------|-------------------------|-----|----------------------------------|---|---------------|
| PIN | Signal | Color Code | PIN | Signal | | |
| 31 | I2C_CLK | White | 1 | SCL | | |
| 32 | I2C_DATA | Brown | 3 | SDA | | |
| | | 4 | | | 4 | VSS Ground |
| 33 | GND | GND Green | 2 | SA1 Bit 1 of slave address | | |
| | | | 7 | SA0 Bit 0 of slave address | | |
| 34 | 3.3V | Yellow | 8 | VDD Supply Voltage | | |

| Aut | Autopilot 1x Harness | | | PNI RM3100-CB Connector | |
|-----|----------------------|---------------|-----|------------------------------------|--|
| PIN | Signal | Color Code | PIN | Signal | |
| | | | 5 | I2C_EN I2C enable pin (HIGH = I2C) | |


⚠ Warning

Remember!! In **Autopilot 1x**, all GND pins are common. Note that pin 54 is not a common GND pin.

Once the magnetometer is connected, the user must proceed to its software integration with **Veronte Autopilot 1x** by referring to the PNI RM3100 - Integration examples section of the **1x PDI Builder** user manual.


RPM Sensors

RPM sensors typically use different types of wiring depending on their technology and application. However, most RPM sensors, such as Hall effect, optical, or inductive sensors, generally have the following connection:



RPM Sensors - Autopilot 1x wiring diagram

RPM sensor must be connected to one of the available I/O pins of **Autopilot 1x**.



Autopilot 1x harness pinout

| Autopilot 1x Harness | | | | |
|----------------------|--------|------------|--|--|
| PIN | Signal | Color Code | | |
| 1 | 1/00 | White | | |
| 2 | I/O1 | Brown | | |
| 3 | 1/02 | Green | | |
| 4 | I/O3 | Yellow | | |
| 5 | 1/04 | Gray | | |
| 6 | I/O5 | Pink | | |
| 7 | 1/06 | Blue | | |
| 8 | 1/07 | Red | | |
| 9 | GND | Black | | |


| Autopilot 1x Harness | | | | |
|----------------------|--------|--------------|--|--|
| PIN | Signal | Color Code | | |
| 10 | 1/08 | Violet | | |
| 11 | 1/09 | Gray-Pink | | |
| 12 | I/O10 | Red-Blue | | |
| 13 | I/O11 | White-Green | | |
| 14 | I/O12 | Brown-Green | | |
| 15 | I/O13 | White-Yellow | | |
| 16 | I/O14 | Yellow-Brown | | |
| 17 | I/O15 | White-Gray | | |
| 55 | EQEP_A | White-Black | | |
| 56 | EQEP_B | Brown-Black | | |
| 57 | EQEP_S | Gray-Green | | |
| 58 | EQEP_I | Yellow-Green | | |
| 59 | GND | Pink-Green | | |

Once the **hardware installation** is complete, to properly integrate the device with **Autopilot 1x** follow the steps detailed in the RPM Sensors - Integration examples section of the **1x PDI Builder** user manual.

Stick

Veronte Autopilot 1x is compatible with joysticks that use PPM, CAN bus, USB, Serial, etc.


If the PPM level is 3.3V, the following **Autopilot 1x** pins can be used:



Autopilot 1x harness pinout

| Autopilot 1x Harness | | | | |
|----------------------|--------|------------|--|--|
| PIN | Signal | Color Code | | |
| 1 | 1/00 | White | | |
| 2 | I/O1 | Brown | | |
| 3 | 1/02 | Green | | |
| 4 | I/O3 | Yellow | | |
| 5 | 1/04 | Gray | | |
| 6 | I/O5 | Pink | | |
| 7 | 1/06 | Blue | | |
| 8 | 1/07 | Red | | |
| 9 | GND | Black | | |
| 10 | 1/08 | Violet | | |
| 11 | 1/09 | Gray-Pink | | |

| Autopilot 1x Harness | | | | |
|----------------------|--------|--------------|--|--|
| PIN | Signal | Color Code | | |
| 12 | I/O10 | Red-Blue | | |
| 13 | I/O11 | White-Green | | |
| 14 | I/O12 | Brown-Green | | |
| 15 | I/O13 | White-Yellow | | |
| 16 | I/O14 | Yellow-Brown | | |
| 17 | I/O15 | White-Gray | | |
| 55 | EQEP_A | White-Black | | |
| 56 | EQEP_B | Brown-Black | | |
| 57 | EQEP_S | Gray-Green | | |
| 58 | EQEP_I | Yellow-Green | | |
| 59 | GND | Pink-Green | | |





PPM signal



PPM signal must be into the **Veronte Autopilot 1x** voltage ranges. Some joysticks may need an adaptation board, please ask our team to check compatibility.

Connector for harness is provided with 3.5mm stereo plug connector as follows:





PPM connector

- To use the joystick with PPM in the system, connect the PPMout of the trainer port to a digital input of Veronte Autopilot 1x and configure that digital input according to the PPM Stick - Integration examples section of the 1x PDI Builder user manual.
- When using a USB joystick, the software installation with Autopilot 1x is detailed in the USB joystick - Integration examples section of the 1x PDI Builder user manual.
- For joysticks with signals **different from PPM or USB**, read the Virtual Stick Integration examples section of the **1x PDI Builder** user manual.


Veronte products

This section explains how integrate **Autopilot 1x** with Veronte products.

CEX connection

When communication is established between the PC and the **CEX** using the **Veronte Autopilot 1x** as a tunnel, the connection between the **CEX** and **Autopilot 1x** is via **CAN**.

The pin connection between the two devices should be like this:



| Autopilot 1x Connector | | | CEX Connector | | |
|------------------------|-------------------|------------------|---------------|--------------|---------------|
| PIN | Signal Color Code | | PIN | Signal | Color Code |
| 25 | CANA_P | White- Black | 5 | CAN (A) P | Gray |
| 26 | CANA_N | Brown- Black | 6 | CAN (A) N | Pink |
| 28 | CANB_P | Yellow- Green | 8 | CAN (B) P | Red |
| 29 | CANB_N | Pink- Green | 9 | CAN (B) N | Black |
| 30 | GND | | 7 | | Blue |

| Autopilot 1x Connector | | | CEX Connector | | |
|------------------------|--------|-----------------|----------------------|------------|---------------|
| PIN | Signal | Color Code | PIN | Signal | Color Code |
| | | Yellow- Pink | | CAN GND | |

(i) Note

If only CAN A or CAN B has been configured in the software for communications, only the corresponding pins must be connected.

For more information on CAN connection, please visit CAN - Wiring connection section of this manual.

Marning

Remember!! In **Autopilot 1x**, all GND pins are common. Note that pin 54 is not a common GND pin.

! Important

Integration is also possible by connecting CAN A of the **Autopilot 1x** to CAN B of the **CEX** and vice versa, i.e. it does not necessarily have to be CAN A-CAN A or CAN B-CAN B.


However, any connections made must be **consistent** with the **configuration** made at software level in 1x PDI Builder and CEX PDI Builder.

MC01 connection

For proper operation via **CAN**, the connection between **MC01** and **Autopilot 1x** pins should be like this:



MC01 connector pinout



Autopilot 1x harness pinout

| Autopilot 1x harness | | MC01 connector | | | |
|----------------------|--------|------------------|-----|--------|-------|
| PIN | Signal | Color code | PIN | Signal | Color |
| 25 | CANA_P | White- Black | 9 | CAN | White |
| 28 | CANB_P | Yellow- Green | 9 | (P) | winte |
| 26 | CANA_N | Brown- Black | 8 | CAN | Gray |
| 29 | CANB_N | Pink- Green | 0 | (N) | Gray |

| Autopilot 1x harness | | | MC01 connector | | |
|----------------------|--------|-----------------|----------------|--------|-------|
| PIN | Signal | Color code | PIN | Signal | Color |
| 30 | GND | Yellow- Pink | 10 | GND | Black |

(i) Note

CAN A and CAN B buses are equivalent and can be used interchangeably for the integration of this device.

For more information on CAN connection, please visit CAN - Wiring connection section of this manual.


⚠ Warning

Remember!! In **Autopilot 1x**, all GND pins are common. Note that pin 54 is not a common GND pin.


Once **MC01** has been properly wired with the **Autopilot 1x**, users can proceed to the software integration detailed in the MC01 - Integration examples section of the **1x PDI Builder** user manual.

MC24 connection

For proper operation via **CAN**, the connection between **MC24** and **Autopilot 1x** pins should be like this:



MC24 connector pinout



Autopilot 1x harness pinout

| Autopilot 1x harness | | | MC24 connector | |
|----------------------|--------|------------------|----------------|--------|
| PIN | Signal | Color code | PIN | Signal |
| 25 | CANA_P | White- Black | 5 | CANA_P |
| 26 | CANA_N | Brown- Black | 6 | CANA_N |
| 28 | CANB_P | Yellow- Green | 18 | CANB_P |
| 29 | CANB_N | Pink- Green | 7 | CANB_N |

| Autopilot 1x harness | | | | MC24 nnector |
|----------------------|--------|-----------------|-----|-----------------|
| PIN | Signal | Color code | PIN | Signal |
| 30 | GND | Yellow- Pink | 24 | CAN_GND |

(i) Note

If only CAN A or CAN B has been configured in the software for communications, only the corresponding pins must be connected.

For more information on CAN connection, please visit CAN - Wiring connection section of this manual.

△ Warning

Remember!! In **Autopilot 1x**, all GND pins are common. Note that pin 54 is not a common GND pin.


Important

Integration is also possible by connecting CAN A of the **Autopilot 1x** to CAN B of the **MC24** and vice versa, i.e. it does not necessarily have to be CAN A-CAN A or CAN B-CAN B.


However, any connections made must be **consistent** with the **configuration** made at software level. For this, refer to the MC110/MC24 - Integration examples section of the **1x PDI Builder** user manual.

MC110 connection

For proper operation via **CAN**, the connection between **MC110 hardware version 1.2** and **Autopilot 1x** pins should be like this:



MC110 1.2 harness pinout



Autopilot 1x harness pinout

| Autopilot 1x harness | | _ | MC110 arness | |
|----------------------|--------|-----------------|-----------------|--------|
| PIN | Signal | Color code | PIN | Signal |
| 25 | CANA_P | White- Black | 5 | CANA_P |
| 26 | CANA_N | Brown- Black | 6 | CANA_N |

| Autopilot 1x harness | | | | MC110 arness |
|----------------------|--------|------------------|-----|-----------------|
| PIN | Signal | Color code | PIN | Signal |
| 28 | CANB_P | Yellow- Green | 18 | CANB_P |
| 29 | CANB_N | Pink- Green | 7 | CANB_N |
| 30 | GND | Yellow- Pink | 24 | CAN_GND |

(i) Note

If only CAN A or CAN B has been configured in the software for communications, only the corresponding pins must be connected.

For more information on CAN connection, please visit CAN - Wiring connection section of this manual.

⚠ Warning


Remember!! In **Autopilot 1x**, all GND pins are common. Note that pin 54 is not a common GND pin. [!IMPORTANT] Integration is also possible by connecting CAN A of the **Autopilot 1x** to CAN B of the **MC110** and vice versa, i.e. it does not necessarily have to be CAN A-CAN A or CAN B-CAN B.

However, any connections made must be **consistent** with the **configuration** made at software level. For this, refer to the MC110/MC24 - Integration examples section of the **1x PDI Builder** user manual.


MEX connection

When communication is established between the PC and the **MEX** using the **Veronte Autopilot 1x** as a tunnel, the connection between the **MEX** and **Autopilot 1x** is via **CAN**.

The pin connection between the two devices should be like this:



MEX connector pinout



Autopilot 1x harness pinout

| Autopilot 1x harness | | | _ | MEX nector |
|----------------------|--------|-----------------|-----|---------------|
| PIN | Signal | Color code | PIN | Signal |
| 25 | CANA_P | White- Black | 22 | CAN A (P) |
| 26 | CANA_N | Brown- Black | 23 | CAN A (N) |

| Autopilot 1x harness | | | _ | ИEX nector |
|----------------------|--------|------------------|-----|---------------|
| PIN | Signal | Color code | PIN | Signal |
| 28 | CANB_P | Yellow- Green | 20 | CAN B (P) |
| 29 | CANB_N | Pink- Green | 21 | CAN B (N) |
| 30 | GND | Yellow- Pink | 24 | CAN GND |

(i) Note

If only CAN A or CAN B has been configured in the software for communications, only the corresponding pins must be connected.

For more information on CAN connection, please visit CAN - Wiring connection section of this manual.

⚠ Warning

Remember!! In **Autopilot 1x**, all GND pins are common. Note that pin 54 is not a common GND pin.

Important

Integration is also possible by connecting CAN A of the **Autopilot 1x** to CAN B of the **MEX** and vice versa, i.e. it does not necessarily have to be CAN A-CAN A or CAN B-CAN B.

However, any connections made must be **consistent** with the **configuration** made at software level in 1x PDI Builder and MEX PDI Builder.

Troubleshooting

In case of any issue with software, read the Troubleshooting section of the **1x PDI Builder** user manual.

Maintenance mode

Maintenance mode is the main recovery mode that Veronte system puts at the user disposal. The main use of **maintanance mode** is to solve issues related to the current configuration, mainly related with communication or memory writting issues.

While in **maintenance mode**, **all communications channels are enabled** by default, so it is possible to connect **Veronte Autopilot 1x** through any of its configuration interfaces, regardless of its current configuration. Thus allowing to re-establish communications with it in case they have been lost for any reason.



It is heavily recommended to always use **maintenance mode** to load a new configuration that is very different from the current one.

△ Warning

Autopilot 1x might enter in **maintenance mode** if a problem with the power supply is detected upon boot up (voltage or current is out of range).

How to enter in maintenance mode

There are two ways to enter in **maintenance mode**: by software or hardware (forcing it).

Using software to enter in maintenance mode

To enter in **maintenance mode** by software, read the Maintenance Mode - Troubleshooting section of the **1x PDI Builder** user manual.

Forcing maintenance mode

There are two ways to force the maintenance mode: using **power supply** or using the **I2C pins**.

Power supply

In order to active **maintenance mode**, power cycle the **Veronte Autopilot 1x** repetively with periods of 700 ms (with a margin range between 380 and 965 ms). After 30 cycles, the autopilot will enter in **maintenance mode**.



How to power cycle an autopilot

I2C pins

To enter in **maintenance mode** with **I2C**:

- 1. Unplug **Veronte Autopilot 1**x
- 2. Connect both I2C pins each other
- 3. Then, power up **Autopilot 1x**
- 4. Finally disconnect both pins

Both pins are I2C_CLK (number 31) and I2C_DATA (number 32) according to the pinout.


(i) Note

Dev Harness 1x 4.8 (Embention reference P007043) has already included a button with this 2 pins to easily enter maintenance mode.

The procedure is the same as for the pins, but instead of connecting and disconnecting the pins, press and release the button.


Half-duplex servo does not respond

Any servo with half duplex RS-485 should communicate with **Autopilot 1x** following the connection diagram:



Normal connection between 1x and servo

Sometimes this connection does not work, because the servo has not enough transmission power. In this case, a couple of 10 Ω resistors may solve the problem. Both resistors have to be placed at the trasmission line of the **Autopilot 1x**.



Resistors connection between 1x and servo

If the couple of resistors does not solve the issue, the user should contact the support team (create a ticket in the customer's **Joint Collaboration Framework**; for more information, see **Tickets** section of the **JCF** manual).

Hardware Changelog

Hereby are described the main differences between the latest release of the **Veronte Autopilot 1x** hardware (v **4.8**) and the previous commercial version (v **4.5**).



Specifications

| Mechanical | | |
|---------------------|--|-----------------|
| | 4.5 4.8 | |
| Mating connector | Circular mating connector with 68 pins | |
| Enclosure | Anodized aluminum | |
| Weight | 190 g 198 g | |
| Dimensions | 78 x 63 x 40 mm | 76 x 65 x 40 mm |
| Protection rating | IP67 | |
| Mounting | M4 screws | M3 screws |
| | -40 to 65 ºC | |

| Mechanical | | | | |
|--------------------------------------|------------------|---|--|--|
| | 4.5 | 4.8 | | |
| Temperature range (no convection) | | | | |
| Pressure port | 2.4 mm | SMC M5 series system. Usable with 2.5 x 4 mm polyurethane | | |
| RF connectors (LOS/BLOS/ GNSS) | SSMA jack female | | | |

| Sensors | | | |
|-----------------------------------|---|---|--|
| | 4.5 | 4.8 | |
| Number of static pressure sensors | 3 | 2 | |
| Static pressure range | 0) 0 - 103,000 Pa 1) 1,000 - 120,000 Pa 2) 30,000 - 120,000 Pa | 1) 1,000 - 120,000 Pa 2) 30,000 - 120,000 Pa | |
| Static pressure band error | 0) 1,030 Pa 1) 500 Pa 2) 200 Pa | 1) 500 Pa 2) 200 Pa | |

| Sensors | | |
|--|---|---|
| | 4.5 | 4.8 |
| Static pressure resolution | 0) 25 Pa1) 1.2 to6.5 Pa2) 0.5 Pa | 1) 1.2 to 6.5 Pa 2) 0.5 Pa |
| Number of dynamic pressure sensors | 1 | |
| Dynamic pressure range | 3 Pa (5 kt 8 km/h sea level) to 6,900 Pa (206 kt 382 km/ h sea level) | |
| Dynamic pressure band error | 0.01 % | |
| Dynamic pressure resolution | 25,5 | 500 Pa |
| Number of accelerometers (3 axis each) | 2 | 3 |
| Accelerometer range | 1) ±16 g 2) ±24 g | 1) ±16 g 2) ±24 g 3) ±8 g |
| Accelerometer max. shock | 1) 20,000 for 0.2 ms 2) 10,000 g/ms | 1) 20,000 g for 0.2 ms 2) 10,000 g/ ms |

| Sensors | | |
|--|--|--|
| | 4.5 | 4.8 |
| | | 3) 14,700 m/ s ² |
| Accelerometer sensitivity | 1) 16,393 LSB/(m/s²) 2) 10,920 LSB/(m/s²) | 1) 16,393 LSB/(m/s²) 2) 10,920 LSB/(m/s²) 3) 26,756,268 LSB/(m/s²) |
| Number of gyroscopes (3 axis each) | 2 | 3 |
| Gyroscope range | 1) 125 to 2,000 °/s 2) 125 to 2,000 °/s | 1) 125 to 2,000 °/s 2) 125 to 2,000 °/s 3) 2,000 °/s |
| Gyroscope sensitivity | 1) 228 to 14.2 LSB/º/ s 2) 262 to 16 LSB/º/s | 1) 228 to 14.2 LSB/ ⁹ /s 2) 262 to 16 LSB/ ⁹ /s 3) 655,360 to 10 LSB/ ⁹ /s |
| Number of magnetometers | 2 | 3 |
| Magnetometer range | 4 gauss 8 gauss | |

| Sensors | | | |
|--------------------------------|---|---|--|
| | 4.5 | 4.8 | |
| | | 4 gauss 8 gauss 11 gauss | |
| Magnetometer sensitivity | 1) 6,842 to 1,711 LSB/ gauss 2) 4,096 LSB/gauss | 0) 6,842 to 1,711 LSB/ gauss 1) 4,096 LSB/ gauss 2) 0.13 mgauss | |
| Number of GNSS units | 2 | | |
| GNSS constellations | BeiDou, GLONASS, GPS | BeiDou, Galileo, GLONASS, GPS/QZSS | |
| Concurrent GNSS constellations | Up to 2 | Up to 4 | |
| GNSS bands | L2OF, L2C, E1B/C, B2I, E5b, L1C/A, L1OF, B1I | | |
| Position accuracy RTK | 0.025 m + 1 ppm CEP | > 0.01 m + 1 ppm CEP | |
| Update rate | 8 Hz | up to 20 Hz | |

| I/O (on base hardware - expansion boards available) | | | |
|---|-----------------------|--|--|
| | 4.5 | 4.8 | |
| Vin | 2 | 2 x (6.5 - 36 V) DC | |
| PWM / GPIO | | Up to 16 | |
| RS232 | | 1 x | |
| RS485 | | 1 x | |
| Vout | | 5 & 3.3 V | |
| FTS | Deadman output (GPIO) | | |
| CAN bus | 2 x | | |
| ADC | | 5 x | |
| EQEP | 1 × | | |
| I2C | 1 x | | |
| UART | 1 x (FTS - SuC) | 1 x Microcontroller (i.e. external datalink) | |
| USB | 1 x | | |

Architecture and Computing Power

Veronte Autopilot 1x 4.8 and 4.5 share the same internal architecture, powered by the same dual core microprocessor from the Texas Instruments EP (Enhanced Performance) series.

Line of Sight Communications

Veronte Autopilot 1x 4.5 had the possibility to install internal datalinks from Microhard (Pico Series), available in 2.4 GHz, 900 MHz and 400 MHz. In the new version (4.8), this datalink has been replaced by a short range module for testing, configuration and telemetry download.

Embention has decided to replace the 1W Microhard datalink for the following reasons:

- As per past experience, each aircraft manufacturer has different datalink needs, so Embention has preferred that customers can have more flexibility choosing the appropriate brand, model and frequency.
- By removing the Microhard modules, there is now more space to include better sensors with extended accuracy.
- Reducing the power of the internal RF module from the autopilot permits to reduce electromagnetic interferences.
- Reducing the power consumption also reduces the heat dissipation needs on the autopilot and improves performance in warm environments.

Thus, Autopilot 1x 4.8 internal datalink has been replaced by Digi XBee® 3 PRO Zigbee 3.0, a 2.4 GHz short range module. This module has the mission to allow the integration and PDI tuning of the autopilot into the customer's platform. An external datalink (Microhard or others) can be installed in the additional UART port available in 4.8.

| Performance for Digi XBee® 3 PRO Zigbee 3.0 | | |
|---|--|--|
| Data rate | RF 250 kbps, serial up to 1 Mbps | |
| Indoor/urban range | Up to 300 ft (90 m) | |

| Performance for Digi XBee® 3 PRO Zigbee 3.0 | | |
|---|---------------------------|--|
| Outdoor/RF line-of-sight range | Up to 2 miles (3200 m) | |
| Transmit power | +19 dBm | |
| Receiver sensitivity (1% PER) | -103 dBm normal model | |

| Features | | |
|-------------------|--------------|--|
| Frequency band | ISM 2.4 GHz | |
| | DSSS (Direct | |
| Interference | Sequence | |
| immunity | Spread | |
| | Spectrum) | |
| | | |

| Networking and Security | | |
|--------------------------------|-------------------------------|--|
| Protocol | Zigbee 3.0 | |
| Encryption | 128/256 bit AES | |
| Reliable packet delivery | Retries / acknowledgements | |
| IDS | | |

| Networking and Security | | |
|-------------------------|--------------------|--|
| | PAN ID and | |
| | addresses, cluster | |
| | IDs and endpoints | |
| | (optional) | |
| Channels | 16 channels | |

New Features

One of our fundamentals at Embention is the continuous evolution of our products and services. The UAM sector is evolving everydays and new needs and technical requirements are demanded almost every week. For this reason, in order to help our customers to achieve their goals, Embention has released a new version of its hardware, with the following features.

- Enhanced sensor accuracy and reliability: Dead reckoning navigation is a critical tool for degraded GNSS scenarios, the new sensors in Veronte Autopilot 1x are significantly more accurate than previous ones.
 These enhanced sensors allows to improve the navigation estimation during the standard operation and in GNSS denied navigation.
- Improved RTK and GNSS heading: New GNSS sensors in Veronte Autopilot 1x are significantly better in various aspects (supported constellations, accuracy, number of concurrent constellations and frequency).

The positioning accuracy has improved from 0.025 m + 1 ppm to 0.01 m + 1 ppm CEP, it also improves RTK and GNSS heading estimation.

- Enhanced high-temperature hardware design and production
 materials: In order to offer the best performances in extreme scenarios
 and to pass more demanding quality and environmental tests.
 New materials are used in PCB manufacturing. These new fibers have
 better performance in heat conditions, extending the lifetime of the
 product.
- Additional failure detection means: Development of failure detection algorithms and redundant hardware.

The new PCB design includes additional signals for failure detection that can communicate each one of the autopilot cores with the arbiter. Also, the internal CAN Bus network has been modified to enhance robustness.

- Short-range 2.4 GHz LOS included in all units: Short range
 communications module included, in order to facilitate system integration.
 This module is based on Digi Xbee and permits to have an independent link
 for telemetry download and configuration.
- **BLOS module with extended coverage**: BLOS communications and UTM capabilities through a physical or eSIM card.
- Extended GNSS-denied navigation capabilities: Flexible and custom
 Kalman filters, high precision IMU sensors and several tools in order to
 build safety automations if GNSS is lost.
 Inertial navigation highly depends on the IMU accuracy, which has been
 significantly improved with the new setup.
- Internal Remote ID or ADS-B with IN/OUT: Extended collaborative sense and avoid capabilites, allowing the compliance of new FAA unmanned operation requirements.
 WIFI and Bluetooth modules have been integrated to enable Remote ID communications. This module can be replaced by a 1W ADS-B IN & OUT module if preferred.
- Embedded global DEM, geoid, magnetic and gravity fields:
 Advanced custom possibilites for the user during the map configuration, in order to carry out high-accuracy operations in the safest way possible.
 Worldwide terrain altitude and magnetic field are included in Veronte Autopilot 1x.
- Internal enclosure pressure port: A new pressure port has been included for measuring the pressure inside the autopilot.

Collaborative Sense & Avoid and UTM

Some of the most important aeronautical authorities in the world have been very clear about the future lines in the certification process: all aircraft have to have collaborative detection capabilities. For example, the American FAA has expressed in several documents that a Remote ID system for drone

identification and detection for smaller drones. For larger drones, it is expected that the ADS-B technology will prevail.

Remote ID

Remote ID is a young technology based on personal area networks (Bluetooth) and local area networks (WiFi). The system is emitting a constant signal with the ID of the drone and its positioning at each moment. Users can see the track of the operation and customers have the ability to configure the information shown.

| Frequency | WiFi & Bluetooth bands |
|------------------------|---|
| Developed according to | RIN 2120-AL31 Remote identification of Unmanned Aircraft FAA Standard |
| Parameters | Aircraft ID, position, altitude and time mark |
| Compatibility | FAA Remote ID Scanner App |

To comply with the final rule of Remote Identification of Unmanned Aircraft (Part 89), manufacturers need to produce standard Remote ID drones and meet the requirements of this rule by September 16th, 2022.

Embention's Remote ID is being adapted in order to be in complicance with Active Standard ASTM F3411 requirements, developed by subcommittee F38.02.


ADS-B

Internal ADS-B with IN & OUT capabilities is another option in order to reach the collaborative detection capabilities and to enhance the fleet management performance.

| Frequency band | 1090 MHz |
|---------------------|---|
| Current consumption | Averaged 140 mA |
| Sensitivity | -80 dBm |
| RF output power | Configurable + 30 dBm (1W), + 27 dBm (0.5 W), + 24 dBm (0.25 W) |
| ESD protection | All lines protected |
| MAVIink (baud) | 115200 bps |
| AERO (baud) | 115200 bps (AT commands) |

Pinout changes from Autopilot 1x 4.5

The pinout for 4.5 and 4.8 versions are very similar, but they have several differences. To prevent any confusion, the following table shows the pinout for both versions. The different pins are marked with Λ , all the rest have the same function.



68 pin connector for both versions

| PIN | Signal | Туре | Description |
|-----|--------|------|--|
| 1 | 1/00 | I/O | PWM / Digital I/O signal (0-3.3V). Protected against ESD and short circuit |
| 2 | I/O1 | I/O | PWM / Digital I/O signal (0-3.3V). Protected against ESD and short circuit |
| 3 | I/O2 | I/O | PWM / Digital I/O signal (0-3.3V). Protected against ESD and short circuit |
| 4 | I/O3 | I/O | PWM / Digital I/O signal (0-3.3V). Protected against |

| PIN | Signal | Туре | Description |
|-----|--------|--------|--|
| | | | ESD and short circuit |
| 5 | 1/04 | I/O | PWM / Digital I/O signal (0-3.3V). Protected against ESD and short circuit |
| 6 | I/O5 | I/O | PWM / Digital I/O signal (0-3.3V). Protected against ESD and short circuit |
| 7 | 1/06 | I/O | PWM / Digital I/O signal (0-3.3V). Protected against ESD and short circuit |
| 8 | I/O7 | I/O | PWM / Digital I/O signal (0-3.3V). Protected against ESD and short circuit |
| 9 | GND | GROUND | Ground signal for actuators 1-8 |
| 10 | I/O8 | I/O | PWM / Digital I/O signal (0-3.3V). Protected against |

| PIN | Signal | Туре | Description |
|-----|--------|------|--|
| | | | ESD and short circuit |
| 11 | 1/09 | I/O | PWM / Digital I/O signal (0-3.3V). Protected against ESD and short circuit |
| 12 | I/O10 | I/O | PWM / Digital I/O signal (0-3.3V). Protected against ESD and short circuit |
| 13 | I/O11 | I/O | PWM / Digital I/O signal (0-3.3V). Protected against ESD and short circuit |
| 14 | I/O12 | I/O | PWM / Digital I/O signal (0-3.3V). Protected against ESD and short circuit |
| 15 | I/O13 | I/O | PWM / Digital I/O signal (0-3.3V). Protected against ESD and short circuit |
| 16 | I/O14 | I/O | PWM / Digital I/O signal (0-3.3V). |

| PIN | Signal | Туре | Description |
|-----|-----------|-----------------|--|
| | | | Protected against ESD and short circuit |
| 17 | I/O15 | I/O | PWM / Digital I/O signal (0-3.3V). Protected against ESD and short circuit |
| 18 | GND | GROUND | Ground signal for actuators 9-16 |
| 19 | RS 232 TX | Output | RS 232 Output (-13.2V to 13.2V Max, -5.4V to 5.4V Typical). Protected against ESD and short circuit |
| 20 | RS 232 RX | Input | RS 232 Input (-25V to 25V Max, -0.6V Low and 2.4V High Threshold). Protected against ESD and short circuit |
| 21 | GND | GROUND | Ground signal for buses |
| 22 | ANALOG_3 | Input Analog | Input 0-3.3V. Protected against |

| PIN | Signal | Туре | Description |
|----------|-------------|-----------------|--|
| | | | ESD and short circuit |
| 23 | ANALOG_4 | Input Analog | Input 0-3.3V. Protected against ESD and short circuit |
| 24 | GND | GROUND | Ground signal for buses |
| 25 | CANA_P | I/O | CANbus interface, up to 1Mbps (2.3V Typical, 1.2V-2.3V Differential). Protected against ESD |
| 26 | CANA_N | I/O | Twisted pair with a 120 ohms Zo recommended (2.3V Typical, 1.2V-2.3V Differential). Protected against ESD |
| 27 | 4.5: GND | 4.5: GROUND | 4.5: Ground signal for buses |
| <u> </u> | 4.8: 4XV_WD | 4.8: I/O | 4.8: Reserved. Do not connect |
| 28 | CANB_P | I/O | CANbus interface. It supports data |

| PIN | Signal | Туре | Description |
|-----|----------|--------|---|
| | | | rates up to 1 Mbps. Protected against ESD |
| 29 | CANB_N | I/O | Twisted pair with a 120 ohms Zo recommended. Protected against ESD |
| 30 | GND | GROUND | Ground signal for buses |
| 31 | I2C_CLK | Output | Clk line for I2C bus (0.3V to 3.3V). Protected against ESD and short circuit |
| 32 | I2C_DATA | I/O | Data line for I2C bus (0.3V to 3.3V). Protected against ESD and short circuit |
| 33 | GND | GROUND | Ground for 3.3V power supply |
| 34 | 3.3V | POWER | 3.3V - 100mA power supply. Protected against ESD short circuit with 100mA resettable fuse |

| PIN | Signal | Туре | Description |
|----------|------------|----------------|--|
| 35 | GND | GROUND | Ground for 5V power supply |
| 36 | 5V | POWER | 5V - 100mA power supply. Protected against ESD short circuit with 100mA resettable fuse |
| 37 | GND | GROUND | Ground for analog signals |
| 38 | ANALOG_0 | Input | Analog input 0-3.3V. Protected against ESD and short circuit |
| 39 | ANALOG_1 | Input | Analog input 0-3.3V. Protected against ESD and short circuit |
| 40 | ANALOG_2 | Input | Analog input 0-3.3V. Protected against ESD and short circuit |
| 41 | 4.5: GND | 4.5: GROUND | 4.5: Ground for FTS signals |
| <u> </u> | 4.8: 4XV_A | 4.8: 1/0 | 4.8: Reserved. Do not connect |

| PIN | Signal | Туре | Description |
|------------------|---------------|----------------|--|
| 42 | FTS1_OUT | Output | Deadman signal from comicro. Protected against ESD and short circuit |
| 43 | FTS2_OUT | Output | !SystemOK Bit. Protected against ESD and short circuit |
| 44 | 4.5: GND | 4.5: GROUND | 4.5: Ground signal for safety buses |
| <u> </u> | 4.8: 4XV_B | 4.8: I/O | 4.8: Reserved. Do not connect |
| 45 <u>(</u>) | 4.5: V_ARB_TX | 4.5: Output | 4.5: Veronte comicro UART output to activate safety mechanism. Protected against ESD and short circuit |
| | 4.8: UARTA_TX | 4.8: Output | 4.8: Microcontroller UART |
| 46 | 4.5: V_ARB_RX | 4.5: Input | 4.5: Veronte comicro UART output to activate |

| PIN | Signal | Туре | Description |
|-----|---------------|---------------|--|
| | | | safety mechanism. Protected against ESD and short circuit |
| | 4.8: UARTA_RX | 4.8: Input | 4.8: Microcontroller UART |
| 47 | GND | GROUND | Ground signal comicro power supply |
| 48 | V_ARB_VCC | POWER | Veronte comicro power (6.5V to 36V). Protected against ESD and reverse polarity |
| 49 | FTS3_OUT_MPU | Output | MPU alive voting signal, to use with 4xVeronte. It is a Square Wave at [100,125] Hz. Protected against ESD and short circuit |
| 50 | OUT_RS485_P | Output | Non-inverted output from RS485 bus (-7V to 12V Max, -2.3V to 2.3V Typical). Protected against |

| PIN | Signal | Туре | Description |
|-----|-------------|--------|--|
| | | | ESD and short circuit |
| 51 | OUT_RS485_N | Output | Inverted output from RS485 bus (-7V to 12V Max, -2.3V to 2.3V Typical). Protected against ESD and short circuit |
| 52 | IN_RS485_N | Input | Inverted input from RS485 bus (-7V to 12V Max, -2.3V to 2.3V Typical). Protected against ESD and short circuit |
| 53 | IN_RS485_P | Input | Non-inverted input from RS485 bus (-7V to 12V Max, -2.3V to 2.3V Typical). Protected against ESD and short circuit |
| 54 | OUT_GND | GND | Ground for RS-485 bus Warning This is not a common GND pin. |

| PIN | Signal | Туре | Description |
|-----|---------------------|------|---|
| 55 | EQEP_A | I/O | DIGITAL output / DIGITAL input / Encoder quadrature input A (0-3.3V). Protected against ESD and short circuit |
| 56 | EQEP_B | | DIGITAL output / DIGITAL input / Encoder quadrature input B (0-3.3V). Protected against ESD and short circuit |
| 30 | ГÓГЬ ⁻ Р | I/O | Warning Only use it as digital I/O with Veronte units of Hardware version 4.5 or lower. |
| 57 | EQEP_S | I/O | DIGITAL output / DIGITAL input / Encoder strobe input (0-3.3V). Protected against ESD and short circuit |

| PIN | Signal | Туре | Description |
|----------------|------------------------|----------------|---|
| 58 | EQEP_I | I/O | DIGITAL output / DIGITAL input / Encoder index input A (0-3.3V). Protected against ESD and short circuit |
| 59 | GND | GROUND | Ground for encoders |
| 60 | V_USB_DP | I/O | Veronte USB data line. Protected against ESD |
| 61 | V_USB_DN | I/O | Veronte USB data line. Protected against ESD |
| 62 <u>^</u> | 4.5: V_USB_ID | 4.5: 1/0 | 4.5: Veronte USB ID line. Protected against ESD and short circuit |
| | 4.8: USB_SHIELD_GND | 4.8: GROUND | 4.8: USB cable shielding |
| 63 | FTS_OUT_MPU | Output | Abort mission voting signal from MPU, to use with 4xVeronte. Bit Low (0V) if mission OK. High (3.3V) if mission |

| PIN | Signal | Туре | Description |
|-----|--------------|--------|---|
| | | | wants to be terminated. Protected against ESD and short circuit |
| 64 | FTS2_OUT_MPU | Output | Abort mission voting signal 2 from MPU, to use with 4xVeronte. Bit Low (0V) if mission OK. High (3.3V) if mission wants to be terminated. Protected against ESD and short circuit |
| 65 | GND | GROUND | Veronte ground input |
| 66 | GND | GROUND | Veronte ground input |
| 67 | VCC | POWER | Veronte power |
| | | | supply (6.5V to 36V). Protected against ESD and reverse polarity. |
| | | | Warning Both pins are common. They MUST be |

| PIN | Signal | Туре | Description |
|-----|--------|-------|---|
| 68 | VCC | POWER | connected to the same power supply. |

⚠ Warning

Remember!! All GND pins are common. Note that pin 54 is not a common GND pin.

Acronyms and Definitions

Acronyms

| Acronym | Description |
|---------|--|
| 16 VAR | 16 Bits variables (Integers) |
| 32 VAR | 32 Bits variables (Reals) |
| ADC | Analog to Digital Converter |
| ADSB | Automatic Dependent Surveillance- Broadcast |
| AGL | Above Ground Level |
| AoA | Angle of Attack |
| ARC | Arcade Mode |
| AUTO | Automatic Mode |
| BIT | Bit Variables |
| BLOS | Beyond Line Of Sight |
| CAN | Controller Area Network |
| CAP | Capture Module |

| Acronym | Description |
|---------|--|
| СЕР | Circular Error Probability |
| СМВ | Climb Phase |
| CRU | Cruise Phase |
| DAA | Detect And Avoid |
| DC | Direct Current |
| DGPS | Differential GPS |
| ECAP | Enhanced CAP |
| ECEF | Earth Centered - Earth Fixed |
| EGNOS | European Geostationary Navigation Overlay Service |
| (E)GPRS | Enhanced Data Rates for GSM Evolution |
| EKF | Extended Kalman Filter |
| EQEP | Enhanced Quadrature Encoder Pulse |
| ESC | |

| Acronym | Description |
|---------|--|
| | Electronic Speed Controller |
| eVTOL | Electric Vertical Take Off and Landing |
| FCS | Flight Control System |
| FHSS | Frequency Hopping Spread Spectrum |
| FLR | Flare Phase |
| FTS | Flight Termination System |
| GIS | Geographical Information System |
| GND | Ground |
| GNSS | Global Navigation Satellite Systems |
| GPIO | General Purpose Input Output |
| GPS | Global Positioning System |
| GS | Ground Speed |
| GS | Ground Segment |
| GSM | |

| Acronym | Description |
|---------|-----------------------------------|
| | Global System for Mobile |
| | Communications |
| HLD | Hold Phase |
| HSPA+ | High Speed Packet Access Plus |
| HUM | Hardware User Manual |
| I2C | Inter-Integrated Circuit |
| IAS | Indicated Air Speed |
| ID | Identification |
| Int. D. | Internal Diameter |
| IMU | Inertial Measurement Unit |
| ISM | Industrial Scientific and Medical |
| LED | Light-Emitting Diode |
| LND | Landing Phase |
| LOS | Line Of Sight |
| M2M | Machine To Machine |
| MSL | Mean Sea Level |

| Acronym | Description |
|---------|--|
| OPV | Optionally Piloted Vehicle |
| Out. D. | Outer Diameter |
| PCS | Pole Control Station |
| PFD | Primary Flight Display |
| PID | Proportional Integral Derivative |
| PPM | Pulse Position Modulation |
| PWM | Pulse Width Modulation |
| QNH | Barometric atmospheric pressure adjusted to sea level |
| QZSS | Quasi-Zenith Satellite System |
| RC | Radio Control Mode |
| RF | Radio Frequency |
| RPAS | Remotely Piloted Aircraft System |
| RPM | |

| Acronym | Description |
|---------|---|
| | Revolutions Per Minute |
| RS 232 | Recommended Standard 232 |
| RS 485 | Recommended Standard 485 |
| RX | Reception |
| SMA | SubMiniature Version A Connector |
| SSMA | Miniature-SMA |
| STB | Standby Phase |
| SU | Servo-Output matrix |
| TAS | True Air Speed |
| TKO | Take Off Phase |
| TX | Transmission |
| UART | Universal asynchronous receiver-transmitter |
| UAS | Unmanned Aerial System |
| UAV | Unmanned Aerial Vehicle |

| Acronym | Description |
|---------|--|
| UMTS | Universal Mobile Telecommunications System |
| US | Output-Servo matrix |
| VTOL | Vertical Take Off and Landing |
| WGS 84 | World Geodetic System 84 |
| WP | Waypoint |

Definitions

- **Control Phase:** The operation is divided into phases in which the UAV has a specific performance. Each of this phases is called a control phase.
- **Control Channel:** It is each of the signals used to control a behaviour or action.
- **Control Mode:** It is possible to make a manual control of the UAV by stick, assisted control and fully automatic control.
- **Actuator:** It is a mechanic device to provide force to move or "act" another mechanical device.

Contact Data

For support-related inquiries, customers have access to a dedicated portal through the Joint Collaboration Framework. This platform facilitates communication and ensures traceability of all support requests, helping us to address your needs efficiently.

For other questions or general inquiries, you can reach us via email at sales@embention.com or by phone at (+34) 965 115 421