
Veronte Link

Release 7/1.1

Embention Sistemas Inteligentes, S.A.

2026-08-03

Contents

Scope of Changes	3
Quick Start	4
System Requirements	4
Software Requirements	4
Download and Installation.....	5
Firewall Configuration.....	5
Additional apps.....	6
Veronte Telemetry UDP	6
Download and Installation.....	6
Configuration	6
1x PDI Builder	6
Veronte Telemetry UDP.....	6
Index-Unit correspondence table.....	19
Operation	25
Sending UDP messages	25
Veronte Telemetry CSV.....	28
Download and Installation.....	6
Operation	25
Operation	30
Connections	35
Sessions	42
Cloud connection	46
Integration examples.....	50
Serial connection.....	50
UDP connection.....	53
TCP-SERVER connection	57
TCP-CLIENT connection	59
Troubleshooting	62
Comm Port error in Windows Device Manager	62
Error when replaying a session	64
Viewing UDP data.....	65
Software Changelog	66
7.8.16.....	66

Scope of Changes

- Version 1.0
 - Added:
 - First version issued
- Version 1.1
 - Added:
 - **Local (Default)** explanation in [Connections](#)

Quick Start

Veronte Link establishes **communication between a computer and any Veronte product** by creating a **VCP bridge**. It allows to use multiple control stations and autopilots to be interconnected, operating simultaneously.

Veronte Link also includes a **post-flight viewer**, to reproduce all recorded data from previous flights and generate plots and reports.

System Requirements

Before executing this software, users should check the following sections with the minimum and recommended PC hardware requirements.

Minimum requirements

- CPU: Intel Core i5-8365UE
- RAM: 8 GB DDR4
- STO: 256 GB SSD

Recommended requirements

- CPU: 12th Gen Intel(R) Core(TM) i7-12700H 14 cores up to 4,70 GHz
- RAM: 32,0 GB
- STO: 1TB SSD M.2 NVMe PCIe

Software Requirements

Compatible browsers

The following are the functional and optional browsers for used with **Veronte Link** software:

- **Functional:** Chrome
- **Optional:** Firefox, Edge

Window Size In order for the application and all its features to display correctly, check the following minimum and maximum sizes for the application window: - **Minimum:** 1024x768 - **Maximum:** No limit

Operating System - Recommended: Windows 11

Download and Installation

Veronte Link software is available in the **Veronte Toolbox** platform. From there, users can download and install the application. For more information, please refer to the [Veronte Toolbox](#) user manual.

A **personal account** is required to access **Veronte Toolbox**; create a [Ticket](#) in the user's **Joint Collaboration Framework** and the support team will create it for you.

Firewall Configuration

Users must enable **HTTP port 9535** and **TCP ports 8051 and 9991** in the firewall to ensure the correct operation of **Veronte Link**.

Note

This configuration might need to be performed by the cybersecurity manager of your company.

Additional apps

Veronte Telemetry UDP



Veronte Telemetry UDP

Veronte Telemetry UDP is an additional command-line tool which allows **Veronte Link** to send Autopilot 1x telemetry over UDP.

Download and Installation

Veronte Telemetry UDP software is available in the **Veronte Toolbox** platform. From there, users can download and install the application. For more information, please refer to the [Veronte Toolbox](#) user manual.

A **personal account** is required to access **Veronte Toolbox**; create a [Ticket](#) in the user's **Joint Collaboration Framework** and the support team will create it for you.

Configuration

The following sections detail the steps to **configure** the Veronte system to transmit telemetry UDP messages through **Veronte Telemetry UDP**, after it is installed.


1x PDI Builder

First, in **1x PDI Builder**, the intended variables to send must be added to the corresponding telemetry vector.

To do this:

1. Go to Telemetry menu → **Telemetry panel**.

2. By clicking the corresponding **+** button, add the desired telemetry variables to one of the telemetry vectors Data to VApp.



Add variables


Note

For further information about this Telemetry menu, please refer to the [Telemetry](#) section of **1x PDI Builder** user manual.

3. Configure the Data to VApp vector where the variables have been added as follows:
 - **Frequency:** Desired frequency of data transmission
 - **Address:** App 2 (Veronte apps address)

Note

Hash parameter is not configurable, it is automatically calculated by the system based on the telemetry vector configured by the user. It is a hexadecimal representation of the CRC of the fieldset.



Data vector parameters

4. Save the changes by clicking  button.

Veronte Telemetry UDP


Veronte Telemetry UDP has a configuration file (`tudp.config`) where users must specify which telemetry variables to send. Once the app is installed, this file can be found in `C:/Users/user/AppData/Roaming/VeronteUDPTelemetryCli` :



Configuration file

⚠ Caution

- On Windows, the AppData folder is hidden by default, if it is not visible in `C:\Users\user`, users can "show" it by checking the "Hidden Items" checkbox:



Windows File Explorer

- The `tudp.config` file is automatically generated by the application. It will only appear in the folder after you have run Veronte Telemetry UDP at least once.

This configuration file consists of 3 parts:

- `&HEAD hex`. This establishes the header of the UDP messages sent.
- `&LVARs ... END_LVARs`. Defines the **LVARs**, which are complex variables defined by the user, as expressions in which autopilot variables may or may not be used. Each new line between `&LVARs` and `END_LVARs` is a **LVAR**. LVARs can be boolean or number type.

Each LVAR has the following structure: `L[id] = [default value] = [expression]`

- **id**: It is any integer to identify the LVAR and is used in the entries to indicate the LVAR to send.
- **default value**: The default value is the initial value that the LVAR will have the first time it is set.
- **expression**: For each UDP packet sent, the LVAR values are updated with the result by evaluating the expression.

Example

```
L40 = false = (u1599_RVAR_1021 > (0.5)) && (u1599_BIT_1053 > (0))
```

LVAR L40, initialized as **false**, and for each UDP packet sent, the LVAR value is updated with the result of the expression `(u1599_RVAR_1021 > (0.5)) && (u1599_BIT_1053 > (0))`.

Where, `u1599_RVAR_1021` refers to RVAR 1021 of the autopilot with address 1599, and `u1599_BIT_1053` refers to BIT 1053 of the same autopilot.

- **Offsets/Entries**. This is the information that is sent via UDP for each telemetry variable.

Users must fill in for each entry (except bits) the following fields of the table in **this order**:

1. **MULT** (float): Scaling factor by which the variable obtained from the autopilot is multiplied.

Note

Only used for the following **VVARs** (VERVARs): `L_EQ`, `RVAR`, `UVAR`, `CUSTOM` and `LVAR`.

This field does not affect the bits, but must be set nonetheless.

2. **OFFSET** (float): Offset factor to be added to the variable value obtained from the autopilot, before being multiplied by the **MULT** value.

Note

This field does not affect the bits, but must be set nonetheless.

3. **TVAR**: Type of variable representing the value sent via UDP. It can be:

Important

The variables configured in the `tudp.config` file must match the previous configuration from [1x PDI Builder configuration](#) section of this manual, so each variable is parsed according to the organization of the bits.

- **byte**: Unsigned byte (0 to 255)
- **bit**: A desired number of bits
- **UInt16**: Unsigned 16-bit integer (0 to 65.536)
- **Int16**: Signed 16-bit integer (-32.768 to 32.768)
- **UInt32**: Unsigned 32-bit integer (-2.147.483.648 to 2.147.483.648)
- **Int32**: Signed 32-bit integer (0 to 4.294.967.295)
- **Float**: 32 bit single-precision floating-point ($3.4028237 \cdot 10^{38}$ to $1.175494 \cdot 10^{-38}$)

Note

Unlike the other TVARs, **bits** allows users to define several variables that are packed as only one within the UDP message. To do this, each new line is a variable that is included in the bits entry, until the `&END_BIT` line is read.

4. **UAV** (int): Serial Number of the Autopilot 1x where the variables **come from**.

Note

UAV address does not matter for LVARs, since it is either already indicated in the LVAR expression or it is a value that does not come from any autopilot.

5. **VERVAR/VVAR**: Type of variable in Veronte system.

- **RVAR**: Real variables obtained **directly from the autopilot**
- **UVAR**: Integer variables obtained **directly from the autopilot**
- **BIT**: Bit variables obtained **directly from the autopilot**
- **CUSTOM**
- **NONE**: Equivalent to 0

- **L_EQ**: Linear equation. Similar to TVAR bits, it allows defining several variables in a single entry.

The resulting value of this type of entry is the addition of all the consequent variables, multiplied by COEFFICIENT, to which the unit conversion (UNIT), addition (OFFSET) and multiplication (MULT) are finally applied.

The linear equation continues to wait for more variables until the `&END_L_EQ` line is read.

 Note

As implemented, there is no use for the ID field when defining an L_EQ, since the IDs used are those of the following lines.

- **LVAR**: It must be previously defined as explained above.
6. **ID** (int): Identifier of the variable in Veronte. Refer to the [Lists of Variables - Lists of interest](#) section of **1x Software Manual** for Index-Variable correspondence or check it on the [Variables panel of the UI menu](#) of **1x PDI Builder** app.
 7. **UNIT** (int): Index of the unit of measurement of the variable in case a conversion has to be made.
Please, see the [Index-Unit correspondence table](#) for detailed information.
 8. **LIMITS** (optional) (Only for BITs): It is optional and its format is `[min&max]`, both are of float type.
 9. **COEFFICIENT** (Only for L_EQ): It is a coefficient of the linear equation.

Below are several examples of the configuration file depending on the type of variable to be sent.

- **RVARs**. Example with Relative Timestamp, Longitude and Latitude variables:

```
#HEAD HEX
&HEAD 0AA0

#MULT      OFFSET      TVAR          UAV          VERVER      ID      UNIT
1000       0           UInt32       1599         RVAR        300     NONE
1          0           Float       1599         RVAR        500     NONE
1          0           Float       1599         RVAR        501
NONE

# First row: Send Time Since Hardware Start-Up (Milliseconds) as an UInt32
(4 bytes)
# Second row: Send Longitude as a Float (4 bytes)
# Third row: Send Latitude as a Float (4 bytes)
```

• **LVARs:**

```

#HEAD HEX
&HEAD    1FB9

&LVARS
L1 = 0 = L1 + 1
L70 = 20 = L70 + L1
L45 = false = L70 % 2 == 0
L80 = false = (u1599_RVAR_1021 > (0.5)) && (u1599_BIT_1053 > (0))
&END_LVARS

# L80 initially has a value of false. Next values are obtained from the
expression
# (u1599_RVAR_1021 > (0.5)) && (u1599_BIT_1053 > (0))
# u1599_RVAR_1021 = value of RVAR 1021 (stky21, Stick Input y21)
# from autopilot with address 1599.
# The value of this variable is also updated every time

# Use of Lvars
#MULT      OFFSET      TVAR          UAV          VERVAR      ID      UNIT
1           0           Int16         0000         LVAR         1      NONE
1           0           Float         0000         LVAR         70     NONE
1           0           byte         0000         LVAR         45     NONE

# UAV address does not matter for these LVARs since they do not come from an
autopilot.

# First row: Send L1 as an Int16 (2 bytes)
# Second row: Send L70 as a Float (4 bytes)
# Third row: Send L45 as a byte (1 byte)

```


- **BITs:**

```
#HEAD HEX
&HEAD 0AA0

#MULT      OFFSET      TVAR      UAV      VERVER      ID      UNIT
1          0           bits
#UAV      VERVER      ID      UNIT      LIMITS(optional)
1599      RVAR      501      NONE
1599      RVAR      500      NONE      [-1000&1000]
&END_BIT

# Mult and Offset do not affect bits, but they must be set regardless.
# Any int value is valid and acts the same.
```

- **BITs with LVARs.** Taking the LVARs defined in the previous example:




```

#HEAD HEX
&HEAD    1FB9

#Definition of LVARs
&LVARs
L1 = 0 = L1 + 1
L70 = 20 = L70 + L1
L45 = false = L70 % 2 == 0
&END_LVARs

#Bits example with lvars
#MULT      OFFSET      TVAR      UAV      VERVER      ID      UNIT
1          0           bits
#UAV      VERVER      ID      UNIT      LIMITS(optional)
0000      LVAR       1       NONE      [0&10]
0000      LVAR       70      NONE      [100&500]
0000      LVAR       45      NONE
&END_BIT

# Mult and Offset do not affect bits, but they must be set regardless.
# Any int value is valid and acts the same.

# In this example, each one of the variables occupies one bit in the
resulting message.
# L1, which is incremented by one, is checked if it is within the set limit
0&10,
# i.e., for values strictly greater than 0 and strictly less than 10,
# the bit will be 1, and for all other values, it will be 0.

# The same applies to L70, when 100<L70>500, the bit is 1, and for the rest
it is 0.

# L45 on the other hand doesn't have a limit.
# When no limit is established, it compares it to 1.
# Since L45 is a boolean that checks that L70 is even,
# the bit will be one when the value is 1, and 0 when not.

# Concrete example: L1 = 16, L70 = 156, L45 = true (because L70 is even)
# The UDP packet will be:
# HEADER: 31 -71
# L1: 16 0
# L70: 0 0 28 67
# L45: 1
# bits: 6 = bits[1 1 0] because:
# L1 is not in the limits (0), L70 is (middle 1), and L45 is 1/true (left
1).

```

The order is from least to most significant in the order indicated in the bits list.

- **L_EQ:**

```
#HEAD HEX
&HEAD 0AA0

#MULT      OFFSET      TVAR      UAV      VERVER      ID      UNIT
1          0          Int16      0000      L_EQ      NONE    NONE
#UAV      VERVER      ID      UNIT      COEFFICIENT
1001      RVAR      1      NONE      2.3
1001      UVAR      1      NONE      2.3
&END_L_EQ

# LINEAR EQUATION:
# ((COEFFICIENT*RVAR(1) + COEFFICIENT*UVAR(1)) + Offset) * Mult
# ((2.3*RVAR(1) + 2.3*UVAR(1)) + 0) * 1
```

- **L_EQ with LVARs.** Taking the LVARs defined in the previous example:

```
#HEAD HEX
&HEAD 1FB9

#Definition of LVARs
&LVARs
L1 = 0 = L1 + 1
L70 = 20 = L70 + L1
&END_LVARs

#Linear equation example with lvars
#MULT      OFFSET      TVAR      UAV      VERVER      ID      UNIT
2          13          Float      0000      L_EQ      0      NONE
#UAV      VERVER      ID      UNIT      COEFFICIENT
0000      LVAR      1      NONE      50
0000      LVAR      70      NONE      25
&END_L_EQ

# Concrete example: L1 = 1, L70 = 21
# ((50*L1 + 25*L70) + Offset) * Mult = ((50*1 + 25*21) + 13) * 2 = 1176
# Sent as a Float, therefore in the udp packet it will be:
# 1176 = [0 0 -109 68]
```

Index-Unit correspondence table

Unit ID	Unit
0	m/s
1	kt
2	km/h
3	mph
4	ft/s
121	ft/m
321	mm/s
5	m

Unit ID	Unit
6	km
62	mm
63	cm
7	mi
8	NM
9	yd
10	ft
11	in
12	m/s ²
13	ft/s ²
14	in/s ²
15	g (gravity)
202	rad
16	rad [$-\pi$, π]
203	rad [0, 2π]
205	°
17	° [-180,180]
101	° [0,360]
102	° ' ''
103	° ' '' (N/S)

Unit ID	Unit
104	° ' " (E/W)
21	T
160	nT
23	G
22	mG
24	V
25	mV
26	A
27	mA
340	kA
28	Pa
29	kPa
30	bar
31	mbar
32	psi
33	mmHg
34	at
35	atm
147	Pa ²
36	K

Unit ID	Unit
37	°C
38	°F
39	s
120	Time
40	min
41	h
330	ns
108	μ s
109	ms
42	rad/s
117	°/s
43	rad/min
44	rad/h
45	rpm
46	rps
47	rph
57	m³/s
58	gal/s
54	gal/h
59	l/s

Unit ID	Unit
55	l/h
56	--
60	x1
64	%
61	pkts/s
105	Hz
106	mHz
107	kHz
140	Bd
141	kBd
142	MBd
110	m ²
111	cm ²
112	mm ²
113	km ²
114	mile ²
115	ft ²
116	yd ²
118	bit
119	byte

Unit ID	Unit
131	KB
132	GB
122	kg
123	g
124	tonnes
125	lbs
126	oz
127	N
128	kN
129	lbf
130	pdl
134	rad/s ²
135	rad/min ²
136	rad/h ²
137	°/s ²
138	°/m ²
139	°/h ²
329	rpm/s
143	T ²
144	(m/s) ²

Unit ID	Unit
145	(cm/s) ²
146	(mm/s) ²
327	Ω
328	Henrios
322	watios
323	kW
324	Kgm/s
325	erg/s
326	cv
331	m ³
332	dm ³
333	mm ³
334	L
335	mL

Operation

This section details the steps to **transmit telemetry UDP messages** through **Veronte Telemetry UDP**.

Sending UDP messages

Veronte Telemetry UDP connects to **Veronte Link** to send the previously configured Autopilot 1x telemetry via UDP messages. For this reason, the connection between the autopilot and **Veronte Link** must be properly established, and **Veronte Link** needs to be opened.

Note

For more information about this connection, please refer to [Connection - Operation](#) section of this manual.

These are the options to send the configured variables:


1. Launching **Veronte Telemetry UDP** by double-clicking on the App shortcut or the `.exe` file:

**Veronte Telemetry UDP shortcut**

This will send the UDP messages with the following default configuration:

- **Host url:** 127.0.0.1
 - **UDP port:** 3000
 - **Frequency:** 10 Hz
2. Launching **Veronte Telemetry UDP** `.exe` from terminal, where it is possible to specify the parameters of the trasmission using the following command-line options:
 - **- u:** UDP address
 - **- p:** UDP port
 - **- f:** Desired frequency of data transmission (Hz)

This is an example:

A screenshot of a Windows Command Prompt window. The title bar reads 'C:\Windows\System32\cmd.exe'. The command prompt shows the directory 'C:\Program Files\Embention\veronte-udp-telemetry' and the command 'start veronte-udp-telemetry-7.6.exe -u 192.158.1.38 -p 3001 -f 1' being entered. The rest of the terminal area is black.


Launching from terminal example

Note

These installation files location will vary depending on the location selected during installation.

Note that **Veronte Telemetry UDP Installer** `.exe` is not the **Veronte Telemetry UDP** `.exe` to launch.

The expected outcome is the following:



```
veronte-udp-telemetry-7.6 X + v
2026-01-12 11:38:04 [INFO] Starting Veronte-UDP-Telemetry RUNNABLE
2026-01-12 11:38:04 [INFO] Trying to connect with vlink...
2026-01-12 11:38:05 [INFO] Client deployed and connected to vlink.
2026-01-12 11:38:05 [INFO] UAVINI# 1x v4.8 4041 (7.6) ADD
```

Expected outcome

Note

Veronte Telemetry UDP always adds the matcher 0x0A 0xA0 at the beginning of each sent UDP packet before the variable data.

Therefore the received UDP packet will be: 0x0A 0xA0 followed by the consecutive stream of data in the order and byte width configured in `tudp.config`.

If users have any doubts about the UDP packets that are generated, please refer to [Viewing UDP data - Troubleshooting](#) section of this manual.

Veronte Telemetry CSV



Veronte Telemetry CSV

Veronte Telemetry CSV is an additional command-line tool that processes Veronte Link sessions to export recorded telemetry data into CSV files.

Download and Installation

Veronte Telemetry CSV software is available in the **Veronte Toolbox** platform. From there, users can download and install the application. For more information, please refer to the [Veronte Toolbox](#) user manual.

A **personal account** is required to access **Veronte Toolbox**; create a [Ticket](#) in the user's **Joint Collaboration Framework** and the support team will create it for you.

Operation

This section details how to convert recorded session into CSV files.

To properly operate the program, launch **Veronte Telemetry CSV** `.exe` from terminal with the following required parameters:


- **-i**: Path to the session folder that users want to convert.

Note

- Remember that the folder containing the session files is located in the following path `C:\Users\USER\NAME\AppData\Roaming\VeronteLink\sessions`
- These session files are grouped by autopilot UUID and inside they are generated with the date and time.

- **-o**: Path where session files will be stored in CSV format.

This is an example:

A screenshot of a Windows PowerShell terminal window. The title bar reads "Windows PowerShell". The command prompt shows the following command: `C:\Users\user\AppData\Local\Embention\postflight-cli\7.6 > "Veronte Telemetry CSV-7.6" i- C:\Users\user\AppData\Roaming\VeronteLink\sessions\4096\4096_2026.01.09.18.33.01 -o C:\Users\user\Desktop\sessions_csv`. The rest of the terminal window is black and empty.

```
Windows PowerShell
C:\Users\user\AppData\Local\Embention\postflight-cli\7.6 > "Veronte Telemetry CSV-7.6" i- C:\Users\user\AppData\Roaming\VeronteLink\sessions\4096\4096_2026.01.09.18.33.01 -o C:\Users\user\Desktop\sessions_csv
```

Operation

In order to establish a connection between a Veronte device and a PC with **Veronte Link**, follow the steps:

1. Authentication is required before any operation.

Veronte Link - Login

After clicking **Sign in**, a new window will open for users to enter their credentials. If users do not have credentials, do not know what they are or have any problems logging in with them, please contact the support team via the Joint Collaboration Framework opening a [Ticket](#) or contact sales@embention.com.


If the login is successful, the screen will change as shown below:



Veronte Link - Login successful

Warning

If incorrect credentials are entered, the system will display the error message Incorrect username or password.



Connect the device to a PC via Serial (USB, RS232 or RS485) or UDP/TCP (Wifi or Ethernet).




PC-Veronte device connection

Note

Connecting the device to the PC is not necessary when communicating via Veronte Cloud. Please, see [Cloud connection](#) for further information.

1. Open **Veronte Link**, then a similar image to the following should be displayed:



Veronte Link interface - Devices menu

1. **Veronte Link version:** Informs the user about the version of the software being used.
2. **Devices:** This is the currently displayed menu. It shows the devices connected to the PC.
3. **Connections:** This menu allows the user to configure the connection between the PC and a Veronte device. See [Connections](#) section for more information.

4. **Sessions:** In this menu users can play back recorded logs and flights.
See [Sessions](#) section for more information.
5. **Cloud connection:** This menu allows the user to configure the **internet** connection between the PC and the available Veronte Autopilots 1x.

See [Cloud connection](#) section for more information.

 Note

Only available if the user has logged in.

6. **Login:** Log in to the desired account.
7. **Set disconnect timeouts:** Configure a timeout after which the autopilot is disconnected if Veronte Link receives no data.
8. **Find all:** Runs a discovery to all devices.
9. **Search from ID:** Searches for a specific device by its ID. Entering the ID **999** will search for all devices.
10. **Unique autopilot ID:** Autopilot UUID.
11. **Refresh configurables:** It is recommended to use in case of any connection error.

 Note

Only available if a device is connected or has been connected.

12. **Remove device:** Only works after disconnecting the device.

 Note

Only available if a device is connected or has been connected.

13. **Veronte device:** Here it is displayed an image of the Veronte device that is connected.
14. **Dark/light mode:** Switches to light/dark mode, changing the display mode of the interface.
15. **Terms and Conditions:** Users can consult the 'End User License Agreement (EULA)' by simply clicking on this button.
16. **Port:** Port through which the autopilot is connected.
17. **Hardware version**

18. **ID:** Autopilot ID.

19. **Software version**

20. **Unit:** Can be 1x or 4x.

21. **Configuration status:** It can be:

- PDIF: Waiting to read
- PDIF: Reading
- PDIF: Ready
- PDIF: Failed load
- PDIF: Not Downloaded (for products other than Veronte Autopilot 1x)
- PDIF: Not compatible

Note

Products are typically operational even if the configuration is not marked as "ready".


22. **Device status:** Can be in Normal mode, Maintenance mode or Loaded with errors.

23. **Connection status:** It can be Connected or Disconnected.

24. **Serial number:** Expressed in hexadecimal.

Important

Once Veronte Link is executed, an icon will appear in the taskbar and a browser window will open.




To close the application, it is not enough to close the browser window, it is necessary to right-click on the icon and select Close.

If the browser window is closed, it can be accessed again by pressing the Open button.

Connections

- **UDP Multicas Configuration:** Verontelink manages the bidirectional communication between a device and a STANAG CUCS via UDP multicast. It transmits messages from the device to the configured destination IP/port and forwards incoming messages received on the dedicated receiving port back to the device.



The screenshot shows the 'UDP Multicast Configuration' window in the Veronte Link application. The window has a dark theme. At the top, there's a header bar with 'Veronte Link' on the left and 'User name' on the right. Below the header, there's a navigation bar with 'Devices' and 'Configuration' tabs. The 'Configuration' tab is active, and a red arrow points to a red box containing a network icon and a plus sign. The main area of the window is titled 'UDP Multicast Configuration'. It contains several input fields: 'IP Address*' with the value '225.200.1.0', 'Sending Port*' with the value '51017', 'Receiving Port*' with the value '51018', and 'Time to Live*' with the value '5'. There is also a 'Network Interface' dropdown menu set to 'Local (default)'. At the bottom right, there are 'Close' and 'Save' buttons. A red arrow points to the 'Save' button.


UDP Multicast Congifuration menu

- **IP Adress:** The multicast group address to which the data is sent and received.
- **Sending Port:** The local UDP source port used for sending messages to the multicast group
- **Recelving Port:** The dedicated UDP port used by the application to listen for incoming messages and forward them to the device.
- **Time to Live:** Time To Live, it is the maximum amount of time or 'hops' that a UDP packet can exist inside a network before being discarded by a router. A default value should automatically be set.
- **Network interface:** This setting defines the device's network adapter used by Verontelink for multicast traffic. You can choose a specific interface or let the operating system manage the routing (System default).

Selecting **Local (Default)** as Network Interface standardizes internal communication between VeronteLink and VeronteOps under a unified name, replacing the legacy loopback. This configuration is active by default to enable automatic interconnection between applications on the same computer without manual adjustments.

To implement the changes, it is necessary to restart Veronte Link after saving the configuration.

In this menu users must **configure the connection type** of the Veronte device.



Connection menu

Clicking on the **+** icon will display the **configuration** panel. The parameters to be configured depend on the type of connection selected:

Warning

Apart from **Type** and **Port** parameters, it is not recommended to modify the default configuration, as the default parameters should work correctly.

- **Serial:** USB, RS232 or RS485 connections.

New connection

Type*
SERIAL

SERIAL configuration

Port Baudrate
115200

Parity Flow control
NONE NONE

Data bits Stop bits
8 1

Advanced

Reconnect time
5

Disconnect time
1

Cancel Save

Serial connection configuration

- **Port:** Select the port of the computer to which the device is connected. It does not have to be the same as the one in the example image ([Veronte Link interface](#)).

More information about the port where the device is connected is explained in [Serial connection - Integration examples](#) section of the present manual.

- **Baudrate:** This field specifies how fast data is sent over a serial line.
- **Parity:** Is a method of detecting errors in transmission.

When parity is used with a serial port, an extra data bit is sent with each data character, arranged so that the number of 1 bits in each character, including the parity bit.


The available options are **EVEN**, **MARK**, **ODD**, **SPACE** and **NONE**.

- **Flow control:** RTS/CTS and XON/XOFF control can be configured if needed.
- **Data bits:** Defines the number of bits in the message. It can be configured from **5 to 8** bits.
- **Stop bits:** Number of stop bits sent at the end of every character. Can be **1, 1.5** or **2**.
- **Advanced:**
 - **Reconnect time:** The time to consider a device reconnected. Default is set to 5 seconds.
 - **Disconnect time:** Time to consider a device disconnected is defined here. 1 second is configured by default.

Note

In case of not getting the device connected, make sure that the PC acquires a [communication port](#).

- **UDP:** Ethernet or Wifi connections.



The screenshot shows a 'New connection' dialog box with a dark background. At the top, it says 'New connection'. Below that is a 'Type*' dropdown menu with 'UDP' selected. Underneath is a section titled 'UDP configuration' with four input fields: 'Address' (239.0.0.1), 'Port' (12345), 'TTL' (5), and 'Buffer size' (548). The 'TTL' field has a red 'X' icon to its right. At the bottom are two buttons: 'Cancel' and 'Save'.

UDP connection configuration

 Important

Consider the maximum packet size supported by the [Veronte Communication Protocol \(VCP\)](#) when using serial data converters.

- **Address:** IP address, normally set to 239.0.0.1 (for broadcast) or 127.0.0.1 (for local).
- **Port:** IP Port must be set.
- **TTL:** Time To Live, it is the maximum amount of time or 'hops' that a UDP packet can exist inside a network before being discarded by a router.

A default value should automatically be set.

- **Buffer size:** Users would have to increase or decrease this value depending on the number of devices sending information through this channel.

By default this parameter has a value of **300**, which is the maximum value of a VCP message.


Explanation

For example, if a PCS is connected by radio to an Autopilot 1x, the buffer size should be increased because more consecutive messages arrive and can be mixed between them, generating invalid messages that cause messages to be discarded.

 Note

How to establish a connection via UDP is detailed in the [UDP connection - Integration examples](#) section of the present manual.

- **TCP-SERVER:** Ethernet or Wifi connections.



TCP-SERVER connection configuration

- **Port:** Set the TCP port from which the devices will get the information provided by Veronte Link.
- **Buffer size:** Users would have to increase or decrease this value depending on the number of devices sending information through this channel.

By default this parameter has a value of **300**, which is the maximum value of a VCP message.

Explanation

For example, if a PCS is connected by radio to an Autopilot 1x, the buffer size should be increased because more consecutive messages arrive and can be mixed between them, generating invalid messages that cause messages to be discarded.

Otherwise, if a very high buffer size is set, and only one device sends messages, the buffer will take longer to fill up, thus generating a delay in the reception of messages.

Note

How to establish a TCP-SERVER connection is detailed in the [TCP-SERVER connection - Integration examples](#) section of this manual.

- **TCP-CLIENT:** Ethernet or Wifi connections.

**TCP-SERVER connection configuration**

- **Address:** Enter the address of the device from which Veronte Link has to obtain the information.
- **Port:** Enter the TCP port from which the information is obtained.
- **Buffer size:** Users would have to increase or decrease this value depending on the number of devices sending information through this channel.

By default this parameter has a value of **300**, which is the maximum value of a VCP message.

Explanation

For example, if a PCS is connected by radio to an Autopilot 1x, the buffer size should be increased because more consecutive messages arrive and can be mixed between them, generating invalid messages that cause messages to be discarded.

 Note

How to establish a TCP-CLIENT connection is detailed in the [TCP-CLIENT connection - Integration examples](#) section of this manual.

Finally, click on **Save**.


Sessions

Sessions tab displays all **finished** device sessions.

 Important

- Sessions that are currently **being recorded** will not be displayed.
- A session from the currently **connected device** cannot be replayed.
- If users experience problems when attempting to replay a session, please check the [Error when replaying a session - Troubleshooting](#) section of this manual.

Each block represents the autopilot session.




Sessions menu

The following images describe each functionality.



Devices - Sessions menu

Devices: The user can select one or more devices they want. Click the All button to select all devices.



Range - Sessions menu

Range: This function allows the user to enter the time range they want to examine.

- **Enter a date range:** Enter the start and end dates of the session.
- **Start time:** Enter the session start time.
- **End time:** Enter the session end time.


The display shows the entered data:



Range display- Sessions menu


1. Date and time of session start.
2. Date and time of the moment being displayed.
3. Date and time of session end.

Hovering over the session block displays the following:



Range session - Sessions menu

1. The start date and time of the session.
2. The and date and time of the session.
3. The duration of the session.
4. The autopilot version.
5. The file weight.



Command display - Sessions menu

- Stop: It stops playing the session. It does not delete the session.
- Play/Pause: The button allows you to pause or resume the session.
- Rewind/forward: Enables rewind or forward by thirty seconds.
- Speed: Playing speed can be selected as x0.5, x1, x2, x4 and x8.

Cloud connection

Cloud connection tab allows the user to connect to a Veronte Autopilot 1x through **LTE network**. This functionality is enabled thanks to the **HSPA+** module (internal or external) embedded in Veronte autopilots.

Note

To activate the internal card or Veronte Cloud data traffic through internet, please contact sales@embention.com. Remember that there is **no internet connection** when **HSPA+ module** is deactivated.

To configure this type of connection, these steps must be followed:

Warning

In order to set up and operate a Veronte Autopilot 1x via Cloud connection, users must **first**:

1. Log in Cloud.
2. Establish a connection to Autopilot 1x that is not through Cloud (Serial, UDP, TCP-Server or TCP-Client).
3. **Upload** PDIF (configuration) to 1x with the **1x PDI builder** app or

with the **Upload PDIFs to cloud** button



This button will work as long as the cloud device is connected and the PDIFs are in the Ready state otherwise it will show errors:

This device does not have PDIFs
available for uploading


OK

Now the users are ready to establish the connection via Cloud and work. If these steps are not followed, Autopilot 1x will be in **PDIF: Failed load** status.

Note

This only needs to be done once per Veronte Autopilot 1x and per configuration. > Login credentials are automatically assigned. In case they have not been provided to you, please contact the support team by creating a ticket in the customer's Joint Collaboration Framework; for more information, see [Tickets](#) section of the JCF manual or contact sales@embention.com.

1. **Open Cloud connection tab.** Veronte Autopilots 1x linked to user's account should be displayed.




Cloud Connection: Available devices

The following information is displayed for each autopilot:

- **ID**: Identification number of the autopilot (Serial Number).
- **Last connection**: Indicates the date on which the last connection to that device was established.

2. **Activate the connection** with the desired Autopilot 1x by turning on **the toggle button** displayed next to it.



Cloud Connection: Connect to an Autopilot 1x

Note


Since Cloud connections are based on **LTE communication**, this connection may not be immediate. The selected autopilot will only be displayed in the 'Devices' tab when it is successfully connected.

3. At this point, **Veronte Link** must have established the connection with the selected Autopilot 1x. Consequently, the autopilot must be displayed in the Devices tab.

Note

Since Cloud connections are based on **LTE communication**, **connection may be lost** even when the toggle button is on. In this case, the autopilot will disappear from the 'Devices' tab, appearing again when the connection is retrieved.

To **log out**, click on the username to enable the log out button, and then press it.

**Cloud Connection: Log out**

Integration examples


Serial connection

As the com port configuration is common to all devices, the following steps are applied to MC110 controller as an example.

1. Once **Veronte Link** is installed, the first step that must be done is to set the connection that your MC unit is currently using.


By default, every MC is capable to comunicate through USB, RS232 and RS485 so any of these can be used (properly adapted to USB/serial).

First, click on "+":



Add new connection

2. Besides, it is required to find out which port is employing the MC unit. Windows allows to do that with the **Device Manager** from the **Control Panel**.



Windows Device Manager

3. Select your COM settings by entering the **Comm Port** previously found. Normally, the other default parameters should not be changed.

New connection

Type*
SERIAL

SERIAL configuration

Port
COM3

Baudrate
115200

Parity
NONE

Flow control
NONE

Data bits
8

Stop bits
1

Advanced

Reconnect time
5

Disconnect time
1

Cancel

Save

New connection configuration

4. If the selected port is correct and everything went well, a new MC will be displayed in the devices list. However, the device status will remain as **PDIF: Not Downloaded**. The user is ready now to start configuring the motor controller using **MC PDI Builder**.

Veronte Link

User name

Devices

Connections

Sessions

Cloud connection

MC110 v2.0 - 0x000089FE

UUID: 151724014699287

Connected

Bootloader mode

PDIF: Not Downloaded

v7.3.139

ID: 35326

HW: v2


Port: COM5

MC unit correctly connected

More Veronte devices (MC units, Veronte Autopilots, etc.) could be added following these instructions.

Note

In case of connecting a Veronte Autopilot 1x, after a few seconds, the device status should replace **PDIF: Waiting to read** by **PDIF: Ready**, since **only Autopilot 1x is able to change or load configuration in normal mode**.



Veronte Autopilot 1x connected and ready


For Veronte devices other than 1x, **PDIF: Waiting to read** should be replaced by the status **PDIF: Not Downloaded**.

UDP connection

Wi-Fi/Ethernet connection


Open [1x PDI Builder](#) and check the following settings:

- The RS485 port must be connected to the Commgr port, in this example, it's connected to Commgr port 4. Conversely, the same Commgr port, in this example Commgr port 4, must be connected to the RS485 port.



IO setup - Settings

- In the RS485 section, the Baud rate must have the following value.



RS485 - Settings

⚠ Warning

If the device is being connected for the first time, it is necessary to connect it via **USB**. Afterwards, it is possible to disconnect the USB and confirm that it works via **SERIAL**.

Wi-Fi/Ethernet configuration


The following steps are applied to a **PCS** unit as an example.

⚠ Important

If connecting through **Ethernet**, **step 1 does not apply**.

1. The first step is to look under available networks for the PCS unit and connect to it.
2. Once the connection is made, enter **Veronte Link** and configure the UDP connection in the **Connection menu**.

First, click on "+":



Add new connection

3. Then, the configurable parameters must be entered.




The image shows a 'New connection' dialog box with a dark background. At the top, the title 'New connection' is displayed. Below it, there is a 'Type*' dropdown menu with 'UDP' selected. Underneath, the 'UDP configuration' section contains four input fields: 'Address' with the value '239.0.0.1', 'Port' with the value '12345', 'TTL' with the value '5' and a clear button (X), and 'Buffer size' with the value '548'. At the bottom of the dialog are two buttons: 'Cancel' and 'Save'.

New UDP connection configuration

⚠ Important

This address and port are configured for this PCS unit, they do not have to be the same for another device.

4. Finally, if the configured connection is correct and everything went well, a new PCS will appear in the device list and the device status will change to **PDIF: Ready**. The user is ready now to start configuring the PCS using **1x PDI Builder**.



PCS unit correctly connected

Note

The image of a Veronte Autopilot 1x is displayed and not a PCS as the device that is actually connected is the Autopilot 1x inside the PCS.

TCP-SERVER connection


Ethernet configuration

The following steps detail how to connect Veronte Link to an Autopilot 1x via a TCP connection to a **Microhard** radio.

Note

In this connection, the **radio** acts as "**Client**" and **Veronte Link** as "**Server**".

1. Configure, in the Microhard WebUI, the radio as "**TCP Client**" and enter the following parameters:
 - **Remote Server IP Address**: IP address of the PC.
 - **Remote Server port**: TCP port to which the radio has to connect. It must be the same as the one configured in Veronte Link.For more information on the radio configuration, users can refer to the [Microhard radio configuration - Integration examples](#) section of the **1x Hardware Manual** or directly to the Microhard radio documentation.
2. Connect **Veronte Autopilot 1x** to the Microhard radio via **RS232** as detailed in the [Microhard pDDL900-ENC external - Integration examples](#) section of the **1x Hardware Manual**.
3. Once the configuration and connection is done, open **Veronte Link** and configure the **TCP-SERVER** connection in the **Connection menu**.
First, click on "+":




Add new connection

4. Then, the configurable parameters must be entered.

New TCP-SERVER connection configuration

- **Port:** Enter a TCP port to which the radio will be connected, the same as the one previously configured as "Remote Server port" in the radio configuration.
5. Finally, if the configured connection is correct and everything went well, a new Autopilot 1x will appear in the Devices list. It should look like this:



1x unit correctly connected

TCP-CLIENT connection


Ethernet configuration

The following steps detail how to connect Veronte Link to an Autopilot 1x via a TCP connection to a **Microhard** radio.

Note

In this connection, the **radio** acts as "**Server**" and **Veronte Link** as "**Client**".

1. Configure, in the Microhard WebUI, the radio as "**TCP Server**" and enter a "**Local Listening Port**" to which Veronte Link will have to connect (usually the default one is used).
For more information on the radio configuration, users can refer to the [Microhard radio configuration - Integration examples](#) section of the **1x Hardware Manual** or directly to the Microhard radio documentation.
2. Connect **Veronte Autopilot 1x** to the Microhard radio via **RS232** as detailed in the [Microhard pDDL900-ENC external - Integration examples](#) section of the **1x Hardware Manual**.
3. Once the configuration and connection is done, open **Veronte Link** and configure the **TCP-CLIENT** connection in the **Connection menu**.
First, click on "+":



Add new connection

4. Then, the configurable parameters must be entered.




New TCP-CLIENT connection configuration

- **Address:** IP address of the radio.
- **Port:** Enter as TCP port the "Local Listening Port" previously set in the radio configuration.

Important

This address and port are configured for this radio unit, they do not have to be the same for another device.

5. Finally, if the configured connection is correct and everything went well, a new Autopilot 1x will appear in the Devices list. It should look something like this:



1x unit correctly connected

Troubleshooting

In case of any software error, it is possible to extract and analyze files from session folder.

Warning


Do not modify or delete manually any **Veronte Link** file. Copy them to a different path to send or analyze.

Veronte Link files are placed on the following paths:

- `C:\Users\USER NAME\AppData\Roaming\VeronteLink\configurables` Device configurations.
- `C:\Users\USER NAME\AppData\Roaming\VeronteLink\sessions` Session files, it includes flights information.
- `C:\Users\USER NAME\AppData\Roaming\VeronteLink\tracelogs` Event logs, it includes flights information.
- `C:\Users\USER NAME\AppData\Roaming\VeronteLink` ⇒ `cfg.son`
Veronte Link connections configuration file. **If deleted, the configuration will be lost.**
- `C:\Users\USER NAME\AppData\Roaming\VeronteLink` ⇒ `vlink.lock`
Internal file that only appears if any instance of **Veronte Link** is open. **If deleted, there will be instability in the system.**

Comm Port error in Windows Device Manager


If the following Windows Comm Port error occurs:



Windows Device Manager - Comm Port error

Users must extend the disconnection time to 5 seconds to fix it. To do this:

1. Go to the **Connection** menu → click on the ⚙ icon to open the COM configuration.
2. Open the **Advanced** parameters drop down menu → modify the **Disconnect time** to **5 seconds**.



The screenshot shows the 'New connection' dialog in the Veronte Link (v7.6.5) application. The dialog is titled 'New connection' and has tabs for 'Type*', 'SERIAL configuration', and 'Advanced'. The 'Type*' dropdown is set to 'SERIAL'. The 'SERIAL configuration' section includes fields for 'Port', 'Baudrate' (115200), 'Parity' (NONE), 'Flow control' (NONE), 'Data bits' (8), and 'Stop bits' (1). The 'Advanced' section is expanded, showing 'Reconnect time' (5) and 'Disconnect time' (5). The 'Disconnect time' field is highlighted with a red box. A red arrow points to the gear icon in the top right corner of the dialog.

Connection configuration - Disconnect time

If the user is still having problems with this, please contact the support team by creating a ticket in the customer's **Joint Collaboration Framework**; for more information, see [Tickets](#) section of the JCF manual.

Error when replaying a session

If the following error message appears when attempting to replay a session:

The session cannot be played because a device with the same address is connected

OK

Error message

It is often due to users trying to replay a previous session from the device that is **currently connected**, which is not possible as indicated in the [Sessions](#) section.

Viewing UDP data

An application such as Wireshark can be used to visualize raw data sent from Autopilot 1x. Nonetheless, at the beginning, it may show characaters that do not come from 1x, because Wireshark reads all data from the connected port, including protocol information.

To distinguish 1x messages, the user has to search the matcher 0x0A 0xA0 for **Veronte UDP Telemetry CLI**. The matcher indicates the beginning of the data. In the following example, characters marked with blue correspond to 1x, while yellow characters are the UDP protocol structure.

0000	02 00 00 00 45 00 00 36 04 9e 00 00 80 11 00 00	...E...6
0010	7f 00 00 01 7f 00 00 01 fa 54 0b b8 00 22 ea 00	T..."
0020	0a a0 f9 f9 0d 00 00 00 00 00 00 00 00 00 00	
0030	00 00 00 00 00 00 00 00 00 00	

Software Changelog

This section presents the changes between versions of **Veronte Link** application.

7.8.16

This section presents the changes between the previous software version **v. 6.14.64** and **7.8.16**.

Added

- Device names now include the product name and version
- Alert in multicast configuration panel
- Session player
- Commands sent to a device are saved in the Veronte Link session
- Central log in

Removed

- Planet connection

Changed

- Method to get sessions within the range executes asynchronously in a separate thread, with a limit on data processing
- Max range selectable