
Veronte Link

Release 6.14.55

Embention

2025-02-12

CONTENTS

1 Quick Start	3
1.1 System Requirements	3
1.2 Installation	3
2 Additional apps	5
2.1 Veronte UDP Telemetry CLI	5
2.1.1 Download	5
2.1.2 Installation	5
2.1.3 Configuration	7
2.1.3.1 1x PDI Builder	7
2.1.3.2 Veronte UDP Telemetry CLI	8
2.1.3.3 Index-Unit correspondence table	14
2.1.4 Operation	17
2.1.4.1 Sending UDP messages	17
3 Operation	21
3.1 Connection	24
3.2 Sessions	31
3.3 Cloud connection	33
4 Integration examples	37
4.1 Serial connection	37
4.2 UDP connection	41
4.3 TCP-SERVER connection	44
4.4 TCP-CLIENT connection	47
5 Troubleshooting	51
5.1 Comm Port error in Windows Device Manager	51
5.2 Error when replaying a session	53
5.3 Viewing UDP data	54
6 Software Changelog	55




Veronte Link interconnects multiple control stations and autopilot units, so they can operate simultaneously.

Important: This app is **backwards compatible** as long as it matches the “major” version (versions are composed as major.minor.revision, e.g. 6.12.22), so users should always use the **last version** that is within the same “major” version.

Contact Embention to ensure having the latest version, please see [Joint Collaboration Framework user manual](#) or contact sales@embention.com.

The following image shows where to select a version from any Embention user manual.



QUICK START

Veronte Link establishes **communication between a computer and any Veronte product** by creating a **VCP bridge**. It allows to use multiple control stations and autopilots to be interconnected, operating simultaneously.

Veronte Link also includes a **post-flight viewer**, to reproduce all recorded data from previous flights and generate plots and reports.

Veronte Link supports **Windows operating system**.

Note: **Windows 10** is recommended, but **Windows 11** is supported.

1.1 System Requirements

Before executing this software, users should check the following sections with the minimum and recommended PC hardware requirements.

Minimum requirements

- CPU: Intel Core i5-8365UE
- RAM: 8 GB DDR4
- STO: 256 GB SSD

Recommended requirements

- CPU: 12th Gen Intel(R) Core(TM) i7-12700H 14 cores up to 4,70 GHz
- RAM: 32,0 GB
- STO: 1TB SSD M.2 NVMe PCIe

1.2 Installation

Once a Veronte device has been purchased, a GitHub release should be created for the customer with the application.

To access to the release and download the software, read the [Releases](#) section of the **Joint Collaboration Framework** manual.

To install **Veronte Link** on Windows, execute Veronte Link.exe and follow the indications of the *Setup Wizard*.

Warning: In case of any issue during installation, please disable Windows Defender and Firewall. To disable Firewall, go to “Control Panel” and “Firewall of windows”, then click on **Turn off**.




Fig. 1: Windows Defender Firewall




Fig. 2: Windows Defender Firewall - Customize Settings

ADDITIONAL APPS

2.1 Veronte UDP Telemetry CLI



Fig. 1: Veronte UDP Telemetry CLI

Veronte UDP Telemetry CLI is an additional command-line tool which allows **Veronte Link** to send Autopilot 1x telemetry over UDP.

2.1.1 Download

Once the **Veronte Autopilot 1x** has been purchased, a GitHub release should be created for the customer with the application.

To access to the release and download the software, read the [Releases](#) section of the **Joint Collaboration Framework** manual.

2.1.2 Installation

To install **Veronte UDP Telemetry CLI** on Windows just execute “veronte-udp-telemetry-cli.exe” and follow the indications of the *Setup Wizard*.

Warning: If users have any problems with the installation, please disable the antivirus and the Windows firewall. Disabling the antivirus depends on the antivirus software.

To disable the firewall, go to “Control Panel” → “System and Security” → “Windows Defender Firewall” and then, click on “Turn windows Defender Firewall on or off”.




Fig. 2: Windows Defender Firewall




Fig. 3: Windows Defender Firewall: Customize Settings

2.1.3 Configuration

The following sections detail the steps to **configure** the Veronte system to transmit telemetry UDP messages through **Veronte UDP Telemetry CLI**, after it is installed.

2.1.3.1 1x PDI Builder

First, in **1x PDI Builder**, the intended variables to send must be added to the corresponding telemetry vector.

To do this:

1. Go to Telemetry menu → **Telemetry panel**.
2. By clicking the corresponding **+** button, add the desired telemetry variables to one of the telemetry vectors *Data to VApp*.




Fig. 4: Add variables

Note: For further information about this Telemetry menu, please refer to the [Telemetry](#) section of **1x PDI Builder** user manual.

3. Configure the *Data to VApp* vector where the variables have been added as follows:
 - **Frequency:** Desired frequency of data transmission
 - **Address:** App 2 (Veronte apps address)

Note: Hash parameter is not configurable, it is automatically calculated by the system based on the telemetry vector configured by the user. It is a hexadecimal representation of the CRC of the fieldset.





Fig. 5: Data vector parameters

4. Save the changes by clicking  button.

2.1.3.2 Veronte UDP Telemetry CLI

Veronte UDP Telemetry CLI has a configuration file (`tudp.config`) where users must specify which telemetry variables to send. Once the app is installed, this file can be found in `C:/Users/user/AppData/Roaming/VeronteUDPTelemetryCli`:



Fig. 6: Configuration file

Caution: On Windows, the AppData folder is hidden by default, if it is not visible in C:\Users\user, users can “show” it by checking the “Hidden Items” checkbox:




Fig. 7: Windows File Explorer

This configuration file consists of 3 parts:

- `&HEAD hex`. This establishes the header of the UDP messages sent.
- `&LVARS ... END_LVARS`. Defines the **LVARS**, which are complex variables defined by the user, as expressions in which autopilot variables may or may not be used. Each new line between `&LVARS` and `END_LVARS` is a **LVAR**. *LVARS* can be boolean or number type.

Each *LVAR* has the following structure: `L[id] = [default value] = [expression]`

- `id`: It is any integer to identify the *LVAR* and is used in the entries to indicate the *LVAR* to send.
- `default value`: The default value is the initial value that the *LVAR* will have the first time it is set.
- `expression`: For each UDP packet sent, the *LVAR* values are updated with the result by evaluating the expression.

Example

$L40 = \text{false} = (u1599_RVAR_1021 > (0.5)) \ \&\& \ (u1599_BIT_1053 > (0))$

LVAR L40, initialized as **false**, and for each UDP packet sent, the *LVAR* value is updated with the result of the expression $(u1599_RVAR_1021 > (0.5)) \ \&\& \ (u1599_BIT_1053 > (0))$.

Where, *u1599_RVAR_1021* refers to RVAR 1021 of the autopilot with address 1599, and *u1599_BIT_1053* refers to BIT 1053 of the same autopilot.

- **Offsets/Entries.** This is the information that is sent via UDP for each telemetry variable.

Users must fill in for each entry (*except bits*) the following fields of the table in **this order**:

1. **MULT** (float): Scaling factor by which the variable obtained from the autopilot is multiplied.

Note: Only used for the following **VVARs** (VERVARs): *L_EQ*, *RVAR*, *UVAR*, *CUSTOM* and *LVAR*.

This field does not affect the *bits*, but must be set nonetheless.

2. **OFFSET** (float): Offset factor to be added to the variable value obtained from the autopilot, before being multiplied by the *MULT* value.

Note: This field does not affect the *bits*, but must be set nonetheless.

3. **TVAR:** Type of variable representing the value sent via UDP. It can be:

Important: The variables configured in the `tudp.config` file must match the previous configuration from [1x PDI Builder configuration](#) section of this manual, so each variable is parsed according to the organization of the bits.

- **byte:** Unsigned byte (0 to 255)
 - **bit:** A desired number of bits
 - **UInt16:** Unsigned 16-bit integer (0 to 65.536)
 - **Int16:** Signed 16-bit integer (-32.768 to 32.768)
 - **UInt32:** Unsigned 32-bit integer (-2.147.483.648 to 2.147.483.648)
 - **Int32:** Signed 32-bit integer (0 to 4.294.967.295)
 - **Float:** 32 bit single-precision floating-point ($3.4028237 \cdot 10^{38}$ to $1.175494 \cdot 10^{-38}$)
-

Note: Unlike the other TVARs, **bits** allows users to define several variables that are packed as only one within the UDP message. To do this, each new line is a variable that is included in the bits entry, until the `&END_BIT` line is read.

4. **UAV** (int): Serial Number of the Autopilot 1x where the variables **come from**.

Note: UAV address does not matter for *LVARs*, since it is either already indicated in the *LVAR* expression or it is a value that does not come from any autopilot.

5. **VERVAR/VVAR:** Type of variable in Veronte system.

- **RVAR:** Real variables obtained **directly from the autopilot**
- **UVAR:** Integer variables obtained **directly from the autopilot**
- **BIT:** Bit variables obtained **directly from the autopilot**
- **CUSTOM**
- **NONE:** Equivalent to 0
- **L_EQ:** Linear equation. Similar to *TVAR bits*, it allows defining several variables in a single entry.

The resulting value of this type of entry is the addition of all the consequent variables, multiplied by *COEFFICIENT*, to which the unit conversion (*UNIT*), addition (*OFFSET*) and multiplication (*MULT*) are finally applied.

The linear equation continues to wait for more variables until the `&END_L_EQ` line is read.

Note: As implemented, there is no use for the ID field when defining an *L_EQ*, since the IDs used are those of the following lines.

- **LVAR:** It must be previously defined as explained above.
6. **ID** (int): Identifier of the variable in Veronte. Refer to the [Lists of Variables - Lists of interest](#) section of **1x Software Manual** for Index-Variable correspondence or check it on the [Variables](#) panel of the UI menu of **1x PDI Builder** app.
7. **UNIT** (int): Index of the unit of measurement of the variable in case a conversion has to be made. Please, see the [Index-Unit correspondence table](#) for detailed information.
8. **LIMITS** (*optional*) (Only for *BITs*): It is optional and its format is `[min&max]`, both are of float type.
8. **COEFFICIENT** (Only for *L_EQ*): It is a coefficient of the linear equation.

Below are several examples of the configuration file depending on the type of variable to be sent.

- **RVARs.** Example with *Relative Timestamp*, *Longitude* and *Latitude* variables:

```
#HEAD HEX
&HEAD      0AA0

#MULT      OFFSET      TVAR      UAV      VERVER      ID      UNIT
1000       0              UInt32    1599     RVAR       300     NONE
1          0              Float     1599     RVAR       500     NONE
1          0              Float     1599     RVAR       501     NONE

# First row: Send Time Since Hardware Start-Up (Milliseconds) as an UInt32 (4 bytes)
# Second row: Send Longitude as a Float (4 bytes)
# Third row: Send Latitude as a Float (4 bytes)
```

- **LVARs:**

```

#HEAD HEX
&HEAD      1FB9

&LVARS
L1 = 0 = L1 + 1
L70 = 20 = L70 + L1
L45 = false = L70 % 2 == 0
L80 = false = (u1599_RVAR_1021 > (0.5)) && (u1599_BIT_1053 > (0))
&END_LVARS

# L80 initially has a value of false. Next values are obtained from the expression
# (u1599_RVAR_1021 > (0.5)) && (u1599_BIT_1053 > (0))
# u1599_RVAR_1021 = value of RVAR 1021 (stky21, Stick Input y21)
# from autopilot with address 1599.
# The value of this variable is also updated every time

# Use of Lvars
#MULT      OFFSET      TVAR      UAV      VERVER      ID      UNIT
1          0           Int16     0000     LVAR       1      NONE
1          0           Float     0000     LVAR       70     NONE
1          0           byte      0000     LVAR       45     NONE

# UAV address does not matter for these LVARs since they do not come from an
↳ autopilot.

# First row: Send L1 as an Int16 (2 bytes)
# Second row: Send L70 as a Float (4 bytes)
# Third row: Send L45 as a byte (1 byte)

```

- **BITs:**

```

#HEAD HEX
&HEAD      0AA0

#MULT      OFFSET      TVAR      UAV      VERVER      ID      UNIT
1          0           bits
#UAV      VERVER      ID      UNIT      LIMITS(optional)
1599     RVAR       501     NONE
1599     RVAR       500     NONE     [-1000&1000]
&END_BIT

# Mult and Offset do not affect bits, but they must be set regardless.
# Any int value is valid and acts the same.

```

- **BITs with LVARs.** Taking the LVARs defined in the previous example:

```

#HEAD HEX
&HEAD      1FB9

#Definition of LVARs
&LVARS
L1 = 0 = L1 + 1
L70 = 20 = L70 + L1

```

(continues on next page)

(continued from previous page)

```

L45 = false = L70 % 2 == 0
&END_LVARS

#Bits example with lvars
#MULT      OFFSET      TVAR      UAV      VERVER      ID      UNIT
1          0           bits
#UAV      VERVER      ID      UNIT      LIMITS(optional)
0000     LVAR       1      NONE     [0&10]
0000     LVAR       70     NONE     [100&500]
0000     LVAR       45     NONE
&END_BIT

# Mult and Offset do not affect bits, but they must be set regardless.
# Any int value is valid and acts the same.

# In this example, each one of the variables occupies one bit in the resulting
↳message.
# L1, which is incremented by one, is checked if it is within the set limit 0&10,
# i.e., for values strictly greater than 0 and strictly less than 10,
# the bit will be 1, and for all other values, it will be 0.

# The same applies to L70, when 100<L70>500, the bit is 1, and for the rest it is 0.

# L45 on the other hand doesn't have a limit.
# When no limit is established, it compares it to 1.
# Since L45 is a boolean that checks that L70 is even,
# the bit will be one when the value is 1, and 0 when not.

# Concrete example: L1 = 16, L70 = 156, L45 = true (because L70 is even)
# The UDP packet will be:
# HEADER: 31 -71
# L1: 16 0
# L70: 0 0 28 67
# L45: 1
# bits: 6 = bits[1 1 0] because:
# L1 is not in the limits (0), L70 is (middle 1), and L45 is 1/true (left 1).
# The order is from least to most significant in the order indicated in the bits
↳list.

```

- **L_EQ:**

```

#HEAD HEX
&HEAD      0AA0

#MULT      OFFSET      TVAR      UAV      VERVER      ID      UNIT
1          0           Int16     0000     L_EQ      NONE     NONE
#UAV      VERVER      ID      UNIT      COEFFICIENT
1001     RVAR       1      NONE     2.3
1001     UVAR       1      NONE     2.3
&END_L_EQ

# LINEAR EQUATION:

```

(continues on next page)

(continued from previous page)

```
# ((COEFFICIENT*RVAR(1) + COEFFICIENT*UVAR(1)) + Offset) * Mult
# ((2.3*RVAR(1) + 2.3*UVAR(1)) + 0) * 1
```

- **L_EQ with LVARs.** Taking the LVARs defined in the previous example:

```
#HEAD HEX
&HEAD      1FB9

#Definition of LVARs
&LVARs
L1 = 0 = L1 + 1
L70 = 20 = L70 + L1
&END_LVARs

#Linear equation example with lvars
#MULT      OFFSET      TVAR      UAV      VERVER      ID      UNIT
2          13          Float    0000     L_EQ       0      NONE
#UAV      VERVER      ID      UNIT      COEFFICIENT
0000     LVAR       1      NONE     50
0000     LVAR       70     NONE     25
&END_L_EQ

# Concrete example: L1 = 1, L70 = 21
# ((50*L1 + 25*L70) + Offset) * Mult = ((50*1 + 25*21) + 13) * 2 = 1176
# Sent as a Float, therefore in the udp packet it will be:
# 1176 = [0 0 -109 68]
```

2.1.3.3 Index-Unit correspondence table

Unit ID	Unit
0	m/s
1	kt
2	km/h
3	mph
4	ft/s
121	ft/m
321	mm/s
5	m
6	km
62	mm
63	cm
7	mi
8	NM
9	yd
10	ft
11	in
12	m/s ²
13	ft/s ²
14	in/s ²

continues on next page

Table 1 – continued from previous page

Unit ID	Unit
15	g (gravity)
202	rad
16	rad $[-\pi, \pi]$
203	rad $[0, 2\pi]$
205	°
17	° $[-180, 180]$
101	° $[0, 360]$
102	° ‘ ‘’
103	° ‘ ‘’ (N/S)
104	° ‘ ‘’ (E/W)
21	T
160	nT
23	G
22	mG
24	V
25	mV
26	A
27	mA
340	kA
28	Pa
29	kPa
30	bar
31	mbar
32	psi
33	mmHg
34	at
35	atm
147	Pa ²
36	K
37	°C
38	°F
39	s
120	Time
40	min
41	h
330	ns
108	μ s
109	ms
42	rad/s
117	°/s
43	rad/min
44	rad/h
45	rps
46	rpm
47	rph
57	m ³ /s
58	gal/s
54	gal/h
59	l/s

continues on next page

Table 1 – continued from previous page

Unit ID	Unit
55	l/h
56	–
60	x1
64	%
61	pkts/s
105	Hz
106	mHz
107	kHz
140	Bd
141	kBd
142	MBd
110	m ²
111	cm ²
112	mm ²
113	km ²
114	mile ²
115	ft ²
116	yd ²
118	bit
119	byte
131	KB
132	GB
122	kg
123	g
124	tonnes
125	lbs
126	oz
127	N
128	kN
129	lbf
130	pdl
134	rad/s ²
135	rad/min ²
136	rad/h ²
137	°/s ²
138	°/m ²
139	°/h ²
329	rpm/s
143	T ²
144	(m/s) ²
145	(cm/s) ²
146	(mm/s) ²
327	Ω
328	Henrios
322	watios
323	kW
324	Kgm/s
325	erg/s
326	cv

continues on next page

Table 1 – continued from previous page

Unit ID	Unit
331	m ³
332	dm ³
333	mm ³
334	L
335	mL

2.1.4 Operation

This section details the steps to **transmit telemetry UDP messages** through **Veronte UDP Telemetry CLI**.

2.1.4.1 Sending UDP messages

Veronte UDP Telemetry CLI connects to **Veronte Link** to send the previously configured Autopilot 1x telemetry via UDP messages. For this reason, the connection between the autopilot and **Veronte Link** must be properly established, and **Veronte Link** needs to be opened.

Note: For more information about this connection, please refer to *Connection - Operation* section of this manual.

These are the options to send the configured variables:

1. Launching **Veronte UDP Telemetry CLI** by double-clicking on the App shortcut or the `.exe` file:



Fig. 8: **Veronte UDP Telemetry CLI** shortcut

This will send the UDP messages with the following default configuration:

- **Host url:** 127.0.0.1
- **UDP port:** 3000
- **Frequency:** 10 Hz


Note: These installation files location will vary depending on the location selected during installation.

Note that **Veronte UDP Telemetry CLI Installer .exe** is not the **Veronte UDP Telemetry CLI .exe** to launch.

2. Launching **Veronte UDP Telemetry CLI .exe** from terminal, where it is possible to specify the parameters of the trasmission using the following command-line options:
 - **- u:** UDP address
 - **- p:** UDP port

- **- f**: Desired frequency of data transmission (*Hz*)


This is an example:



```
C:\Windows\System32\cmd.exe
C:\Program Files\Embention\veronte-udp-telemetry-cli>start veronte-udp-telemetry-cli-6.12.1.exe -u 192.158.1.38 -p 3001 -f 1
```

Fig. 9: Launching from terminal example

The expected outcome is the following:



```
veronte-udp-telemetry-cli-6.12.1
+ [34m2023-12-05 10:18:12 [INFO] Starting Veronte-UDP-Telemetry RUNNABLE
+ [34m2023-12-05 10:18:13 [INFO] Trying to connect with vlink...
+ [34m2023-12-05 10:18:13 [INFO] Client deployed and connected to vlink.
+ [34m2023-12-05 10:18:15 [INFO] UAVINI# 1x v4.8 4041 (6.12.69) ADD
```

Fig. 10: Expected outcome

Note: Veronte UDP Telemetry CLI always adds the matcher *0x0A 0xA0* at the beginning of each sent UDP packet

before the variable data.

Therefore the received UDP packet will be: `0x0A 0xA0` followed by the consecutive stream of data in the order and byte width configured in `tudp.config`.

If users have any doubts about the UDP packets that are generated, please refer to [Viewing UDP data - Troubleshooting](#) section of this manual.

OPERATION

In order to establish a connection between a Veronte device and a PC with **Veronte Link**, follow the steps:

1. Connect the device to a PC via Serial (USB, RS232 or RS485) or UDP/TCP (Wifi or Ethernet).



Fig. 1: **PC-Veronte device connection**

Note: Connecting the device to the PC is not necessary when communicating via Veronte Cloud. Please, see *Cloud connection* for further information.

2. Open **Veronte Link**, then a similar image to the following should be displayed:




Fig. 2: Veronte Link interface - Devices menu

1. **Devices:** This is the currently displayed menu. It shows the devices connected to the PC.
2. **Veronte Link version:** Informs the user about the version of the software being used.
3. **Connection:** This menu allows the user to configure the connection between the PC and a Veronte device. See [Connection](#) section for more information.
4. **Sessions:** In this menu users can play back recorded logs and flights. See [Sessions](#) section for more information.
5. **Cloud connection:** This menu allows the user to configure the **internet** connection between the PC and the available Veronte Autopilots 1x. See [Cloud connection](#) section for more information.

Note: Only available if the user has logged in.

6. **Host:** Allows connecting to the local IP address or to another desired IP address.
7. **Login:** Enables cloud connection through user logging.
8. **Find all:** Runs a discovery to all devices.
9. **Search from ID:** Searches for a specific device by its ID. Entering the ID **999** will search for all devices.
10. **Sort list:** Click on it to sort the list of devices.
11. **Remove device:** Only works after disconnecting the device.

Note: Only available if a device is connected or has been connected.

12. **Refresh configurables:** It is recommended to use in case of any connection error.

Note: Only available if a device is connected or has been connected.

13. **Open Veronte FDR:** From here users can access Veronte FDR on the same version of the connected device.
14. **Open Veronte Ops:** From here users can access Veronte Ops on the same version of the connected device.
15. **Dark/light mode:** Switches to light/dark mode, changing the display mode of the interface.
16. **Switch particles:** Particles can be *on* or *off*, changing the application appearance.
17. **Terms and Conditions:** Users can consult the ‘End User License Agreement (EULA)’ by simply clicking on this button.
18. **Configuration status:** It can be:
 - *PDIF: Waiting to read*
 - *PDIF: Reading*
 - *PDIF: Ready*
 - *PDIF: Failed load*
 - *PDIF: Not Downloaded* (for products other than Veronte Autopilot 1x)
 - *PDIF: Not compatible*

Note: Products are typically operational even if the configuration is not marked as “ready”.

19. **Device status:** Can be in *Normal mode*, *Maintenance mode* or *Loaded with errors*.
20. **Connection status:** It can be *Connected* or *Disconnected*.
21. **Veronte device:** Here it is displayed an image of the Veronte device that is connected.

Important: Once **Veronte Link** is executed, an icon will appear in the taskbar and a browser window will open.




Fig. 3: Veronte Link icon

To **close** the application, it is not enough to close the browser window, it is necessary to **right-click** on the icon and select **Close**.

If the browser window is closed, it can be accessed again by pressing the **Open** button.

3.1 Connection

In this menu users must **configure the connection type** of the Veronte device.




Fig. 4: Connection menu

Clicking on the '+' icon will display the **configuration** panel. The parameters to be configured depend on the type of connection selected:

Warning: Apart from **Type** and **Port** parameters, it is not recommended to modify the default configuration, as the default parameters should work correctly.

- **Serial:** USB, RS232 or RS485 connections.

New connection

Type *
SERIAL

SERIAL configuration

Port

Baudrate
115200

Parity
NONE

Flow control
NONE

Data bits
8

Stop bits
1

Advanced

Reconnect time
5

Disconnect time
1

Cancel Save

- **Port:** Select the port of the computer to which the device is connected. It does not have to be the same as the one in the example image (*Veronte Link interface* image).

More information about the port where the device is connected is explained in *Serial connection - Integration examples* section of the present manual.

- **Baudrate:** This field specifies how fast data is sent over a serial line.
- **Parity:** Is a method of detecting errors in transmission.

When parity is used with a serial port, an extra data bit is sent with each data character, arranged so that the number of 1 bits in each character, including the parity bit.

The available options are **EVEN, MARK, ODD, SPACE** and **NONE**.

- **Flow control:** RTS/CTS and XON/XOFF control can be configured if needed.
- **Data bits:** Defines the number of bits in the message. It can be configured from **5 to 8** bits.
- **Stop bits:** Number of stop bits sent at the end of every character. Can be **1, 1.5** or **2**.
- **Advanced:**
 - * **Reconnect time:** The time to consider a device reconnected. Default is set to 5 seconds.
 - * **Disconnect time:** Time to consider a device disconnected is defined here. 1 second is configured by default.

Note: In case of not getting the device connected, make sure that the PC acquires a *communication port*.

- **UDP:** Ethernet or Wifi connections.

New connection

Type *
UDP

UDP configuration

Address
239.0.0.1

Port
12345

TTL X

Buffer size
300

Cancel Save

Fig. 6: UDP connection configuration

Important: Consider the maximum packet size supported by the [Veronte Communication Protocol \(VCP\)](#) when using serial data converters.

- **Address:** IP address, normally set to *239.0.0.1* (for broadcast) or *127.0.0.1* (for local).
- **Port:** IP Port must be set.
- **TTL:** Time To Live, it is the maximum amount of time or ‘hops’ that a UDP packet can exist inside a network before being discarded by a router.

A default value should automatically be set.

- **Buffer size:** Users would have to increase or decrease this value depending on the number of devices sending information through this channel.

By default this parameter has a value of **300**, which is the maximum value of a VCP message.

Explanation

For example, if a PCS is connected by radio to an Autopilot 1x, the buffer size should be increased because more consecutive messages arrive and can be mixed between them, generating invalid messages that cause messages to be discarded.

Note: How to establish a connection via UDP is detailed in the *UDP connection - Integration examples* section of the present manual.

- **Planet:** Satellital connections, it requires internet connection.




Fig. 7: Planet connection configuration

- Satcom ID must be set.

- **TCP-SERVER:** Ethernet or Wifi connections.




Fig. 8: TCP-SERVER connection configuration

- **Port:** Set the TCP port from which the devices will get the information provided by Veronte Link.
- **Buffer size:** Users would have to increase or decrease this value depending on the number of devices sending information through this channel.

By default this parameter has a value of **300**, which is the maximum value of a VCP message.

Explanation

For example, if a PCS is connected by radio to an Autopilot 1x, the buffer size should be increased because more consecutive messages arrive and can be mixed between them, generating invalid messages that cause messages to be discarded.

Otherwise, if a very high buffer size is set, and only one device sends messages, the buffer will take longer to fill up, thus generating a delay in the reception of messages.

Note: How to establish a TCP-SERVER connection is detailed in the *TCP-SERVER connection - Integration examples* section of this manual.

- **TCP-CLIENT:** Ethernet or Wifi connections.

The screenshot shows a dark-themed mobile interface for configuring a new connection. At the top, the title 'New connection' is displayed. Below it is a dropdown menu labeled 'Type *' with 'TCP-CLIENT' selected. A horizontal separator line follows. The next section is titled 'TCP-CLIENT configuration' and contains three input fields: 'Address' with the value '192.168.168.1', 'Port' with the value '20002', and 'Buffer size' with the value '300'. At the bottom of the form are two buttons: a grey 'Cancel' button and a green 'Save' button.

Fig. 9: TCP-SERVER connection configuration

- **Address:** Enter the address of the device from which Veronte Link has to obtain the information.
- **Port:** Enter the TCP port from which the information is obtained.
- **Buffer size:** Users would have to increase or decrease this value depending on the number of devices sending information through this channel.

By default this parameter has a value of **300**, which is the maximum value of a VCP message.

Explanation

For example, if a PCS is connected by radio to an Autopilot 1x, the buffer size should be increased because more consecutive messages arrive and can be mixed between them, generating invalid messages that cause messages to be discarded.

Note: How to establish a TCP-CLIENT connection is detailed in the *TCP-CLIENT connection - Integration examples* section of this manual.

Finally, click on **Save**.

3.2 Sessions

Sessions tab displays all **finished** device sessions.

Important:

- Sessions that are currently being recorded will not be displayed.
- A session from the currently connected device cannot be replayed.
- If users experience problems when attempting to replay a session, please check the *Error when replaying a session - Troubleshooting* section of this manual.

The following image and list describe each functionality.




Fig. 10: Sessions menu

1. **Session name:** It is made with recording time (date and hour).
2. **Delete session.** If the user wishes to delete more than 1 session at a time, it is possible to delete them from the **Veronte Link sessions folder** located in the following path:
`C:\Users\USER NAME\AppData\Roaming\VeronteLink\sessions`
3. **Files weight.**
4. **Duration.**
5. **Play/Pause:** Play button creates a **virtual device** in the “*session port*” similar to the following figure:




Fig. 11: Virtual device

It starts a simulation replaying everything that happened during the session recording. It will recreate all the occurred events with detail and **Veronte Ops** will display the corresponding data and trajectories; read the [Veronte Ops user manual](#) for more information.

Note: In addition, when the virtual device is in a **ready** state, users can **open the 1x PDI Builder software and download the configuration (PDI files)**.

6. **Stop:** It stops playing the session. It **does not delete the session**.
7. **Speed:** Playing speed can be selected as x0.5, x1, x2, x4 and x8.

Note: This button is only available when reproducing a session.




Fig. 12: Speed button enabled

8. **Display bar:** Click and drag to replay any moment.

3.3 Cloud connection

Cloud connection tab allows the user to connect to a Veronte Autopilot 1x through **LTE network**. This functionality is enabled thanks to the **HSPA+** module (internal or external) embedded in Veronte autopilots.

Note: To activate the internal card or Veronte Cloud data traffic through internet, please contact sales@embention.com. Remember that there is **no internet connection** when **HSPA+ module** is deactivated.


To configure this type of connection, these steps must be followed:

Warning: In order to set up and operate a Veronte Autopilot 1x via Cloud connection, users must **first**:

1. Log in Cloud.
2. Establish a connection to Autopilot 1x that is not through Cloud (*Serial, UDP, TCP-Server* or *TCP-Client*).
3. **Upload** PDIF (configuration) to 1x with the **1x PDI builder** app or with the **Upload PDIFs to cloud** button



This button will work as long as the cloud device is connected and the PDIFs are in the *Ready* state otherwise it will show errors:



Now the users are ready to establish the connection via Cloud and work. If these steps are not followed, Autopilot 1x will be in **PDIF: Failed load** status.

Note: This only needs to be done once per Veronte Autopilot 1x and per configuration.

1. **Login:** After clicking the *Login* button, users must introduce their associated username and password.




Fig. 13: Cloud Connection: Login

Note: Login credentials are automatically assigned. In case they have not been provided to you, please contact the support team by creating a ticket in the customer's Joint Collaboration Framework; for more information, see [Tickets](#) section of the JCF manual or contact sales@embention.com.

2. **Open Cloud connection tab.** Veronte Autopilots 1x linked to user's account should be displayed.




Fig. 14: Cloud Connection: Available devices

The following information is displayed for each autopilot:

- **ID:** Identification number of the autopilot (Serial Number).
- **Last connection:** Indicates the date on which the last connection to that device was established.

3. **Activate the connection** with the desired Autopilot 1x by turning on **the toggle button** displayed next to it.




Fig. 15: Cloud Connection: Connect to an Autopilot 1x

Note: Since Cloud connections are based on **LTE communication**, this connection may not be immediate. The selected autopilot will only be displayed in the 'Devices' tab when it is successfully connected.

4. At this point, **Veronte Link** must have established the connection with the selected Autopilot 1x. Consequently, the autopilot must be displayed in the *Devices* tab.

Note: Since Cloud connections are based on **LTE communication**, **connection may be lost** even when the toggle button is on. In this case, the autopilot will disappear from the 'Devices' tab, appearing again when the connection is retrieved.

5. **Log out:** Click on the username to enable the log out button, and then press it.




Fig. 16: Cloud Connection: Log out

INTEGRATION EXAMPLES

4.1 Serial connection

As the com port configuration is common to all devices, the following steps are applied to MC24 and MC110 controllers as an example.

1. Once **Veronte Link** is installed, the first step that must be done is to set the connection that your MC unit is currently using. By default, every MC is capable to communicate through USB, RS232 and RS485 so any of these can be used (properly adapted to USB/serial).

First, click on “+”:




Fig. 1: Add new connection

2. Besides, it is required to find out which port is employing the MC unit. Windows allows to do that with the **Device Manager** from the **Control Panel**.




Fig. 2: Windows Device Manager

3. Select your COM settings by entering the **Comm Port** previously found. Normally, the other default parameters should not be changed.

New connection

Type *
SERIAL

SERIAL configuration

COM7

Baudrate
115200

Parity
NONE

Flow control
NONE

Data bits
8

Stop bits
1

Cancel Save

Fig. 3: New connection configuration

4. If the selected port is correct and everything went well, a new MC will be displayed in the devices list. However, the *device status* will remain as **PDIF: Waiting to read**.

The user is ready now to start configuring the motor controller using **MC PDI Builder**.




Fig. 4: MC unit correctly connected

More Veronte devices (*MC units, Veronte Autopilots, etc.*) could be added following these instructions.

Note: In case of connecting a Veronte Autopilot 1x, after a few seconds, the *device status* should replace **PDIF: Waiting to read** by **PDIF: Ready**, since **only Autopilot 1x is able to change or load configuration in normal mode.**




Fig. 5: Veronte Autopilot 1x connected and ready

For Veronte devices other than 1x, **PDIF: Waiting to read** should be replaced by the status **PDIF: Not Downloaded**.

4.2 UDP connection

Wi-Fi/Ethernet configuration

The following steps are applied to a **PCS** unit as an example.

Important: If connecting through **Ethernet**, **step 1 does not apply**.

1. The first step is to look under *available networks* for the PCS unit and connect to it.
2. Once the connection is made, enter **Veronte Link** and configure the UDP connection in the **Connection menu**.
First, click on “+”:




Fig. 6: Add new connection

3. Then, the configurable parameters must be entered.

New connection

Type *
UDP

UDP configuration

Address
239.0.0.1

Port
12345

TTL X

Buffer size
300

Cancel Save

Fig. 7: New UDP connection configuration

Important: This address and port are configured for this PCS unit, they do not have to be the same for another device.

4. Finally, if the configured connection is correct and everything went well, a new PCS will appear in the device list and the *device status* will change to **PDIF: Ready**.

The user is ready now to start configuring the PCS using **1x PDI Builder**.




Fig. 8: PCS unit correctly connected

Note: The image of a Veronte Autopilot 1x is displayed and not a PCS as the device that is actually connected is the Autopilot 1x inside the PCS.

4.3 TCP-SERVER connection

Ethernet configuration

The following steps detail how to connect Veronte Link to an Autopilot 1x via a TCP connection to a **Microhard** radio.

Note: In this connection, the **radio** acts as “**Client**” and **Veronte Link** as “**Server**”.

1. Configure, in the Microhard WebUI, the radio as “**TCP Client**” and enter the following parameters:
 - **Remote Server IP Address:** IP address of the PC.
 - **Remote Server port:** TCP port to which the radio has to connect. It must be the same as the one configured in Veronte Link.

For more information on the radio configuration, users can refer to the [Microhard radio configuration - Integration examples](#) section of the **1x Hardware Manual** or directly to the Microhard radio documentation.

2. Connect **Veronte Autopilot 1x** to the Microhard radio via **RS232** as detailed in the [Microhard pDDL900-ENC external - Integration examples](#) section of the **1x Hardware Manual**.

3. Once the configuration and connection is done, open **Veronte Link** and configure the **TCP-SERVER** connection in the **Connection menu**.

First, click on “+”:





Fig. 9: Add new connection

4. Then, the configurable parameters must be entered.



New connection

Type *
TCP-SERVER

TCP-SERVER configuration

Port
20002

Buffer size
300

Cancel Save

Fig. 10: New TCP-SERVER connection configuration

- **Port:** Enter a TCP port to which the radio will be connected, the same as the one previously configured as “Remote Server port” in the radio configuration.
5. Finally, if the configured connection is correct and everything went well, a new Autopilot 1x will appear in the Devices list. It should look like this:




Fig. 11: 1x unit correctly connected

4.4 TCP-CLIENT connection

Ethernet configuration

The following steps detail how to connect Veronte Link to an Autopilot 1x via a TCP connection to a **Microhard** radio.

Note: In this connection, the **radio** acts as “**Server**” and **Veronte Link** as “**Client**”.

1. Configure, in the Microhard WebUI, the radio as “**TCP Server**” and enter a “**Local Listening Port**” to which Veronte Link will have to connect (usually the default one is used).

For more information on the radio configuration, users can refer to the [Microhard radio configuration - Integration examples](#) section of the **1x Hardware Manual** or directly to the Microhard radio documentation.

2. Connect **Veronte Autopilot 1x** to the Microhard radio via **RS232** as detailed in the [Microhard pDDL900-ENC external - Integration examples](#) section of the **1x Hardware Manual**.
3. Once the configuration and connection is done, open **Veronte Link** and configure the **TCP-CLIENT** connection in the **Connection menu**.

First, click on “+”:




Fig. 12: Add new connection

4. Then, the configurable parameters must be entered.

New connection

Type *
TCP-CLIENT

TCP-CLIENT configuration

Address
192.168.168.1

Port
20002

Buffer size
300

Cancel Save

Fig. 13: New TCP-CLIENT connection configuration

- **Address:** IP address of the radio.
- **Port:** Enter as TCP port the “Local Listening Port” previously set in the radio configuration.

Important: This address and port are configured for this radio unit, they do not have to be the same for another device.

5. Finally, if the configured connection is correct and everything went well, a new Autopilot 1x will appear in the Devices list. It should look something like this:




Fig. 14: 1x unit correctly connected

TROUBLESHOOTING

In case of any software error, it is possible to extract and analyze files from session folder.

Warning: Do not modify or delete manually any **Veronte Link** file. Copy them to a different path to send or analyze.

Veronte Link files are placed on the following paths:

- C:\Users\USER NAME\AppData\Roaming\VeronteLink\configurables Device configurations.
- C:\Users\USER NAME\AppData\Roaming\VeronteLink\sessions Session files, it includes flights information.
- C:\Users\USER NAME\AppData\Roaming\VeronteLink\tracelogs Event logs, it includes flights information.
- C:\Users\USER NAME\AppData\Roaming\VeronteLink ⇒ cfg.son **Veronte Link** connections configuration file. **If deleted, the configuration will be lost.**
- C:\Users\USER NAME\AppData\Roaming\VeronteLink ⇒ vlink.lock Internal file that only appears if any instance of **Veronte Link** is open. **If deleted, there will be instability in the system.**

5.1 Comm Port error in Windows Device Manager

If the following Windows Comm Port error occurs:





Fig. 1: Windows Device Manager - Comm Port error

Users must extend the disconnection time to 5 seconds to fix it. To do this:

1. Go to the **Connection** menu → click on the  icon to open the COM configuration.
2. Open the **Advanced** parameters drop down menu → modify the **Disconnect time** to **5 seconds**.




Fig. 2: Connection configuration - Disconnect time

If the user is still having problems with this, please contact the support team by creating a ticket in the customer's **Joint Collaboration Framework**; for more information, see [Tickets](#) section of the JCF manual.

5.2 Error when replaying a session

If the following error message appears when attempting to replay a session:




Fig. 3: Error message

It is often due to users trying to replay a previous session from the device that is **currently connected**, which is not possible as indicated in the *Sessions* section.

5.3 Viewing UDP data

An application such as Wireshark can be used to visualize raw data sent from Autopilot 1x. Nonetheless, at the beginning, it may show characters that do not come from 1x, because Wireshark reads all data from the connected port, including protocol information.

To distinguish 1x messages, the user has to search the matcher *0x0A 0xA0* for **Veronte UDP Telemetry CLI**. The matcher indicates the beginning of the data. In the following example, characters marked with blue correspond to 1x, while yellow characters are the UDP protocol structure.

0000	02 00 00 00 45 00 00 36 04 9e 00 00 80 11 00 00E..6.....
0010	7f 00 00 01 7f 00 00 01 fa 54 0b b8 00 22 ea 00T.....
0020	0a a0 f9 f9 0d 00 00 00 00 00 00 00 00 00 00
0030	00 00 00 00 00 00 00 00 00 00

Fig. 4: Distinguished data on Wireshark

SOFTWARE CHANGELOG

This section presents the changes between the previous software version (**v.6.14.28**) and the current (**v.6.14.55**).

Added

- *Buffer size* configuration parameter for UDP/TCP connections
- Button to upload the device's PDIFs to the cloud (*Upload PDIFs to cloud*)
- Show UDP port in the Connection tab