Veronte Ops

Release 6.8

Embention

2023-10-04

CONTENTS

1	Quic	Start	3
	1.1	System requirements	3
		1.1.1 Minimum	3
		1.1.2 Recommended	3
	1.2	Compatible browsers	4
	1.3	First Steps	4
2	Addi	ional apps	7
-	2.1	Veronte Terrain Provider	7
		2.1.1 Download	7
		2.1.2 Installation	, 7
		2.1.2 Installation 2.1.3 Configuration	8
		2.1.6 Operation Op	8
	2.2	Web Converter	9
	2.2	2.2.1 Download	9
			10
			10
			11
3	Pane		13
	3.1		14
			14
			14
		1 I	18
			18
			19
		3.1.1.2.3 Status bar settings	19
		3.1.1.2.4 Setup	24
		3.1.1.2.5 Terms and Conditions	38
		3.1.2 Feedback menu	38
		3.1.3 Background configuration	40
		3.1.4 Platform icon	44
	3.2	Mission	52
		3.2.1 Operation	56
			56
		3.2.1.2 Segment	53
		3.2.1.3 Orbit	56
			59
			72
		50	74

5	Trou	bleshoo	20 sting	61
4	Integ 4.1 4.2	Gimba	Examples 25	55
			3.5.2.2.6 Flight instruments	
			3.5.2.2.5 Inputs	
			3.5.2.2.4 Statics	
			3.5.2.2.3 Charts	
			3.5.2.2.2 Displays	-
			3.5.2.2 Wildgets	
			3.5.2.1 Workspaces	
		5.5.4	3.5.2.1 Workspaces	
		3.5.2	Workspace toolbar	
	5.5	3.5.1	Map options	
	3.5	Works		
		3.4.3	Platform list	
		3.4.1	Platform actions	
	5.4	3.4.1	Platform connection status	
	3.4		Operation actions 1 'm 12	
		3.3.2 3.3.3	Operations 12 Operation actions 13	
		320	3.3.1.2.3 Advanced Calibration	
			3.3.1.2.2 Wind Calibration	
			3.3.1.2.1 Calibrate Atmosphere	
			3.3.1.2 Calibrations	
			3.3.1.1.7 Spots	
			3.3.1.1.6 Runways	
			3.3.1.1.5 Marks	
			3.3.1.1.4 Patches	
			3.3.1.1.3 Areas	
			3.3.1.1.2 Custom Points	
			3.3.1.1.1 Operation Variables	
			3.3.1.1 Customize	
		3.3.1	Operation panel	
	3.3		tion	
		3.2.5	Settings	
			3.2.4.3 Remove tiles	
			3.2.4.2 Save tiles	
		5.4.4		98 98
		3.2.4	1	90 98
			1	95 98
		3.2.3		95 95
		2 2 2		93 05
		3.2.2		93
				93
				92
				91
			1	87
				81
				79
			3.2.1.7 Spot	77

5.1	Connecting to Veronte Link	261
5.2	Error when changing phase	263
5.3	Navigation does not start	264



Veronte Ops is the application employed to operate Veronte Autopilots.

CHAPTER

QUICK START

Veronte Ops is a website application for the operation and monitoring of the vehicle during the mission.

Veronte Ops includes:

- **Telecommand**: Support for all synchronous operator control commands that can be sent to the flight segment, e.g. operational mode switch, mission management, payload control.
- **Mission design**: Configuration of user-defined, pre-defined mapping and launch missions, as well as in-flight mission editing.
- **Operation parameters**: Configuration of operation parameters, such as theirs values, positions and directions, which may vary depending on the mission and during the mission.
- Workspace: User can get feedback on autopilot variables and status through widgets.
- Multiple users: One or more operators can work simultaneously.

1.1 System requirements

Before executing this software, users should check the following sections with the minimum and recommended PC hardware requirements.

1.1.1 Minimum

- CPU: Intel Core i5-8365UE
- **RAM**: 8 GB DDR4
- STO: 256 GB SSD

1.1.2 Recommended

- CPU: Intel Core i5-1235U (10C/DecaCore 1.3 / 4.4GHz, 10MB)
- RAM: 8 GB DDR4
- STO: 512 GB SSD M.2 NVMe PCIe

1.2 Compatible browsers

The following are the functional, optional and unsupported browsers for used with Veronte Ops software:

Functional

- Google Chrome: version 85 Q2 2020
- Edge (Chromium): Q1 2020

Optional

- Opera (Chromium): latest
- Safari: version 12

Unsupported

- Edge not based on Chromium
- Firefox

1.3 First Steps

- To access this application simply click on the following link: https://v68-vapp.embention.net/
- Users can work with it from the **browser** or **download** it to the PC.

- Browser




Fig. 1: Download Veronte Ops

- Installed in PC



Fig. 2: Veronte Ops in PC




Fig. 3: Uninstall/Open in browse Veronte Ops

• As it is a web application, **updates** will be done on their own and will appear as a **changelog** in the application.

CHAPTER

TWO

ADDITIONAL APPS

2.1 Veronte Terrain Provider



Fig. 1: Veronte Terrain Provider

Veronte Terrain Provider is an additional application that provides SRTM terrain data to Veronte Ops.

Thanks to this, Veronte Ops allows the user to visualize terrain heights on the created route. This makes it possible to foresee possible collisions of the aircraft with the terrain along the route.

2.1.1 Download

Once the **Veronte Autopilot 1x** has been purchased, a GitHub release should be created for the customer with the application.

To access to the release and download the software, read the Releases section of the **Joint Collaboration Framework** user manual.

2.1.2 Installation

To install Veronte Terrain Provider on Windows just execute "VeronteTerrainProvider.exe" and follow the indications of the setup wizard.

Warning: If users have any problems with the installation, please disable the antivirus and the Windows firewall. Disabling the antivirus depends on the antivirus software.

To disable the firewall, go to "Control Panel" \rightarrow "System and Security" \rightarrow "Windows Defender Firewall" and then, click on "Turn windows Defender Firewall on or off".

📽 Windows Defender Firewall		- 🗆 X			
← → × ↑ 📽 « System an	ad Security > Windows Defender Firewall v 🕐 Search Control Panel	م			
Control Panel Home Allow an app or feature through Windows Defender	Help protect your PC with Windows Defender Firewall Windows Defender Firewall can help to prevent hackers or malicious software from gaining access to your PC through the Internet or a network.				
Firewall Change notification settings	Private networks Connected 📀				
Turn Windows Defender Firewall on or off	Guest or public networks Not connected 📀				
Restore defaults					
Advanced settings					
Troubleshoot my network					
Fig. 2: Windows Defender Firewall					

2.1.3 Configuration

It is possible to import external hgt files, which contain terrain information, and use them for mission preparations. These files follow the SRTM (Shuttle Radar Topography Mission) standard, with 3 arc-seconds (approximately 90 meters) of resolution. To import one of them, simply copy it into the directory:

C:\Users\user\AppData\Roaming\VeronteTerrainProvider\terrainprovider

Each hgt contains terrain information about one area of the world. The following image shows how these areas are distibuted, so each cell corresponds to one hgt:




Fig. 3: Terrain information distribution

2.1.4 Operation

Once installed, users just need to run it. When it runs, it will always remain open in the background, which users can check in the PC's Windows taskbar.



Fig. 4: Veronte Terrain Provider in task bar

It is **only necessary to run it the first time it is used**, then it should **always remain open** so that when the computer is switched on, it starts up as well.

Note: If users close it, i.e. remove it from the taskbar, just run it again to start it.

2.2 Web Converter



Fig. 5: Web Converter

Web Converter is a tool able to receive video in RTSP and serve it in webRTC and/or receive udp messages and send them via websocket.

Veronte Ops needs this application to visualize video and to work with udp content after it has been converted to websocket.

Therefore, it must be used when working with **gimbals** to visualize their video and click on them to send the **tracking command** to an object.

2.2.1 Download

Once **Veronte Autopilot 1x** has been purchased, a GitHub release should be created for the customer with the application.

To access to the release and download the software, read the Releases section of the **Joint Collaboration Framework** user manual.

2.2.2 Installation

To install Web Converter on Windows just execute "WebConverter.msi" and follow the indications of the setup wizard.

Warning: If users have any problems with the installation, please disable the antivirus and the Windows firewall. Disabling the antivirus depends on the antivirus software. click on "Turn windows Defender Firewall on or off". 📽 Windows Defender Firewall _ Х ン Search Control Pane م Help protect your PC with Windows Defender Firewall Control Panel Home Windows Defender Firewall can help to prevent hackers or malicious software from gaining access to your PC Allow an app or feature through the Internet or a network through Windows Defender Firewall Private networks Connected 🔗 Change notification settings 💡 Turn Windows Defender Not connected \odot Guest or public networks Firewall on or off Restore defaults Advanced settings Troubleshoot my network Fig. 6: Windows Defender Firewall

2.2.3 Configuration

Once the Web Converter software is downloaded and installed, configure it.

The configuration of this application is simply a config.json file with parameters for video display and command that need to be modified:

```
{
  "server": {
    "http_port": ":8083",
    "ice_servers": ["stun:stun.l.google.com:19302"]
 },
  "streams": {
    "veronte_Gimbal_Camera": {
      "on_demand": false,
      "url": "rtsp://192.168.8.94/net0"
    }
  },
  "udp_config": {
    "ip": "192.168.8.94",
    "port": 14003,
    "websocket_url": "localhost",
    "websocket_port": "1997"
  }
}
```

• server Users can modified the localhost port (*http_port*).

The generated URL will look like this: http://localhost"http_port"

- streams Parameters to modify to view the video recording of the desired camera in Veronte Ops
 - "camera name": Is to identify the gimbal camera. By default veronte_Gimbal_Camera is set.
 - As the user can enter as many cameras to display the video as desired, each gimbal camera is configured here:
 - * url: URL of the gimbal video. This is just an example, the URL (rtsp) depends on the user's gimbal.
- udp_config To command from Veronte Ops to the gimbal. Set the following parameters:
 - ip: IP address configured as the udp connection of the camera.
 - port: Port configured as the udp connection of the camera.
 - websocket_url: Websocket URL to which users want to send the converted udp messages.
 - websocket_port: Websocket port to which users want to send the converted udp messages.

Note: Even if users only want to view the video recording in **Veronte Ops**, they can leave the default configuration parameters of **upd_config**, as they do not affect the video configuration.

However, they can also remove these lines from the configuration if they wish.

2.2.4 Operation

Once the **Web Converter** application has been configured according to the user's needs, follow the steps below to work with:

- 1. Just run the application and always keep it open.
- 2. Copy the link generated by the tool into the corresponding Veronte Ops configuration:
 - For video recording, copy the URL generated into the *Iframe widget*.

For example, with the default http_port, the URL generated will be: http://localhost:8083.

• For **command**, the user must copy the **websocket_url** and **websocket_port** previously configured into the **URL** and **Port** fields, respectively, of the **WebSocket** connection configuration of the *Gimbal panel*.

CHAPTER

THREE

PANELS



Panels on Veronte Ops are distributed as shown in the following figure:

Fig. 1: Veronte Ops panels

- 1. Veronte Ops configuration: Edit Veronte Ops settings.
- 2. *Mission*: Create and edit missions.
- 3. *Operation*: Edit **operations** defined in 1x PDI Builder and perform **calibrations**.
- 4. *Platform*: Veronte Autopilot information.
- 5. *Workspace*: Customize everything related to the Veronte Ops workspace, such as telemetry (widgets), map and workspace settings.

These panels are described in detail in the following sections.

3.1 Veronte Ops configuration

This section describes all the menus, options and actions that allow the user to **modify the configuration and appearance** of this application. These are:

- Status bar
- Feedback menu
- Background configuration
- Platform icon

3.1.1 Status bar

In the status bar, the user can view mission and operation relevant information, as well as modify general Veronte Ops settings.



Fig. 2: Status bar

This bar is divided into 3 'parts':

• Status bar items: Clock, Weather and Platform selected information items are grouped here.

The user can choose to show/hide each of these elements from the Status bar settings.

By default, the clock and the selected platform are shown, as can be seen in the image above.

- Notifications: Veronte Ops notifications for users. This is always displayed in the status bar.
- *More options*: By clicking on this drop-down menu, users will find options for configuring this application and its appearance.

3.1.1.1 Notifications

Veronte Ops will notify the user of any changes made with notifications (visual and audible, the latter is optional), as shown in the figure below:

🖃 i 👻	
Notifications	× \$
INFO OPERATION	3/16/23,
Nothing to Save in Veronte PCS	11:36 AM
INFO OPERATION	3/16/23,
Configuration Saved in Veronte PCS	11:34 AM
INFO OPERATION	3/16/23,
Configuration Saved in Veronte PCS	11:29 AM
INFO OPERATION	3/16/23,
Configuration Saved in PCS LINE	11:26 AM
INFO OPERATION	3/16/23,
Configuration Saved in PCS LINE	11:26 AM
INFO UAV: PCS LINE	3/16/23,
Uav PCS LINE connected	11:25 AM
INFO UAV: VERONTE GROUND	3/15/23,
Uav VERONTE GROUND connected	4:20 PM
INFO OPERATION	3/14/23,
Configuration Saved in M600	12:38 PM
INFO OPERATION	3/14/23,
Configuration Saved in M600	10:56 AM
(INFO) UAV: M600	3/14/23,
Uav M600 connected	10:55 AM
☐ Show more notifications	

Fig. 3: Notifications menu

In addition, notifications are classified into 3 groups (**Information**, **Warning** and **Error**) with a colour code (**blue**, **orange** and **red** respectively):




Fig. 4: Notifications menu - Classification

These notifications can be **marked as read** by clicking on the \checkmark icon at the top of this menu. So, they will no longer be displayed in this menu.





Fig. 5: Notifications readed

However, if the user wishes to consult them, simply clik on '**Show more notification...**' and a new window will appear with the entire history of notifications. Here the user can search for notifications or delete them:

Notifications						×
		Search		×		
Level	Message			Origin	Time	
INFO				OPERATION	3/16/23, 10:28 AM	
INFO				OPERATION	3/16/23, 10:09 AM	
WARN				OPERATION	3/16/23, 10:09 AM	
INFO				UAV: M400 - PDI	3/16/23, 10:07 AM	
INFO				UAV: M400 - PDI	3/16/23, 10:06 AM	
				ltems per page: 5 👻	1 – 5 of 89	> >I



Besides, in the notification configuration users can choose, to some degree, which groups of notifications are shown or not. This is to a certain degree because, as the classification described above has been defined according to importance, **error notifications will always be shown** (as they are the most important ones) but warning and information notifications can be chosen to be seen/heard or not.

To access it, simply click on the ⁽²⁾ icon at the top of this menu:

\$	®	
3 11	Max level visual	
3,	INFO WARN	ERROR
11		
3 10	Max level voice	¢
	INFO-WARN-	ERROR

Fig. 7: Notifications menu - Configuration

Besides, the user can also choose the language of the sound notifications by clicking on the settings icon:




Fig. 8: Sound notifications language

Below is an example of how to customize the notification settings:

Fig. 9: Modified notifications

3.1.1.2 More options

Moreover, by clicking on the drop-down menu on the right, users will find more options, such as:

- Changelog
- *Light/Dark mode*
- Status bar settings
- Setup
- Terms and Conditions




Fig. 10: Drop-down menu

3.1.1.2.1 Changelog

Users can consult the changelog, which shows all updates made to the application.




Fig. 11: Changelog

3.1.1.2.2 Light/Dark mode

Change the interface display mode: Light/Dark mode.

Fig. 12: Light/Dark mode

3.1.1.2.3 Status bar settings

This menu allows the user to enable/disable the information items in the status bar.

Note: To save any changes, click the "Save" button in the bottom right corner of the menu.

• Weather

This option will only be **available** if the user has **geolocation enabled**, i.e. the browser has permissions to use the user's geolocation.

In order to do this:




Fig. 13: Weather section - Enable geolocation




Fig. 14: Weather section

• Clock

It is possible to customize the timezone where users are working.

Status bar settings	
🕒 🌣 Weather	10:53:48
Clock	Europe/Madrid
C 🖉 🖉 Platform selec	Africa/Abidjan
	Africa/Accra
	Africa/Addis_Ababa
	Africa/Algiers
	Africa/Asmara
	× Cancel Save

Fig. 15: Clock section


• Platform selected

This element informs the user whether a Veronte Autopilot 1x is **not connected**, **connected**, **disconnected** or **in maintenance mode**, and the name of this device.

Status bar settings		
🔵 🖉 🌾 Weather		
Clock		
Contraction and Contraction an		
	This item has no form	
		× Cancel Save

Fig. 16: Platform selected section

The figures below show all 1x autopilot states:



- Disconnected:



Fig. 20: Platform selected - Autopilot disconnected

3.1.1.2.4 Setup

This menu allows to edit the general settings of Veronte Ops:

Setup			
🕅 Map settings	Veronte terrain provider	localhost	~
Unit settings	Preferences		~
🖉 Veronte Link Host	AGL		~
🐺 Style manager			
Workspace manager			
Operation manager Gimbal panel			
🛧 Import 🛛 🛓 Export			× Close

Fig. 21: Status bar - Setup

Note: Clicking the 'Close' button, in the bottom right corner of the menu, will close this window and save any changes made.

• Map settings

In this menu, it is possible to edit the terrain data settings, such as:

- Veronte Ops **SRTM data provider**: By default, this is the additional application *Veronte terrain provider*, but users can enter another SRTM data provider that is on the PC.

Setup			
🕪 Map settings	Veronte terrain provider	localhost	^
Unit settings	- Host		
🔗 Veronte Link Host	localhost		
🚆 Style manager	Check success.		
Workspace manager	Preferences		~
Operation manager	AGL		
🗟 Gimbal panel	AGL		~
🛧 Import 🛛 🛓 Export			× Close

Fig. 22: Map settings section - Veronte terrain provider

- Preferences

Users can customize the coordinates and height units of the map.

Setup						
🕅 Map settings	Veronte terrain provider	localhost	~			
Unit settings						
🖉 Veronte Link Host	Preferences		^			
🚆 Style manager	Coordinate Decimal degrees		•			
Workspace manager						
Operation manager	m	-	•			
🗟 Gimbal panel						
	AGL		~			
1. Import 🛓 Export			× Close			

Fig. 23: Map settings section - Preferences

- * Coordinate: Select the units of the coordinates. The available options are Decimal degress, Degrees, UTM and MGRS.
- * **Unit**: It is possible to select the units of the height from the drop-down menu.

- AGL

Setup			
Map settings	Veronte terrain provider	localhost	~
Unit settings	Preferences		~
🔗 Veronte Link Host			
🖷 Style manager	AGL		^
Workspace manager	Default waypoint	30.0 m	~
Operation manager			
🙆 Gimbal panel	Warning Threshold	10.0 m	^
	AGL		
	10		
<u>↑</u> Import 🛃 Export			× Close

Fig. 24: Map settings section - AGL

- * **Default waypoints**: Enter the default altitude, in AGL, of the waypoints created.
- * Warning Threshold: It is possible to add a warning threshold to avoid collision with terrain. This will appear as a line when users open the 'elevations' option in the created route.

For example, if the warning threshold is set to 10 metres, a **red warning line** will be drawn in the 'elevations' menu **10 metres above each terrain point**.

Also, if the **mission path intersects this line**, Veronte Ops will interpret this as the route **colliding** with the terrain:



Fig. 25: Map settings section - Warning

• Unit settings

This panel shows all the system units available for the system variables.

They are sorted by variable type in alphabetical order: acceleration, temperature, velocity, etc.

Setup		
🕅 Map settings	Search	×
Unit settings		
🖉 Veronte Link Host	Acceleration	m/s ² T
🗒 Style manager		
Workspace manager	Angle	•[0,360] 🗸
Operation manager		
💿 Gimbal panel	Angular Acceleration	rad/s² 🗸
		Units
	Angular Velocity	rad/s
		Units
🛧 Import 🛛 🕁 Export		× Close

Fig. 26: Unit settings section

The following table shows all the units available in Veronte Ops:

Variable Type	Units
Acceleration	$[m/s^2]$ [ft/s ²] [in/s ²] [g]
Angle	rad[-;] °[-180;180] °[0;360] [° ' "] [rad] rad[0;2] °
Angular Acceleration	[rpm/s] [rad/s ²] [rad/m ²] [rad/h ²] [$^{\circ}$ /s ²] [$^{\circ}$ /m ²] [$^{\circ}$ /h ²]
Angular Velocity	[rad/s] [rad/m] [rad/h] [rps] [rpm] [rph] [°/s]
Area	$[m^2] [cm^2] [mm^2] [km^2] [mile^2] [ft^2] [yd^2]$
Baudrate	[Bd] [kBd] [MBd]
Centimeters/Pixels	[cm/pixel]
Current	[A] [mA]
Data	[bit] [byte] [KB] [GB] [bytes/s]
Decibel	[dB]
Density	[kg/m ³]
Flow Rate	[m ³ /s] [gal/s] [gal/h] [l/s] [l/h]
Force	[N] [kN] [lbf] [pdl]
Frequency	[Hz] [mHz] [kHz]
Jerk	[m/s ³]
Length	[m] [km] [mi] [NM] [yd] [ft] [in] [cm] [mm]
Magfield Variance	[T ²]
Magnetic Flux Density	[T] [mG] [gauss] [nT]
Mass	[kg] [g] [tonnes] [lbs] [oz]
	aantinuga on novt naga

continues on next page


Variable Type	Units
Numeral System	[bin] [octal] [dec] [hex]
Percentage	[x1] [%]
Power	[W] [kW] [Kgm/s] [erg/s] [CV]
Pressure	[Pa] [kPa] [bar] [mbar] [psi] [mmHg] [at] [atm]
Pressure Square Error Rate	[Pa ² /s]
Pressure Variance	$[Pa^2]$
Resistence	[]
Temperature	[K] [°C] [°F]
Time	[s] [min] [h] [s] [ms] [Time]
Transfer	[pkts/s]
Velocity	[m/s] [kt] [km/h] [mph] [ft/s] [mm/s] [ft/m]
Velocity Variance	$[(m/s)^2] [(cm/s)^2] [(mm/s)^2]$
Voltage	[V] [mV]
Volume	$[m^3] [dm^3] [mm^3] [L] [mL]$

Table	1	- continued	from	previous	page
-------	---	-------------	------	----------	------

Veronte Link Host

As Veronte Link is the Embention application that stores, reads and manages all the configurables of the products, the user can choose which Veronte Link to use to access the data, to access certain products.

By default, the IP address 'localhost' is set, which is the Veronte Link on the same PC as Veronte Ops. However, it is also possible to connect Veronte Ops to a Veronte Link running on a different computer, simply by entering the IP address of that computer, so Veronte Ops will be able to access the devices connected to it.





In the image above, users can identify:

- 1. The local IP: 'localhost'
- 2. The IP address of another computer
- 3. Add a new VLink Host: It is possible to have access to several Veronte Link and therefore multiple users can manage the same Veronte Link, the same products.

If the user has any problems when trying to connect Veronte Ops to Veronte Link, see *Troubleshooting section* -> *Connecting to Veronte Link* of this manual.

• Style manager

This section allows the user to import and export custom widget styles.

Setup	
🛍 Map settings	Style I/O
Unit settings	<u>↑</u> Import styles Export all styles
🔗 Veronte Link Host	
🐺 Style manager	
Workspace manager	
Operation manager	
🗟 Gimbal panel	
🛧 Import 🛛 🛓 Export	× Close

Fig. 28: Style manager section

- Import styles: By clicking here, users can import custom styles as a zip folder or by directly selecting all desired custom styles .css files.

When the styles are imported, a notification will appear:




Fig. 29: Style manager section - Import notification

- Export all styles: By clicking here, all custom styles will be exported as a zip folder:




Fig. 30: Style manager section - Export

Note:	Default	widget	styles	will	not	be	exported.
1000	Dellault	winger	Styles	** 111	not	υc	capor icu.

The zip folder will contain all the .css files with custom styles for the different widgets, a metadata.json file and a README file:

<mark></mark>	
# 0_Label_blue.css	
# 0_Large_pink.css	
# 6_Default_box_blur_copy.css	
# 6_Default_box_copy.css	
# 7_Large_pink.css	
# 7_Large_pink_copy.css	
🕛 metadata.json	
README.md	

Fig. 31: Style manager section - Exported files

* metadata.json file: This file contains the IDs of the styles that are assigned to the workspaces.

Danger: It is advisable **not to modify** this file.

* **README** file: Pay special attention to this file to find out how to create or modify a style.

Workspace manager

From this panel users can **delete** one, several or all **workspaces** created.

To do this, simply select the workspaces to be deleted and then click on the 'Delete' button.

Setup	
Map settings	Items selected: 0
Ø Veronte Link Host	Name
🐺 Style manager	Default
I Workspace manager	Flight tests
Operation manager Gimbal panel	Stick testing
	Testing servos
	ltems per page: 10 🔻 1 − 4 of 4
1. Import 🛓 Export	× Close

Fig. 32: Workspace manager section

• Operation manager

From this panel users can **delete** one, several or all **operations** created.

To do this, simply **select** the **operations** to be deleted and then click on the '**Delete**' button.

Setup	
🔟 Map settings	Items selected: 0
Unit settings	
🔗 Veronte Link Host	Name Name
🐺 Style manager	Empty operation
I Workspace manager	M400 operation 1
Operation manager	M400 operation 2
Gimbal panel	M600 operation
	ltems per page: 10 🔻 1 − 4 of 4
1. Import 🛓 Export	× Close

Fig. 33: Operation manager section

• Gimbal panel

Users can add a predefined gimbal from this panel:

Setup					
🕅 Map settings	Name	Model	Platform Address	Connection	+
Unit settings					
Ø Veronte Link Host					
🐺 Style manager					
Workspace manager					
Operation manager					
🗟 Gimbal panel					
🛧 Import 🔺 Export					× Close

Fig. 34: Gimbal panel section

Clicking the **+** icon displays the following configuration panel to add a new gimbal:

Create gimbal	
Models * 👻	
Name Gimbal *	Choose Platform *
Connections *	
	Cancel

Fig. 35: Gimbal panel section - Create gimbal

- Models: Select a gimbal model from the list.
- Name Gimbal: Enter the desired name for the gimbal to be added.
- Choose Platform: Users must select the platform for which the gimbal is configured.

The available options will always be the IDs of the connected autopilots 1x and 'Selected platform', i.e. the platform that is selected.

- **Connections**: The type of connection through which Veronte Ops sends commands to the gimbal must be selected:
 - * Veronte Tunnel: When choosing this connection type, Veronte Autopilot 1x tunnel is used to send commands to the gimbal.

Users must also specify the Veronte tunnel port used: 1, 2 or 3.

Warning: Be careful! This port must match the Tunnel port configured in the **1x PDI Builder** software.

- * WebSocket: In order to send commands via the *Web Converter application*, it is required to enter the websocket_url configured in that tool in the URL field and copy the websocket_port configured as the camera's udp connection in the **port** field.
- Advanced: Depending on the gimbal model chosen, some additional options can be configured which are characteristic of each gimbal.

Note: This option will only appear after the selection of the gimbal model.

Then, the created gimbal will appear on the panel:

Setup					
Map settings	Name	Model	Platform Address	Connection	+
Unit settings					ß
Ø∕ Veronte Link Host	NextVision Gimbal	NextVision Trip2/Trip5	1631	Veronte Tunnel	
🐺 Style manager					
Workspace manager					
Operation manager					
🙆 Gimbal panel					
<u>↑,</u> Import <u>↓,</u> Export					× Close

Fig. 36: Gimbal panel section - Gimbal added

Edit gimbal: Allows the user to access again to the configuration menu described above.

Remove Gimbal: Removes this gimbal.

• Import/Export buttons

Furthermore, all these settings can be **exported and imported** from one Veronte Ops to another, for example to move them from one PC to another.

When the user tries to import a new Veronte Ops configuration, the following confirmation message will appear:




Fig. 37: Import Veronte Ops configuration

3.1.1.2.5 Terms and Conditions

Users can consult the 'End User License Agreement (EULA)' by simply clicking on this button.

3.1.2 Feedback menu




Fig. 38: Feedback button

Press the button above to access the Feedback menu:




Fig. 39: Feedback menu

Users can report a problem they have encountered by creating an issue in their own 'Joint Collaboration Framework'

Note: The user's 'Joint Collaboration Framework' is simply a own Github repository for each customer.

In case of having any question about this Joint Collaboration Framework, please read its user manual.

It is also possible to take a snapshot or a recording of that problem.

Clicking on the **'Download' button** downloads a zipped folder with the data of the workspace, the operation and other data to easily identify the problem. It is advisable to attach this folder when creating the issue.

Finally, by clicking on the **'Send' button**, a Github window will open in the browser with an issue. This issue is created in the repository indicated before with the title that has been defined.

Find below an **example** of the creation of a feedback:




Fig. 40: Feedback example - Feedback menu

O New Issue - embention/Vilbs × +	~ - 🗆 X
C a github.com/embention/Vlibs/issues/new?title=feedback&labels=PR%2CSoftware%2CVeronteApp%2CSupport&template=VeronteApp.yml	🖻 🖈 🗟 🔗 🗰 🖬 🕴
Embention	»
Search or jump to Pull requests Issues Codespaces Marketplace Explore	₽ +• ••
A embention / Vibs = / Management ≎ (Private)	\textcircled{O} Watch 1 \checkmark \textcircled{O} Fork 0 \checkmark \checkmark \fbox{M} Star 2 \checkmark
<> Code 🗿 Issues 456 👖 Pull requests 20 🗰 Zenhub 💿 Actions 🖽 Projects 9 🖽 Wiki 🛈 Security 🗠 Insights	
feedback	Pipelines
WritePreviewHBII <th< td=""><td></td></th<>	
Leave a comment	Assignees 🚯
	No one—assign yourself
	Labels 🚱
	PR Software Support
	/ Projects
Attach files by dragging & dropping, selecting or pasting them.	None yet
Styling with Markdown is supported Create an epic	Sprints 28
(3) Remember, contributions to this repository should follow our GitHub Community Guidelines.	No sprint assigned
	Milestone 💱
	No milestone

Fig. 41: Feedback example - Issue created in Github

3.1.3 Background configuration

It is possible to edit the background behind the map. To access this editing menu it is necessary to first **minimize the map** (or hide it) and then **right click on the background**:

Fig. 42: Access background edition

In this menu, users will find:

	Widget creator	
	Widget Options Frequency (milliseconds) 100	
	Color Image	
	Image:	
	<u> </u>	
	◯ Auto	
	Over	
	O Contain	
	Repeat:	
	No repeat	
peration	✓ Accept	

Fig. 43: Background edition

- 1. Widget options: The user can change the refresh frequency of the workspace, of the widgets. By default this frequency is 100 miliseconds.
- 2. Background options: Choose the type of background style between a color or an image:
 - Color: Users can select the desired color for the background.

*	Widge	et creator	×
1	Widget Options		
	Frequency (milliseconds)		
	Color Ima	ge	
	Color picker		
		✓ Accept	

Fig. 44: Background - Color

• Image: When choosing 'Image', users must configure some parameters:

÷		Widget creator	× ×
	Color	Image	
	Image:		
	▲ Import Image		1
	Size:		
	🔿 Auto		
	Cover		
	Contain		
	Repeat:		
	💿 No repeat		
	O Repeat		
	O Repeat X		
	O Repeat Y		
	\sim -		
			✓ Accept

Fig. 45: Background - Image

- **Image**: A Veronte Ops image is set by default, but it is possible to import another image from the local PC.
- Size: The size of the background can be modified, the available options are: Auto, Cover and Contain.
- **Repeat**: The repetition of the image can also be customized, choose from: *No repeat, Repeat, Repeat X, Repeat Y, Space* and *Round*.

3.1.4 Platform icon

This icon allows the user to locate and follow the position of the platform at any time during the operation.

By right-clicking on it, users will access its options:





Fig. 46: Platform icon options

- Follow: Keeps the platform always centered on the map during operation.
- Settings: Users will access to the settings menu:





- Set icon: Users can customize the icon that will be used to represent the position of this unit on the map. Simply choose one of the default icons or upload one from the laptop.




Fig. 48: Platform icon settings - Set icon

- Set tooltip: Allows the user to display a variable next to the platform icon.




Fig. 49: Platform icon settings - Set tooltip

The following parameters must be configure by clicking on 'Add new var':

Set Tooltip M400		
		Items: 1 + Add new var
No selected		^
VRef *	fa-chevron-right	> Persistent
		× Delete
		Cancel Save

Fig. 50: Platform icon settings - Set tooltip configuration

- * **VRef**: Select the desired variable to be displayed.
- * **Unit** and **Decimals**: The units and decimals can also be modified. These parameters will appear depending on the variable chosen.
- * Icon: Choose the icon to be shown next to the variable.
- * **Persistent**: When **enabled**, this *tooltip* will **remain displayed during the operation**. **Otherwise**, it will **only** appear **when clicking** on the icon.

Set Tooltip M400			
		Items: 2 + Add n	ew var
MSL (Height Above Mean Sea Level) - Altitude			^
MSL (Height Above Mean Sea Level)	Decimals	fa-arrows-up-down	istent
		×Dele	ate
Input Power (MC)			~
		Cancel	Save

An example is shown here:

Fig. 51: Platform icon settings - Set tooltip example

Set Tooltip M400		
		Items: 2 + Add new var
MSL (Height Above Mean Sea Level) - Altitude	Persist	~
Input Power (MC)		^
VRef* Unput Power (MC)	• Decimals	fa-car-battery
		× Delete
		Cancel

Fig. 52: Platform icon settings - Set tooltip example

Fig. 53: Platform icon settings - Set tooltip example

- Set alerts: These alerts are bit variables that appear next to the platform icon when in 'error mode'.

By default, the same bits that are sent in the autopilot 'Status Message' are configured as alerts. The user can add as many alerts as desired.




Fig. 54: Platform icon settings - Set alerts

They are displayed with the **icon**, which has been configured with them, **flashing red** when in 'error mode'. When the platform icon is clicked on, the name of the variable that has triggered this alert will be displayed. An example is shown below:

Fig. 55: Platform icon settings - Set alerts

- Set gimbal: Allows the display of information on the map provided by the selected gimbal.

Set Gimbal M400 - PDI
Choose Gimbal 👻 🗙
Cancel Save

Fig. 56: Platform icon settings - Set gimbal

- * **Choose Gimbal**: Select the desired gimbal to add from those previously configured in the *Gimbal* panel.
- Direction arrows: Users can change the color of the yaw and heading arrows.

Arrows			
☆ Yaw	Color		
☆ Heading	Color		
	Cancel Save		

Fig. 57: Platform icon settings - Direction arrows

- **Trail**: The trail path of the platform can be customized.

	Trail	
🔹 🚆 Color		
i ↔ Dash line length		0 Number
🔋 💠 Dash line space		0 Number
🔋 🔶 Pick Up Time	0	s
i 🖋 Max distance	100000	
		Cancel Save

Fig. 58: Platform icon settings - Trail

- * **Color**: Set the color trail.
- * Dash line length: Sets the length of the dash line. This change is visualized when a number other than of 0 is set.
- * Dash line space: Sets the space between dash lines. This change is visualized when a number other than of 0 and greater than *dash line length* is set.
- * **Pick Up Time**: Sets the time for the first point of the trial to be removed. This change is **visualized** when the time is **other than 0 s**.
- * Max distance: Sets the maximum length of the path to be drawn.
- Fly to loiter: Create a volatile loiter and change the current route.

Note: The platform will remain the altitude it had before this command.

Fig. 59: Platform icon - Fly to loiter

• Fly to hover: Create a volatile waypoint and change the current route.

Note: The platform will remain the altitude it had before this command.

Fig. 60: Platform icon - Fly to hover

• Follow leader: With this action the platform will follow a moving object (it can be another platform). For more information on this, see Follow Leader automation of the 1x PDI Builder manual.

The platform icon changes its appearance depending on the situation:

- Platform disconnected:
 - When Autopilot 1x is not connected, the platform icon is 'translucent grey'
 - By default, it is placed in the world coordinates (0,0).



Fig. 61: Platform icon - Translucent grey

- Platform connected:
 - During operation/configuration creation:
 - * The platform icon is '**translucent colored**', indicating that GPS data is not being received, i.e. **Position not fixed** status.
 - * By default, it is placed in the world coordinates (0,0).




Fig. 62: Platform icon - Translucent colored

- During operation/simulation:

- * The platform icon is 'colored', indicating that GPS data is being received/simulated.
- * It is placed in the actual position/simulation position.




Fig. 63: Platform icon - Colored

3.2 Mission

The common way to work with **Veronte Autopilot 1x** is to create missions.

Missions can be created and managed through the 'mission toolbar' (left side of the menu (2)).



Fig. 64: Mission toolbar

The mission toolbar provides graphical tools to create the path that the aircraft follows while it is in cruise phase.

Multiple missions can be created for different purposes. The missions generated are stored in the **Operation folder of the PDI configuration files** when the user saves the changes. For more information on the folders containing the PDI

files, see the initial menu of the Configuration section of the 1x PDI Builder user manual.

Note: First, make sure the 1x Autopilot unit where the mission has to be upload is selected (4. *Platform -> Platform list*).

Next, a detailed description of the toolbar is given. It is divided into different functionalities:



Fig. 65: Mission toolbar functionalities

3.2.1 Operation

All the tools in this 'section' allow the user to design the mission, such as waypoints, segments, marks, runways, etc.



Use the Waypoint tool and click on the map to create new waypoints. Then, when users have created all the desired waypoint, **right-click on the map** to close/finish the 'creation event'.

To move waypoints, it is first necessary to activate *mission editing* by clicking on the *icon*. Then, simply drag it to the desired position.

In relation to waypoints, the following actions can be performed with the mouse:

• Clicking once on the waypoint will display a summary of the waypoint information, coordinates and elevation:



Fig. 66: Waypoint information

• Right-clicking on the waypoint, users will access to its options:





Fig. 67: Waypoint options

- **Remove waypoint**: Deletes the waypoint.

- Set Start Route: Users must define where they want the cruise route to start by defining the waypoint as such with this option. The waypoint will turn of green color.



- Go to: By clicking here, the platform will fly to this waypoint. If the waypoint belongs to a mission, the platform will continue that mission after reaching it.

Note: This option is only available when a Veronte Autopilot 1x is connected and the operation, which the user is working on, is stored in the autopilot.

- **Waypoint Settings**: The user can change the configuration of the waypoint (coordinates and elevation) in the menu displayed here:

Operation Custom Po	oint 0
Absolute Relative	
Set coordinate	3 0 0
Decimal degrees	
Latitude (DD)	Longitude (DD) -0,56746380920371
Set elevation MSL terrain: 39.00	
⊂ WGS84	
120,38	m
112.38 meters	
70	m
62 meters	
23	m
23 meters	Cancel Confirm

Fig. 69: Waypoint configuration

There are 3 ways of defining the position of a waypoint manually:

- 1. Matching it to the platform position. By selecting the icon, the waypoint coordinates and elevation will be automatically updated with those of the actual platform's actual position.
- 2. Selecting a position in the map. Simply click on this icon icon, then click on the desired point on the map and the waypoint coordinates and elevation will be updated automatically.
- 3. Entering the exact coordinates and elevation here:
- * Absolute:

Operation Custom	Point 0
Absolute Relative	
Set coordinate	
Decimal degrees	•
CLatitude (DD)	Longitude (DD)
38,28481986614193	-0,57542630241033
Set elevation MSL terrain: 47.00	
WGS84	
120,38	m
120.38 meters	
70	m
70 meters	
23	m
23 meters	Cancel Confirm

Fig. 70: Absolute waypoint position

- Set coordinates: The coordinates can be set in:
- $\cdot \:$ Decimal Degrees \rightarrow Latitude (DD) and Longitude (DD)
- $\cdot \,$ Degrees ${}^{\underline{o}}$ ' " \rightarrow Latitude (DMS) and Longitude (DMS)
- · UTM \rightarrow x (Easting), y (Northing), Zone and Hemisphere
- · MGRS (Military Grid Reference System)
- Set elevation: Whichever way the user defines the altitude (WGS84, MSL and AGL) Veronte Ops will calculate the other 2 ways. That is, if the user defines a waypoint at X m in AGL, Veronte Ops will automatically calculate what that value is in WGS84 and MSL.
- * Relative: In this case, the position of the waypoint is relative to another point.

That point could be the **UAV position**, a **Desired position**, a **Track position** or an **Operation Custom Point**. They are indicated through North, East and Down.

Operation Custom Point 0	
Absolute Relative	
Set Relative	
UAV position	
North53,30627705294138	
East -112,94664275670836	Down 0,004091889115361624
	Cancel Confirm

Fig. 71: Relative waypoint position

 Open elevations: To be able to consult the elevation of the route, it is required to have installed the Veronte Terrain Provider application (for more information about this, see *Additional apps* section of this manual).

Here users can see an estimate of the height of the terrain and the height of the route to be taken as well as the collisions that could occur.

In addition, users can set up a **Warning Threshold**, which will be represented as a red warning line over the terrain. Fore more information, see *Map settings section* of this manual.

By clicking on it, the following menu will appear:



Fig. 72: Elevation (MSL) menu

1. This legend showing waypoints, terrain and collision is an 'interactive' legend, i.e. users can choose which of these elements are displayed or not by simply clicking on them:

Fig. 73: Elevation (MSL) menu - Legend

Drag button: When enabled (), users can modify the altitude of the waypoints by simply clicking and dragging them. If it is disabled (), it is not possible to move them:

Fig. 74: Elevation (MSL) menu - Dragging waypoints

3. Settings button: Displays a new window with some parameters that can be customized:

MSL setting	gs	
Units	Units chart view	~
Set elevations	Settings all the waypoints that the chart contains	^
Move to	(In meters) m	
Paddings		~
Sliders		~
Advanced	Set collision line & graphic colors	~
	× Cancel	Save

Fig. 75: Open elevation menu - Settings

- * Units: Units of the elevation and distance of the chart view can be set.
- * Set elevations: The altitude of all waypoints on the route can be modified.
- * Paddings: The size of the grid can be adjusted as desired.
- * Sliders: X and Y axis sliders can be hidden by disabling them.
- * Advanced: The collision line and chart colors can be modified:

Advanced Set collisio	n line & graphic colors	^
0	4	
Solid •	Collision	
Waypoints	Terrain	

Fig. 76: Elevation (MSL) menu - Advanced settings

3.2.1.2 Segment

To create a new segment, click on the segment icon and then select on the map the point where the segment will start. To end the track, users have 2 options:

- Double click directly with the left mouse button will create the last waypoint of the segment.
- After creating the last waypoint, **right-click on the map** to close/finish the 'creation event'.




Fig. 77: Segment

In addition, users can **concatenate two or more segments** by clicking on various points on the map with the **left button**, as shown in the figure below:




Fig. 78: Route

Besides, to create a closed route, users must match the last waypoint of the segment with the first one:

Fig. 79: Closed route

It is also possible to curve a segment. To do so, users must create the segment, edit the mission by clicking on the icon, and then move the **translucent orange waypoint** () in the centre of the segment. The distance moved will correspond to the radius of the curve:

Fig. 80: Curve segment

There is an extra option in the options for a waypoint that corresponds to the start of a curved segment:



Fig. 81: Curve segment options

• Set Turns: This option allows the user to set a desired number of turns. After these turns the platform will continue with the defined mission. An example is shown below:



Fig. 82: Curve segment - Turns

Warning: When a segment is created, be careful with the height of the waypoints.

Users can check for collisions between route waypoints and terrain directly on the map or using the 'Open elevations' functionality described above.

To check directly on the map, if some of the waypoints are below the terrain altitude indicated by the meshes, the affected segment will change its color to red. To solve this, change the altitude of the waypoints. An example is shown below:





Fig. 83: Segment under the ground altitude



This tool allows the user to create a new orbit on the map.

First, select a point on the map which will be the center of the new orbit. Then, when users have created all the desired orbits, **right-click on the map** to close/finish the 'creation event'.



Fig. 84: Orbit

In addition, the initial circular orbit can be converted into an ellipse by modifying the length of the axes and can also be rotated. To do this, edit the mission by clicking on the i icon, then move the **4 translucent orange waypoints** () as desired to turn them into an ellipse and to rotate it, click and rotate the small blue circle ():

Fig. 85: Ellipse orbit

Besides, there is an extra option in orbits regarding waypoints and segments:




Fig. 86: Orbit options

• Set Direction: It is possible to select the direction of the loiter: Auto, Clockwise and Anticlockwise.

Warning: When creating an orbit, be careful with its altitude and the ground level (all the points of the orbit will be at the same altitude).

Users can check for collisions between orbit and terrain directly on the map or using the 'Open elevations' functionality described above.

To check this directly on the map, if any part of the orbit is below the terrain altitude indicated by the meshes, the affected segment will change its color to red. To solve this, change the altitude of the waypoint.




Fig. 87: Orbit partially below ground level

3.2.1.4 Circle

This tool is used to determinate an area in which an action is wanted to be performed. When the aircraft enters or leaves the circle an event may be triggered and it can be used to start an automation.

Note: The linking of a circular area to an automation is done in the **Operation panel**, for more information about this, see *Operation panel* section of this manual.

To add a circle, click on its icon, click on the desired point on the map and drag it to set the radius. Then, when users have created all the desired circles, **right-click on the map** to close/finish the 'creation event'.




Fig. 88: Circle

Like all other elements, it can be edited to move it or change its radius by clicking on the *lice* icon:

Fig. 89: Circle radius

Right-clicking on the circle, users will access to its **options**:




Fig. 90: Circle options

- Set Radius: To accurately set the radius of the circle, users can enter the value manually.
- Set Height: Users can set the upper and lower heights of the circular area. By default, circular areas have infinite lower and upper boundaries.

Lower		
Value	- 🧭 Fid	Fld Approach Initial Point
Upper		
Value	m 🗢 Agl	•
		Cancel

Fig. 91: Circle options - Set Height

As can be seen in the figure above, the lower and upper limits can be set as absolute or relative:

- Relative con: The altitude is relative to a **Operation Variable**, previously defined in **1x PDI Builder**. But, it is required to set the value of the variable in the *Operation Variables* of the **Operation panel**.

In addition, it is necessary to establish whether it is relative to AGL, MSL, WGS84 or to a Fld (feature) that has to be selected.



Fig. 92: Circle options - Height relative

\$	Operatio	on Panel			×
Customize Calibrations					
Operation Variables Cus	stom Points	Areas	Patches	Marks	Ru
Name		Value		Unr	t
Circle height 1	2000)			
Circle height 2	1000	00			

Fig. 93: Circle options - Operation panel

- Absolute con: The value must be entered manually and it is also necessary to establish whether it is relative to AGL, MSL, WGS84 or to a Fld (feature) that has to be selected.
- Set Obstacle: A circle can become an obstacle, an area that is desired to avoid.

Fig. 94: Circle options - Set Obstacle

This tool permits to set an exclusion area on the map that can not be crossed by the RPAS. Main functions of the tool:

- Avoid collisions with obstacles as for example buildings, trees or antenna towers.
- Avoid flying restricted access areas.

What can happen with high speed aircrafts (Airplanes)? It is possible that due to its speed, the RPAS will enter the obstacle area, but will immediately apply the corrections to exit the obstacle area and return to the path. The solutions to this problem is to configure a bigger obstacle area in order to avoid the physical obstacle

What can happen with mow speed aircrafts (Multirotor)? It can happen that a multirotor enter an obstacle area (staying very close to its center), at that moment the *Ground Speed Vector* and the *Field Repulsion Vector* have the same direction but opposite sign. This phenomenon causes a conflict and until the directions are different enough to allow the multirotor to move, it will remain in an indecision situation. To solve this problem the user can configure the obstacle area by leaving the centre of the obstacle away from the path line.

There are some options available for each obstacle by right-cliking on it:



Fig. 95: Cicle options - Obstacle options

- Set 3D: This option allows the aircraft to avoid an obstacle by passing over it, taking into account the height of the obstacle.
- Set 2D: This option only takes into account 2 dimensions for the obstacle. Therefore, the platform will not be able to avoid the obstacle passing over it.
- Set circle: Turns the obstacle back into a circular area.
- Remove Circle: Deletes the circle.

3.2.1.5 Polygon

The way it works is very similar to Circle, described above.

This tool is used to determinate an area in which an action is wanted to be performed. When the aircraft enters or leaves the polygon an event may be triggered and it can be used to start an automation.

Note: The linking of a polygonal area to an automation is done in the **Operation panel**, for more information about this, see *Operation panel* section of this manual.

To add a polygon, click on its icon, click on the desired points on the map and match the last waypoint of the polygon with the first one. Then, when users have created all the desired polygons, **right-click on the map** to close/finish the 'creation event'.




Fig. 96: Polygon

Like the other elements, it can be edited to change its shape by moving its vertices. Click on the *icon*:

Fig. 97: Polygon shape

Right-clicking on the polygon, users will access to its options:



Fig. 98: Polygon options

- Set height: Users can set the upper and lower heights of the polygonal area. By default, polygonal areas have infinite lower and upper boundaries. It works in the same way as in the *circular areas*, described above.
- **Remove polygon**: Deletes the polygon.

3.2.1.6 / Runway

This option allows the user to configure a Runway which is used during flight phases.

To add a runway, click on its icon, click on a point on the map to define the start and click on a second point to define the end of the runway.




Fig. 99: Runway

Note: The loiter position is automatically defined and it is identified by this icon: \square , as can be seen in the image above.

By accessing the *mission edition* (\swarrow icon) it is possible to modify the position of the start and end points of the runway, as well as the position of the loiter point:

Fig. 100: Runway position

Right-clicking on the start or end point of the runway, users will access to its options:




Fig. 101: Runway options

• Runway Settings: The following parameters can be configured:

Runway 1	
Lat: 38.2845 Lon	: -0.5750 Alt: 50.3800 Lat: 38.2840 Lon: -0.5714 Alt: 50.3800
0 Margin	x1 Margin Reverse
2 3	Loiter Position: Lat: 38.2850 Lon: -0.5750 Alt: 80.3800
	Cancel Save

Fig. 102: Runway options - Settings

1. Runway direction: The direction of the runway is defined here with an arrow.

By default it is \rightarrow , but user can define it as desired clicking on it. The available options are \rightarrow , \leftarrow and AUTO.

Note: When the AUTO option is selected, the runway direction will be defined by the wind direction.

- 2. **Runway coordinates**: The user can manually introduce the coordinates of the start and end point of the runway. Its configuration is the same as for a waypoint (a detailed explanation of this has been described in the *Waypoint* section).
- 3. Margin/Margin Reverse: Percentage of the runway distance at which the airplane will try to touch the ground.
- 4. Loiter Position: To accurately define the loiter point of reference (**Runway Loiter**), its coordinates and the altitude that the aircraft will reach during climb, can be defined in this option.

Its configuration is the same as for a waypoint (a detailed explanation of this has been described in the *Waypoint* section).

• **Configure Alarms**: When an alarm is selected, the aircraft shall perform the actions associated to that alarm on the selected runway.





Fig. 103: Runway options - Configure Alarms

Alarms are configured with bit variables, users can select any bit they want.

	Items: 2 + Add new var
×	User BIT 08 Error
×	Select Bit
	Cancel Save

Fig. 104: Runway options - Alarms

• Remove Runway: Deletes the runway.



This option allows the user to configure a **Spot** which is used during flight phases. A spot refers to a kind of runway where a initial point and its azimuth is defined. Besides, it is necessary to define a delta angle.




Fig. 105: Spot

Note: The loiter position is automatically defined and it is identified by this icon:

By accessing the *mission edition* (Line is possible to modify the **position**, **azimuth** and **delta** of the 'spot' and also the position of the loiter point:

Fig. 106: Spot position

Right-clicking on the 'spot' point, users will access to its **options**:




Fig. 107: Spot options

• **Spot Settings**: The aircraft will land or take-off using the best orientation computed within the area bounded by the parameters entered here:

Spot 1	
Position: Lat: 38.284	14 Lon: -0.5750 Alt: 50.3800
Azimuth	Delta
0	°[0,360] (0,360) (0,360)
Loiter Position: Lat: 3	8.2845 Lon: -0.5744 Alt: 80.3800 Cancel Save

Fig. 108: Spot options - Settings

- **Position**: The user can manually introduce the coordinates of the 'spot' point. Its configuration is the same as for a waypoint (a detailed explanation of this has been described in the *Waypoint* section).
- Azimuth and Delta: Users must configure the desired azimuth and delta for the spot. The units available for these angular values are [0, 360], ^a "", rad, $rad[0, 2\pi]$, $, rad[-\pi, \pi]$ and [-180, 180].




Fig. 109: Spot parameters

- Loiter Position: To accurately define the loiter point of reference (Spot Loiter), its coordinates and the altitude can be defined in this option.

Its configuration is the same as for a waypoint (a detailed explanation of this has been described in the *Waypoint* section).

- **Configure Alarms**: When an alarm is selected, the aircraft shall perform the actions associated to that alarm on the selected spot. It is configured in the same way as *runways*, described above.
- **Remove Spot**: Deletes the spot.



This tool allows to set an event mark on a patch. Marks are useful to initiating automations. When the aircraft flies over it, an event is triggered and can be used as a condition to start a set of actions: add a lap to a counter, payload launch, take a photo, start video recording, etc.

Note: The linking of a mark to an automation is done in the **Operation panel**, for more information about this, see *Operation panel* section of this manual.

To place a mark, it is **first required to create a patch**. The elements described above that are patches are **waypoints**, **segments** and **orbits**. To add it, select the tool and click on the desired patch. Then, when users have created all the desired marks, **right-click on the map** to close/finish the 'creation event'.



Initially, new marks appear as a pin (). If the user links an event to one of them, the icon selected for this event will be displayed.




Fig. 110: Mark

Marks can be moved along the patch by clicking on the *icon*:

Note: A mark can only be displaced if it is in a segment.

Fig. 111: Marks moved

Right-clicking on the mark, users will access to its options:




Fig. 112: Mark options

- Set Distance: This distance is the horizontal distance along the patch to the starting waypoint. If the mark is attached to a waypoint, distance will be zero.
- Remove Mark: Deletes the mark.



To be able to create these elements, it is first necessary to have the application Veronte Terrain Provider running.

If this tool is not initialised, the following warning message will appear when trying to use the two 'Generate Route' tools:




Fig. 113: Generate route warning message

. O Spiral

Spiral tool draws a spiral that can cover a target area.




Fig. 114: Generate route - Spiral

The spiral options are accessed in the same way as for the other elements described above, and are the same as

the *waypoint* options. However, by **clicking on the central waypoint of the spiral**, an extra option appears that allows the user to access the '**Spiral Settings**':



Fig. 115: Generate route - Spiral options

Spiral Settings	
C Radius	
100	m
C Rounds	
5	
Altitude (AGL)	
46.45152000000066	ft
Direction	
0	°[0,360]
	Accept

Fig. 116: Generate route - Spiral Settings

Warning: If the user 'refreshes' **Veronte Ops**, it will no longer be possible to access this configuration menu.

In addition, the spiral will act as a *curved segment* and will have the same options like this one.

The following parameters can be configured:

- Invert: When enabled, the direction of the route will be the opposite to the direction configured below.
- Radius: Spiral maximum radius.
- **Rounds**: The number of spiral rounds.
- Altitude (AGL): Altitude of the waypoints expressed in AGL.
- **Direction**: Direction of the spiral axes on the map.

• Photogrammetry Polygon

Polygon tool allows users to draw a polygon on the map to automatically generate a mapping mission.




Fig. 117: Generate route - Polygon

The polygon options are accessed in the same way and are the same as for a 'normal' polygon (see *Polygon section*, for more information). However, an extra option appears that allows the user to access the '**Photogrammetry Settings**' (Route Settings):




Fig. 118: Generate route - Polygon options

Photogramtery	Setting
_ Invert Polygon	
· Margin	
0	m
Curve radius	
20	m
Distance between segments	m
Altitude (AGL) 30.480000000000217	ft
Direction	°[0,360]
	Accept

Fig. 119: Generate route - Photogrammetry Settings

Warning: If the user 'refreshes' Veronte Ops, it will no longer be possible to access this configuration menu. Therefore, photogrammetry polygon will act as a "normal" polygon.

The following parameters can be configured:

- Invert: When enabled, the direction of the route will be the opposite to the direction configured below.
- **Polygon**: As with 'normal' polygons, users can link a predefined polygon to this photogrammetry polygon in the **Operation panel**. For more information about this, see *Operation panel* section of this manual.

Photogramtery Settings								
Invert								
First polygon								
photogrametry polygon								
0 ""								

Fig. 120: Generate route - Photogrammetry Settings polygon

- Margin: This option allows the user to add boundary margins for the route to each side of the polygon.
- Curve radius: Radius of the route turns.
- Distance between segments: Distance between segments can be modified.

Note: Depending on the **curve radius** value and the **distance between segments**, there are three cases for this part of the route (the radius must be set according to the minimum achievable by the platform):

- * Radius $0 \Rightarrow$ There are no curves between passes, but straight lines. This option is used with multicopters, which are able to perform this kind of paths.
- * Radius is smaller than half the distance between segments $(R < \frac{d}{2}) \Rightarrow$ Veronte Ops generates a semicircle with the diameter equal to the distance between parallel segments.
- * Radius bigger than half the distance between segments $(R > \frac{d}{2}) \Rightarrow$ The path between straight lines is formed by two curves and a straight line.
- Altitude (AGL): Altitude of the waypoints expressed in AGL.
- Direction: Direction of the route generated on the map.

Note: The options for the waypoints forming the route generated for this photogrammetry polygon are the same as for a 'normal' waypoint. For more information on waypoint configuration, see *Waypoint section* described above.




Fig. 121: Generate route - Waypoint polygon options

3.2.1.10 Mission panel

This mission panel allows the user to monitor and manipulate the waypoints, polygons and circles created.

• Waypoints

The following fields can be found in this menu:

Mission panel						×
Vaypoints	Polygons	Circl				
Waypoints selected 0 Altitude O meters	M MSL	_	Set			
Name	Latitude	Longitude	MSL Position	Options		
🗌 WP 1	38.284757	-0.569846	68.00 Absolute	۹	* 🔳	
Operation Custom P	oint 2 38.285103	-0.572754	70.00 Absolute	۹	*	
Operation Custom P	oint 3 38.284951	-0.571922	78.00 Absolute	۹	* 🔳	
Operation Custom P	oint 4 38.285372	-0.571815	66.00 Absolute	۹	* 1	

Fig. 122: Mission panel - Waypoints

- Name: Name of this waypoint defined in the 1x PDI Builder software.
- Latitude/Longitude/MSL: Coordinates of the waypoint.
- Position: Absolute or Relative.
 - * Absolute means that the position of the element is fixed.
 - * **Relative** indicates that its position is relative to the position of another element and may change during the operation.
- Options:
 - * **Q** Search: Clicking here will center and zoom the waypoint on the map.
 - * **Edit**: Open the waypoint edit menu. For more information on waypoint settings, click *here*.

It is also possible to **modify the altitude** of one, several or all the selected waypoints by using the **Altitude edit** function **on the top of the list**.

Note: Selecting all will select the waypoints on all pages of the panel.

Users must enter the desired **altitude value**, select the **altitude type** (*WGS84*, *MSL* or *AGL*) and finally click '**Set**'.

Missi	on panel								×
•	Waypoints	🌒 Poly	/gons	Circ					
Hittude - Altitude - 100 meter	nts selected 2	m	Altitude type — MSL		•	Set			
	lame		Latitude	Longitude	MSL	Position	Options		
N	VP 1		38.284757	-0.569846	68.00	Absolute	۹	*	
o	peration Custom Poin	t 2	38.285103	-0.572754	70.00	Absolute	۹	*	
0 []	peration Custom Poin	t 3	38.284951	-0.571922	78.00	Absolute	۹	×	
0	peration Custom Poin	t 4	38.285372	-0.571815	66.00	Absolute	۹	×	

Fig. 123: Middion panel - Waypoints altitude

* **Delete**: Deletes this waypoint.

• Polygons

The following fields can be found in this menu:

ssioi	n panel									×
9 Wa	ypoints	Polygons		Circles						
•	Name		Options							
	Polygon 3		ଡ ସ	2 🔋						
			ltems per	page: 5 🔻	1 – 1 of 1					
•	Q Wa		Waypoints Polygons Name	 Waypoints Polygons Name Options Polygon 3 	Waypoints Polygons © Circles Name Options Polygon 3 ② Q ☑ 10000000000000000000000000000000000	Waypoints Polygons Name Options Polygon 3 Image: Circles	 Waypoints Polygons Circles Name Options Polygon 3 Q< Q 	Waypoints Polygons Name Options Polygon 3 Image: Circles	Waypoints Polygons Name Options Polygon 3 Image: Circles	Waypoints Polygons Name Options Polygon 3 Image: Circles

Fig. 124: Mission panel - Polygons

- **ID**: Feature Id of this polygon.
- Name: Name of this polygon defined in the 1x PDI Builder software.
- Options:
 - * Show/hide: It is possible to show/hide the polygon on the map by clicking here.
 - * Search: Clicking here will center and zoom the polygon on the map.
 - * Edit: Open the polygon edit menu. For more information on polygon settings, click here.
 - * **Delete**: Deletes this polygon.
- Circles

The following fields can be found in this menu:

banel		×
oints 🛛 🍓 Polygons	Circles	
me	Options	
rcle 2	0 Q 2 T	
	Items per page: 5 💌 1 – 1 of 1	
	ints 🏼 🌒 Polygons	anel Ints Polygons Circles me Options rcle 2 O Q Z T

Fig. 125: Mission panel - Circles

- **ID**: Feature Id of this circle.
- Name: Name of this circle defined in the 1x PDI Builder software.
- Options:
 - * **Show/hide**: It is possible to show/hide the circle on the map by clicking here.
 - * Search: Clicking here will center and zoom the circle on the map.
 - * Edit: Open the circle edit menu. For more information on circle settings, click here.
 - * **Delete**: Deletes this circle.



This tool allows the user to move waypoints, marks, areas, etc., as well as to change their shape.

A detailed explanation on how to use this tool can be found in each of the elements described above.

In addition, when modifying a mission with a Veronte autopilot 1x connected, the "original operation" loaded in the autopilot will be greyed out and the modified one will be coloured. This will be the case until the new changes are saved and uploaded to the autopilot, so the previous operation will be completely removed from the map. An example is shown below:

Fig. 126: Edit mission

3.2.1.12 Turn on multiselection

Multiselection allows to move and rotate mission's path from one place on the map to another.

- Select the tool and create a rectangle by clicking and dragging until the waypoints you want to move fall into it.
- With the points selected, click and drag the rectangle to move it to the desired location. And to rotate it, click on the 'white pin' () and drag it to the desired rotation angle.
- After that, click again in the tool's icon to deselect.

Note: Runways and spots cannot be moved with this tool.

Fig. 127: Multiselection tool

In addition, **this tool also allows to delete all items selected** by **pressing the 'delete' key** on the user's keyboard. Before deleting the selected items, the following confirmation message appears:




Fig. 128: Multiselection tool - Remove message

Note: Runways and spots cannot be deleted in this way.

Fig. 129: Multiselection tool - Remove



By clicking on this icon, the user can remove all the elements created by simply clicking on each of them.

Fig. 130: Remove mission

However, if the user wishes to remove all the missions created, simply click on the second icon that appears: I. A confirmation pop-up window will then appear to make sure that all missions wish to be deleted.




Fig. 131: Remove all missions

3.2.2 Measure



Using the ruler, the user can measure distances and azimuths.



Fig. 132: Ruler

The following information can be found in the each point of the figure above:

- In (°): **Azimuth** in **degrees** of the 'incoming' measure. The **azimuth** is the angle of the segment with respect to North.
- Out (°): Azimuth in degrees of the 'outcoming' measure. The azimuth is the angle of the segment with respect to North.
- Blue measurement: Distance from the previous point.
- Green measurement: Distance from the first point.

Note: There 3 different types of points on the ruler segments:

- Green point: Indicates the start of the route.
- Blue point: Midway point of the route.
- Red point: End of the route.

In addition, by clicking on the ruler icon, two more options will appear:

• Change units: The user can change the units of the measurements by clicking on this icon. The available units are: km (kilometeres), mi (miles) and nm (nautical miles).

Note: The ruler indicates the **measures with 2 decimals** in order to have more precision, as can be seen in the figure above.

• **Clear measurements**: By clicking on it, it is possible to delete all the measurements in the mission. A confirmation pop-up window will then appear to make sure that all measurements wish to be deleted.




Fig. 133: Remove all measurements

3.2.3 Paint



This tool allows the user to make quick notes during the operation.

To access the paint option, click on this icon, a 'Paint toolbar' will then appear:



Fig. 134: Paint toolbar

Users can choose from a variety of 'writing elements' and colors to paint:

- Pencil
- Crayon
- Marker
- Circles
- Striples

An example of each is shown in the figure below:



Fig. 135: Paint examples

In addition, all notes made can be erased with an eraser, if they are not already saved, by clicking on the 'eraser option' in the toolbar.

Fig. 136: Paint erased

Note: To save all the notes made here, it is important to click on the '**Save**' button, otherwise they will not be saved. If they are not saved, the following message will appear when exiting the 'Paint' option:




Fig. 137: Warning paint not saved

3.2.3.2 Delete paint

All paints will be removed. The following confirmation pop-up window will appear:




Fig. 138: Remove paint

3.2.4 Offline

This option is designed for when users operate offline, i.e. they do not have internet access to download map information. For this reason, the map tiles of the area to work on can be pre-downloaded.

The following options are available in this section:



This option works differently when working online and offline:

• **Online**: If the user has already downloaded tiles, when clicking on this icon, the area with the downloaded tiles will be marked with a blue rectangle:




Fig. 139: Show tiles

If the user has not downloaded any tiles, the following message will appear when clicking here:




Fig. 140: Show tiles - don't have downloaded

• Offline: If the user has already downloaded tiles, when clicking on this icon, these tiles will always appear:




Fig. 141: Show tiles

If the user has not downloaded any tiles, they may appear because they are stored in the Veronte Ops cache, however, it is not certain that this will always happen. Therefore, it is recommended to have the map tiles downloaded when working offline.

3.2.4.2 Save tiles

The tiles that the user is viewing will be downloaded. An example is shown below:

1. Click on this icon when the user is zooming in on the tiles in the desired area to download:

Warning: As each zoom level in Veronte Ops counts as an independent map tile. When downloading map information, make sure that all relevant zoom levels are downloaded.




Fig. 142: Download tiles

2. The tile download process will then begin:




Fig. 143: Downloading tiles

3. Finally, by clicking on the above option, users can view the downloaded map tiles of the desired area.

If there is no significant zoom, Veronte Ops will not download these files because there are too many of them. The following message will appear:





Fig. 144: Not possible to download tiles



Clicking on this icon will delete all tiles downloaded tiles. The following messages will appear:








Fig. 146: **Remove tiles successfully**

3.2.5 Settings

By clicking here, a settings menu window will appear:

Мар	controls settings
	Operation
	Measure
	Paint
	Offline
	× Cancel

Fig. 147: Settings menu

Here, the user can choose, by enabling or disabling them, the group of functionalities to be displayed in the mission toolbar.

To save the changes made, click on the 'Save' button.

Each group of funcionalities has been described in the previous sections.

- Operation
- Measure
- Paint
- Offline

3.3 Operation



Fig. 148: **Operation toolbar**

The Operation toolbar is composed by 3 'parts': **Operation panel**, **Operations** and **Operation actions**. However, in the figure above there is no *Operation actions* part because there was no Veronte Autopilot 1x connected.

In the figure below, users can see these 3 'parts' when an Autopilot 1x is connected:



Fig. 149: Operation toolbar - Autopilot connected

- 1. *Operation panel*: Here the user can customize operation elements related to the operation and carry out some simple calibrations such as calibration of atmosphere, wind, DEM, etc.
- 2. Operations: Users shall be able to select an operation other than the one loaded on the autopilot and load it.
- 3. *Operation actions*: These are actions related to when changes are applied to the operation/mission, such as *Revert, Save* and *Upload* changes. This 'part' is only available when a Veronte 1x Autopilot is connected.

In addition, when a change is made, the other 2 actions (Revert and Save) appear.

3.3.1 Operation panel

This menu is divided into 2 different functionalities: manage **operation elements** in the **Customize** tab, and **simple calibrations** in the **Calibrations** tab.

٠			Ор	eration Par	nel		×
	Customize	ations					
	Operation Variables	Custom Points		Patches	Marks		
	-	Do	on't have any o	operation custo	m points to co	nfigure	

Fig. 150: Operation panel

All parameters included in this panel are explained in detail in the following sections.

3.3.1.1 Customize

In this part of the menu users can find all the operation elements used during the operation and mission: *Operation Variables, Custom Points, Areas (polygons and circles), Patches, Marks, Runways* and *Spots.*

÷			Operati	on Panel				×
	Customize	prations						
	Operation Variables	Custom Points	Areas	Patches	Marks	Runways	Spots	
_		Don't l	nave anv oper	ation variables to	o configure			
		•	,,-		-			

Fig. 151: Operation panel - Customize tab

If users wish to link a mark, patch, polygonal area, etc., to one of these variables, it is first necessary to define (rename) them in the **UI menu of the 1x PDI Builder software**, as described and explained in the corresponding section of the 1x PDI Builder manual, click here to access it.

3.3.1.1.1 Operation Variables

Operation Variables are configurable values, postitions and directions that can vary depending on the mission.

Examples of *Operation Variables* can be:

- Mission duration
- Cruise speed
- Flight level
- Takeoff and landing direction
- Home point
- Start of route

Their main advantage is that **it is not necessary to access Veronte Autopilot configuration to modify them**. In this way, the operator can modify certain parameters without the need of having access to the entire configuration.

*			Operatio	on Panel				×
Customize	Calibra	tions						
Operation V	ariables	Custom Points		Patches	Marks	Runways	Spots	
		Don't h	ave any opera	ation variables t	o configure			

Fig. 152: Operation Variables

As explained above, operation elements must be created while building a Veronte Autopilot configuration. So, when a new *Operation Variable* is created, a new field will appear in the operation variables tab:

*		Oper	ation Panel					×
Customize	alibrations							
Operation Variables	Custom Points	Areas	Patches	Marks	Runways	Spots		
Name			Val	ue			Unit	
Cruise s	beed		Not set				m/s	

Fig. 153: New Operation Variable

After this, the value of this variable can be defined using this menu. The user simply clicks on the value cell, enters the desired new value and saves the change (button, this is explained in the *Save operation section* section below). An example is shown below:

Fig. 154: Operations Variables configuration

Warning: Although it is possible to modify Operation Parameters during the flight, this practice is not recommended.

Whenever changing values during an operation, make sure that no potential risk to flight safety is involved.

3.3.1.1.2 Custom Points

A Custom point is an operation element that can be linked to a waypoint of the configured mission.

As explained above, an operation element only appears in this panel when it has been previously defined in the 1x PDI Builder software.

÷			Opera	ation Panel				×
	Customize Ca	alibrations						
	Operation Variables	Custom Points	Areas	Patches	Marks	Runways	Spots	
	Name	Latitude	Longitude	Altitud	de (WSG84)		Options	
	WP 1						Not Set 🛛 🕞	

Fig. 155: Custom point

Therefore, as can be seen in the figure above, this *Custom point* has been defined in the autopilot configuration, but is **not yet configured**.

To configure it, it is necessary to click on the kick icon to link this *Custom point* to a waypoint of the mission. An example is shown below:

Fig. 156: Custom point configuration - Select point

Once, the *Custom point* is linked to a waypoint, the following options will appear in the operation panel:

٠			Opera	ation Panel				×
	Customize	Calibrations						
_	Operation Varia	bles Custom F	Points Areas	Patches	Marks			
	Name	Latitude	Longitude	Altitude (WSG84	4)	Ор	tions	
	WP 1	38.286138	-0.573113	127.38		r Q	₽ Ó	
						12	34	
								Å

Fig. 157: Custom point configuration

- Name: Name of this Custom point defined in the 1x PDI Builder software.
- Coordinates: Latitude, longitude and altitude (WGS884) of the selected point.
- **Options**: These are configuration options of the *Custom point*:
 - 1. Edit options: This option allows the user to manually edit the position of the *Custom point*. Its configuration is the same as for a waypoint (a detailed explanation of this has been described in the *Waypoint* section).
 - 2. Search: By clicking here, Veronte Ops will center and zoom in on the area of the map where this *Custom point* is defined.
 - 3. Select in map: To link the *Custom point* to a different waypoint, click here and select it on the map.
 - 4. Remove reference: The user can remove the *Custom point* configuration by clicking here.

Moreover, by clicking on the linked waypoint, it will appear with the name of the configured *Custom point*:




Fig. 158: Custom point description

3.3.1.1.3 Areas

This tab includes polygonal and circular areas.

These operation elements, *Polygons* and *Circles*, are detection areas that can be linked to polygons or circles of the configured mission.

Customize Calibrations Operation Variables Custom Points Areas Patches Marks Runways Spots Polygons	
Polygons	
Name Events Options	
First polygon Hover area @ ┡ 💼	
Circles ^	

Fig. 159: Areas

In the image above, the user can identify that there is a polygonal area already defined and configured and that there is no circular area either configured or defined.

If the user wants to **define** a circular area, this has to be done in **1x PDI Builder**, as described at the beginning of the *Customize section*. Then, to configure it, the process is the same as described for *Custom points*.

Once an Area has been defined and configured, the following options are displayed in the operation panel:

*	Operation Panel		×
Calibrations			
Operation Variables Custom Points	Areas Patches	Marks Runways Spots	
Polygons			^
Name	Events	Options	
First polygon	Hover area		
		$\bigcirc \bigcirc $	

Fig. 160: Are configuration

- Name: Element identifier, this has been defined in the 1x PDI Builder software.
- Events: Here is displayed the list of any events that are linked to this element, such as triggers for automatic actions.
- **Options**: These are configuration options of the Area:
 - 1. Search: By clicking here, Veronte Ops will center and zoom in on the area of the map where this *Area* is defined.
 - 2. Select in map: To link this operation element to a different area, click here and select it on the map.
 - 3. Remove reference: The user can remove the Area configuration by clicking here.

In addition, when clicking on the linked area, its description will appear with the name defined by the user and the events linked to it will also appear:





Fig. 161: Area description

3.3.1.1.4 Patches

A **Patch** is an operation element that can be linked to patches associated with waypoints, segments, arcs or orbits of the configured mission.

This tab has the same options and works exactly the same way as the previous section (Areas section).

	Operation Pan	el	×
Customize Calibrations			
Operation Variables Custom Points	Areas Patches	Marks Runways Spots	
Name	Events	Options	
RTH point	RTH WP		
		000	
	Operation Variables Custom Points Name	Customize Calibrations Operation Variables Custom Points Areas Patches Name Events	Operation Variables Custom Points Areas Patches Marks Runways Spots Name Events Options RTH point RTH WP Image: Im



In addition, if the event that is linked to the Patch has an associated icon and the element of the mission is the patch of

a waypoint, the icon will appear at this waypoint. An example is shown below:

Moreover, if the event that is linked to the *Patch* has an associated icon and the element of the mission is the patch of a **waypoint**, the icon will appear at this waypoint. In addition, when clicking on it, in its description will appear with patch name defined by the user and the events linked to it will also appear. An example is shown below:

Note: As this is a patch, the Operation Custom Point is not renamed as in the case of *Custom Points*, the name of the patch associated to this waypoint is renamed in the description.




Fig. 163: Patches - WP description

3.3.1.1.5 Marks

A Mark is an operation element that can be linked to a mark (reference placed in a patch) of the configured mission.

The procedure for defining and configuring a mark is the same as described above in the Areas section.

Once a *Mark* is configured, the following options will appear in the operation panel:

٠		Operatio	n Panel	×
_	Customize Calibrations			
	Operation Variables Custo		atches Marks Runways	
	Name	Events	Options	
	First mark	Home achieved) O
			<u> </u>	30


Fig. 164: Marks

- Name: Element identifier, this has been defined in the 1x PDI Builder software.
- Events: Here is displayed the list of any events that are linked to this mark, such as triggers for automatic actions.
- **Options**: These are configuration options of the *Mark*:
 - 1. **Search**: By clicking here, Veronte Ops will center and zoom in on the area of the map where this *Mark* is defined.
 - 2. Edit/Create:

Patch type * Route	•	Patch Selected * Route 10	-	Type * Referred to start	•	Distance 0	m
							Cancel Save

Fig. 165: Marks - Edit

- Patch type: The user can select different flight guidance phases where the marks will be placed: Approach, Climbing, Route, Taxi, VTol and Rendezvous. Except for Route patches, for the rest of the guidance phase, patches are generated when the user, or an automation, activates them. As the user cannot select these patches, as they cannot be generated initially, this option will automatically create the marking on the selected patch.
- **Patch Selected**: Most flight guidance phases have predefined patches with specific names. The user can select where the mark will be placed on those patches. A table summarising the available options is shown below.
- Type: Right now the only possible option is "Referred to Start" of the selected patch.






Fig. 166: Marks - Approach patches




Fig. 167: Marks - Climbing patches

Approach	L0/A1/L2/A3/L4/L5
Climbing	L4/A3/L2/A1
Route	512 patches
Taxi	Taxi1/Taxi2
VTol	VTol1/VTol2/VTol3
Rendezvous	Rendezvous1/Rendezvous2/Rendezvous3

- 3. Select in map: To link this operation element to a different mark, click here and select it on the map.
- 4. **Remove reference**: The user can remove the *Mark* configuration by clicking here.

Moreover, if the event that is linked to the *Mark* has an associated icon, the icon will appear on that mark. In addition, when clicking on it, its description will appear with the name defined by the user and the events linked to it will also appear. An example is shown below:




Fig. 168: Marks - Icon and description

3.3.1.1.6 Runways

Runways are operation elements that can be linked to the runways of the configured mission.

Like all other operation elements, *Runways* have to be **defined in 1x PDI Builder** and then **configured by selecting a runway from the map**.

Operation Panel							×
Customize	brations						
Operation Variables	Custom Points	Areas	Patches	Marks	Runways	Spots	
	Name				Options		
	TKO runway				Not Set 🛛 🗟		
		Operation Variables Custom Points Name	Customize Calibrations Operation Variables Custom Points Areas Name	Customize Calibrations Operation Variables Custom Points Areas Patches Name Image: Contract of the state	Customize Calibrations Operation Variables Custom Points Areas Patches Marks Name Image: Imag	Customize Calibrations Operation Variables Custom Points Areas Patches Marks Runways Name Options	Customize Calibrations Operation Variables Custom Points Areas Patches Marks Runways Spots Name Options

Fig. 169: Runways

The following configurable options will then appear in the operation panel:

÷	Operation Panel						×	
	Customize Calibration							
	Operation Variables C	ustom Points		Patches	Marks	Runways	Spots	
	Name				Options			
	TKO runway					R @		

Fig. 170: Runways configuration

- Name: Element identifier, this has been defined in the 1x PDI Builder software.
- **Options**: These are configuration options of the *Runway*:
 - 1. **Search**: By clicking here, Veronte Ops will center and zoom in on the area of the map where this *Runway* is defined.
 - 2. Edit: By clicking here the user will be able to modify the runway settings. A detailed explanation of how to configure it can be found in *Mission toolbar section Runway*.
 - 3. **Configure Alarms**: Alarms can be associated to *Runways*. A detailed explanation of how to configure them can be found in *Mission toolbar section Runway*.
 - 4. Select in map: To link this operation element to a different runway, click here and select it on the map.
 - 5. Remove reference: The user can remove the *Runway* configuration by clicking here.

Moreover, by clicking on the linked runway, it will appear with the name of the configured *Runway*:



Fig. 171: Runways description

If the user clicks on the different points of the Runway, these are also renamed:

• *Start point of the runway*:



Fig. 172: Runways - Start point

• End point of the runway:



Fig. 173: Runways - End point

• Loiter point of the runway:



Fig. 174: Runways - Loiter point

3.3.1.1.7 Spots

 $\ensuremath{\textbf{Spots}}$ are operation elements that can be linked to the spots of the configured mission.

They function in the same way as the *Runways* operation elements:

		Opera	tion Panel				×
Customize Calibr	rations						
Operation Variables	Custom Points	Areas	Patches	Marks	Runways	Spots	
Name				Options			
LND spot				3 Q R			
			00	330			

Fig. 175: Spots configuration

- Name: Element identifier, this has been defined in the 1x PDI Builder software.
- **Options**: These are configuration options of the *Spot*:
 - 1. **Search**: By clicking here, Veronte Ops will center and zoom in on the area of the map where this *Spot* is defined.
 - 2. Edit: By clicking here the user will be able to modify the spot settings. A detailed explanation of how to configure it can be found in *Mission toolbar section Spot*.
 - 3. **Configure Alarms**: Alarms can be associated to *Spots*. A detailed explanation of how to configure them can be found in *Mission toolbar section Spot*.
 - 4. Select in map: To link this operation element to a different spot, click here and select it on the map.
 - 5. Remove reference: The user can remove the Spot configuration by clicking here.

Moreover, by clicking on the linked spot, it will appear with the name of the configured Spot:



Fig. 176: Spots description


If the user clicks on the spot loiter point, it is also renamed:



Fig. 177: Spots - Loiter point

3.3.1.2 Calibrations

In this tab, the user can carry out simple calibrations during a standard operation. This way, there is no need of modifying the configuration or building a specific automation.



٠	Operation Panel	×
	Customize	
	Calibrate Atmosphere	~
	Calibrate Wind	~
	Advanced Calibrations	~

Fig. 178: Operation panel - Calibrations tab

Note: These calibrations will never modify the autopilot's current configuration: the changes are volatile, and will dissapear once the system is rebooted.

Warning: To send any of these calibrations, it is necessary to click on the 'Send' button.

3.3.1.2.1 Calibrate Atmosphere

Calibration for MSL calculation with barometric pressure.

¢		Operation Panel
	Customize	
	Calibrate Atmosphere	^
	Autopilot (QFE)	
	Time to acquire mean3S	
	Temperature 15 °C	
	Altitude(MSL) 0 m	
	Take AP's pressure	
	1013.25 mbar	
		Send

Fig. 179: Calibrate Atmopshere

- Type: QFE and QNH options are available.
- Time to acquire mean: Specified time during which the static pressure is read from the static pressure sensor.
- Temperature: Outside air temperature.
- Altitude (MSL): Actual MSL altitude.
- **Take AP's pressure**: If enabled, static pressure will be selected from the autopilot measurement, otherwise users will must enter it manually.

3.3.1.2.2 Wind Calibration

This command allows to enter initial values for wind state and start wind estimation algorithm.

٠			Operation Panel	×
	Customize Calibrations			
hereit	Calibrate Atmosphere		~	
	Calibrate Wind		^	
	Enable Wind Estimation Initial Vector Wind Speed 0	V Init		
	0	•	Send	
broave	Advanced Calibrations		~	

Fig. 180: Calibrate Wind

- Enable Wind Estimation.
- Init: By enabling it, an initial wind vector can be set to a faster convergence of the estimation.
- Wind Speed: Module of the initial wind speed.
- Direction: Argument/Direction of the initial wind speed.

3.3.1.2.3 Advanced Calibration

Operation Panel	×
Customize Calibrations	
Calibrate Atmosphere	~
Calibrate Wind	~
Advanced Calibrations	^
Calibrate Digital Elevation Model	~
Trim stick for Arcade Modes	~
Calibrate Yaw	~
Calibrate Position	~

The following are the advanced calibrations that can be performed by the user during operation:

Fig. 181: Advanced Calibrations

• Calibrate Digital Elevation Model (DEM)

Calibrate any offset that the current terrain model may have for the user's current position.

Warning: Always perform this action on the ground, unless an accurate estimation of current AGL is available.

¢	Operation Panel	×
	Customize Calibrations	
	Calibrate Atmosphere	~
Products	Calibrate Wind	~
	Advanced Calibrations	^
	Calibrate Digital Elevation Model	^
	0 m Send	
	Trim stick for Arcade Modes	~
	Calibrate Yaw	~

Fig. 182: Advanced Calibrations - Calibrate DEM

• Trim stick for Arcade Modes

This command calibrates the current stick for arcade commands.

Operation Panel	2
Customize Calibrations	
Calibrate Atmosphere	~
Calibrate Wind	~
Advanced Calibrations	^
Calibrate Digital Elevation Model	~
Trim stick for Arcade Modes	^
 Update the arcade trim values Save the arcade trim values calculated 	Send
Calibrate Yaw	~

Fig. 183: Advanced Calibrations - Trim stick

• Calibrate Yaw

Allows to manually modify the Yaw Navigation state.

Warning: If there is any **Yaw sensor active** (i.e. Magnetometer), this command will **not work** since it will be automatically **overrided**.

٠	Operation Panel	
	Customize	
	Calibrate Atmosphere	~
	Calibrate Wind	~
	Advanced Calibrations	^
	Calibrate Digital Elevation Model	~
	Trim stick for Arcade Modes	~
	Calibrate Yaw	^
	0 °[0,360] Send	

Fig. 184: Advanced Calibrations - Calibrate Yaw

• Calibrate Position

Allows to manually modify the Position Navigation state.

The configurable parameters of the position calibration are the same as for configuring the position of a **waypoint**. So they have already been described in detail earlier in the *Waypoint* section of this manual.

Warning: If there is any **absolute positioning sensor active** (i.e. GNSS), this command will **not work** since it will be automatically **overrided**.

٠	Operation Panel	
	Customize Calibrations	
	Calibrate Atmosphere	~
	Calibrate Wind	~
	Advanced Calibrations	^
	Calibrate Digital Elevation Model	~
	Trim stick for Arcade Modes	~
	Calibrate Yaw	~
	Calibrate Position	^
	Absolute Relative	
	Set coordinate	
	Decimal degrees	
	Latitude (DD) Longitude (DD) 0 -0.00000499798931	
	Set elevation	
	MSL terrain: 0.00 WGS84 0 m	

Fig. 185: Advanced Calibrations - Calibrate Position

3.3.2 Operations

By clicking here, a list of all operations loaded in Veronte Ops will appear. The current operation is the one that is selected, the one shown in blue.




Fig. 186: Operations

The following options are available for each operation:




Fig. 187: Operation options

- Rename: The user can rename the operation as desire.
- Export: The current operation can be exported, the available formats are: ZIP, KML and GEOJSON.
- Remove: Clicking here will delete the selected operation.

Note: It is possible to delete several or all operations at once from the **Operation manager menu** of the **Status bar**, click *here* for more infromation.

Adding an operation

It is posible to create a new operation by simply clicking on 'Add Operation'.

The user can choose between adding an empty operation or importing one from the laptop, which has been previously exported. The available formats for importing an operation are the same as for exporting it: ZIP, KML and GEOJSON.

Operation creation	⊥ Import
Name *	
	× Close

Fig. 188: Operation creation

Note: When **a configuration is saved in the 1x PDI Builder software**, the following message will appear to inform the user that there is a new operation loaded in the autopilot 1x:



Fig. 189: Operation overwrite/new

- If the user does not select anything, after 10 seconds this message will disappear and a new operation will be created.
- If the user selects NO, a new operation will also be created, as described in the message.
- If the user selects **YES**, no new operation will be created and the changes saved in the 1x PDI Builder software will be applied to the current operation, i.e. the **current operation will be overwritten**.

3.3.3 Operation actions

Nevert Operation changes

• When a change is made, it is possible to revert it by pressing this button. This is only possible if the changes have not yet been saved.

B Save Operation

• To apply any change it is necessary to save it by pressing this button.

Upload to '(*Platform name*)'

- To update the operation loaded on the autopilot with the **new saved changes**, click on this button.
- If there is no change to upload to the operation configuration, the following message will appear:



Fig. 190: Nothing to Save in '...'

Caution: When **1x PDI Builder** opens the configuration (i.e., 'Open 1xVeronte' has already been clicked), it takes a snapshot of the configuration inside the Veronte Autopilot 1x. This implies that if any other tool (in this case Veronte Ops) modifies the configuration (in this case the operation), it will be modifying the configuration inside the autopilot, but not the snapshot shown in the 1x PDI Builder software, so when saving from this software, the intermediate changes would be overwritten. Therefore, changes made in **Veronte Ops** will not be saved.

Configuration changed	×		
Your configuration on the device has changed, saving will override those change	s. 🥐		
This might occur if you are using other applications while changing the configuration.			
Fig. 191: Configuration override message			

3.4 Platform

This panel shows information from the linked Veronte Autopilots 1x.



Fig. 192: Platform list

3.4.1 Platform connection status

This menu allows the user to check which autopilot 1x is connected and its connection status:

• Not connected




Fig. 193: Platform list - Not connected

• Connected:

Even if an autopilot 1x is connected, until it is selected by the user, Veronte Ops will operate as if no autopilot is connected:




Fig. 194: Platform list - Connected but not selected

Once Veronte Autopilot is connected and selected, Veronte Ops appears as shown in the figure below:




Fig. 195: Platform list - Connected and selected

• Disconnected:

	~			
VERONTE GROUN	D	Q	:	Disconnected

Fig. 196: Platform list - Disonnected

• Maintenance mode: By placing the mouse cursor over the icon, a message appears indicating that the autopilot is in maintence mode:




Fig. 197: Platform list - Maintenance mode

It is possible to exit of maintenance mode from this menu by **clicking** on the **b** icon. Then, the following confimation message will appear:




Fig. 198: Platform list - Exit of maintenance mode

• Maintenance mode (loaded with errors): In this case, by placing the mouse cursor over the icon, Veronte Ops will report the ID of the PDI error and a brief description of the error.

1				
	PDI Error: 687 -	Error for bloc	K EK	F position.
VERONTE GROU	ND		:	Loaded with errors

Fig. 199: Platform list - Maintenance mode (loaded with errors)

3.4.2 Platform actions

Moreover, when in Veronte Ops the **autopilot 1x is displayed in any connection state other than 'not connected'**, the following actions appear in this menu:



Fig. 200: Platform list actions

1. Search & follow: This action searchs the platform's position and centers it on the map.

Note: This action is not available when autopilot 1x is in 'disconnected' state.

2. Options




Fig. 201: Platform options

• Visible/Invisible in map: When the icon is wisible on the map, when the icon is wisible on the map, when the icon is on, the platform does not appear on the map. An example is shown below:

Fig. 202: Platform options - Visible/Invisible in map

• **FastLog**: By **pressing this button**, the Veronte Autopilot 1x will **start recording the fastlog** and this option will be as shown in the figure below:



Fig. 203: Platform options - FastLog recording


To stop fastlog recording, simply click this button again.

For more information on Fast Log, see the Telemetry section of the 1x PDI Builder user manual.

3. Minimize/maximize this pill: By clicking here, this 'pill' will be minimized/maximized.

3.4.3 Platform list

When more than one Veronte 1x Autopilot is connected, either by radio link or directly connected to the laptop, they will all appear here.



The user must then select one of them to operate it, i.e. to modify its operation, mission, etc.

Fig. 204: Platform list - 2 Veronte Autopilots 1x connected

In the above figure, the following things can be observed:

- The selected platform is the one called: 'M600'.
- The 'M600' unit has a limited operation licence.

By **placing** the mouse cursor over the **v** icon, a message appears indicating that the autopilot has a limited operation licence:

	License limited
M600	(B) Q : Connected

Fig. 205: Platform list - Operation License limited

By **clicking** on this **u**icon, the following information message will appear:




Fig. 206: Platform list - Operation License limited message

Clicking on the button "**Upgrade License in AP**", if the users have the **license activated**, Veronte Ops will be updated and they will be able to **operate without limitation**.

In this case, this message changes and the padlock opens and turns green:




Fig. 207: Platform list - Operation License updated message

However, if users do **not have the licence activated**, they will continue to have **limited operation**, in which case they should contact sales@embention.com.

For more information on this operation license, see Limited Operation Firmware section of the **1x Hardware Manual**.

3.5 Workspace




Fig. 208: Workspace toolbar

Workspace settings allow the user to customize any information to be displayed on the screen for monitoring the operation.

Attention: Although Veronte Ops cannot be extended to multiple screens, it is possible to open more than one Veronte Ops in order to display all the widgets necessary for the operation.

3.5.1 Map options

The map widget configures the background map that appears in Veronte Ops screen.

By **right clicking** on the map the following map options are available:




Fig. 209: Map options

• Edit map: In this menu the following options can be configured:

*		Widget creator
	1	Widget Options
		Set Manage custom tiles
		ESRI Satellite
		Enable view moving obstacles to selected Veronte in map
		✓ Accept

Fig. 210: Edit map option

- Manage custom tiles: This menu allows the user to add and manage their own map tiles.

Manage custom til	es		×
Name	API Key (Optional)	Ø	
URL			
Subdomains (Optional)	Max zoom 15		

Fig. 211: Manage custom tiles

- Select a tile: It is possible to select the map provider from a number of options.
- Enable view moving obstacles to selected Veronte in map
- Hide map: The map will be hidden. To show it again, go to 'Main Widgets' menu and select 'Map'.

In addition, **double-clicking** on the map will **zoom in** on the area where it is located.

Furtheremore, the map can be minimized/maximized by clicking on the **s** icon in the top right corner of the application. An example is shown below:

Fig. 212: Minimize/Maximize map

3.5.2 Workspace toolbar

The workspace toolbar is divided into 5 different 'parts':




Fig. 213: Workspace toolbar parts

1. **Sort widgets**: With this button it is possible to sort the widgets, i.e. the user can place one widget on top of another.

To do this, click on this button and a 'sorting panel' will appear for the user to sort widgets, so that the first in the list will be on top of the second, the second on top of the third and so on.

For ease of use, the widget selected for sorting will be outlined in blue, as shown in the example below:



Fig. 214: Sort widgets

In this example, 'Heading widget' is selected and is ordered above the 'Attitude widget'.

Warning: The **map** will always be at the **back** (the last widget in the list), except when minimized, which can be sorted as desired.

- 2. Lock/Unlock widgets: When widgets are locked, users will not be able to move them.
- 3. Show/Hide widgets: Users can choose to show/hide all widgets by pressing this button.
- 4. Workspaces: Users can have different workspaces for different missions, operations, tests, etc.
- 5. *Widgets*: Veronte Ops offers several applications to display parameters and variables in real time of the flight mission.

3.5.2.1 Workspaces

By clicking here, a list of all workspaces loaded in Veronte Ops will appear. The current workspace is the one that is selected, the one shown in blue.




Fig. 215: Workspaces

The following options are available for each workspace:




Fig. 216: Workspaces options

- Rename: The user can rename the workspace as desire.
- Duplicate: Duplicates this workspace.
- Export: The current workspace can be exported. This file is exported in . json format.
- Remove: Clicking here will delete the selected workspace.

Note: It is possible to delete several or all workspaces at once from the Workspace manager menu of the

Status bar, click here for more infromation.

Adding a workspace

It is posible to create a new workspace by simply clicking on 'Add workspace'.

The user can choose between adding an empty workspace or importing one from the laptop, which has been previously exported. To **import** a workspace, the format file must be a .json.




Fig. 217: Add workspace

3.5.2.2 Widgets

By clicking here, the user will see different widget menus sorted by categories.




Fig. 218: Widgets

To display any widget on the map, just search for the desired widget and configure it.

Warning: In order for the widgets to correctly receive data from the variable they represent, i.e. the variable that has been selected in their configuration, it is necessary that this variable has been added to the **Data to Vapp** telemetry vector in the telemetry configuration of the **1x PDI Builder** software. For more information, see the Data to Vapp -> Telemetry section of the **1x PDI Builder** user manual.

Therefore, users should add to that telemetry vector all normally used variables, as well as those variables of the current configuration that are expected to be used during operation.

Otherwise, if the variable configured for a widget is not present in the telemetry configuration of the PDI, the widget will appear with a red triangle (warning icon), which means that the variable selected for this widget is not being received in Veronte Ops:



Fig. 219: Not receiving telemetry in this widget

To fix this, users can simply add this variable to the **complementary vector telemetry** by *uploading the current operation* to the platform configuration. However, this complementary vector telemetry is **always** running at a frequency of **10 Hz** (not configurable) and the variables are sent uncompressed.

It is therefore **recommended** to add the variables to the **Data to Vapp** telemetry vector to configure the desired frequency, the compression/uncompression of the variables, etc.

Widgets common configuration

Warning: This does not apply to widgets in the '**Statics**' category.

All widget editing menus except those in the 'Statics' category have **at least** the following configurable parameters:

÷		Widget creator	×
	Widget Options Choose platform * Selected platform	•	
	→ Next		
	2 Widget Styling		
			✓ Accept

Fig. 220: Edit menu - Widget Options

• **Choose platform**: Users must select the platform for which the widget is configured. The available options will always be the IDs of the connected autopilots 1x and '**Selected platform**', i.e. the platform that is selected.

*	Widget creator
	Widget Options
	2 Widget Styling
	Select style Large_pink
	✓ Accept

Fig. 221: Edit menu - Widget Stylying

Here the user can choose the style of the widget:

1. Select style: Default and custom styles can be selected. The available default styles are *Default_box*, *Default_box_transparent*, *Default_box_blur*, *Default_box_black*, *Default_pill* and *Default_pill_blur*.

Note: Not all these default styles are available in all widgets.

- 2. Add new style: A new style can be created here.
- 3. Import style: Users can import a custom style from local storage. It must be a .css file.
- 4. **Export style**: By clicking here, the **selected custom style** will be exported in a zip folder. More information about the contents of this folder is described in *Status bar Style manager section* of this manual.

Important: This option is only **available** when a **custom style is selected**.

5. Edit style: Users can directly edit the configuration (code) of the selected style by clicking here.

Important: This option is only available when a custom style is selected.

6. Remove style: The selected style will be deleted.

Important: This option is only available when a custom style is selected.

All widgets are explained in detail in the following sections:

- Main
- Displays
- Charts
- Statics
- Flight instruments

3.5.2.2.1 Main

Veronte Panel

This pannel is the **basic operator tool**. It includes all basic commands (phase and action buttons) and information needed during a standard mission. These commands can be triggered with a single click, by sliding and/or automatically.




Fig. 222: Veronte Panel

- 1. Platform name: The name of the selected platform is shown here.
- 2. Flight mode: Displays the currently selected flight mode in which the user is operating.

By clicking on it, it is possible to **manually** change the selected mode. The flight modes available here must be previously defined in the Modes section of the **1x PDI Builder** software.




Fig. 223: Veronte Panel - Flight modes

Note: When in manual mode, the lettering of the icon will be **red**, to warn the operator to be careful in this mode.



Fig. 224: Veronte Panel - Manual flight mode

Besides, the mode can also be changed automatically with an automation or manually with a configured stick. The following example shows the mode change with a stick:

Fig. 225: Veronte Panel - Changing flight modes with a stick

3. Options:




Fig. 226: Veronte Panel options

- Remove: Deletes this widget.
- Edit: This allows the user to access the Veronte panel configuration menu.

This widget has only **one extra edit parameter** compared to the ones described in *Widget common configuration*:

÷	Widget creator	K
	1 Widget Options	
	Choose platform * Selected platform Show Action Buttons	
	→ Next	
	2 Widget Styling	
	✓ Accept	

Fig. 227: Veronte Panel configuration

- Widget Options \rightarrow Show Action Buttons: When enabled, the action buttons are displayed in the Veronte panel.
- 4. Action buttons: Action buttons can be used to manually trigger certain actions. These buttons must have been previously defined in the Automations menu of the **1x PDI Builder** software.

These buttons change to green when clicked.

Fig. 228: Veronte Panel - Changing phase

5. Phase buttons: The currently selected phase is always displayed at the top in the current phase identifier.

Important: Not all existing flight phases are initially displayed. Only flight phases that can be entered from the currently selected phase are displayed.

To change phase, simply slide the **control** icon to the right. Then, if everything is correct, the phase will be displayed in the *current phase indentifier* and will be colored green while switching to that phase. An example is shown below:

Fig. 229: Veronte Panel - Changing phase

Warning: An **error** may occur when changing phase, so that the phase change does not take place. To solve this problem, please check the *Error when changing phase - Troubleshooting section* of this manual.

Checklist

This panel is used to make sure that some requirements have been accomplished, for example, prior to a phase change or to avoid a possible malfunction.

It must be previously defined in the Checklist section of the 1x PDI Builder software.



Fig. 230: Checklist

• Options:




Fig. 231: Checklist options

- **Duplicate**: Duplicates this widget.
- Edit: This allows the user to access the Checklist configuration menu. This widget has only the 'basic' configuration described in the *Widget common configuration*.
- **Remove**: Deletes this widget.

As this widget behaves like a drop-down menu, clicking on the 💟 icon will display all checklists:




Fig. 232: Checklist deployed

Besides, as can be seen in the figures above, the **checklist widget has a small green border**. This indicates that **everything is OK to start the operation**, even though there is no 'check' in the list.


This is because **none of these checks are mandatory** to switch phases or start the operation. **The mandatory checks are marked with an asterisk** (*) on the right, as shown in the image below.

Checklist	^
Control Surfaces Check	
Vertical Motors Check	
Thermal Engine Check	
Calibrate Atmosphere *	
Calibrate DEM *	\Box
Check IMU Calibration	
0L	

Fig. 233: Checklist deployed - Not checked

In this case, the widget has no green border until these mandatory actions are performed:

Checklist	^	Checklist	^
Control Surfaces Check		Control Surfaces Check	
Vertical Motors Check		Vertical Motors Check	
Thermal Engine Check		Thermal Engine Check	
Calibrate Atmosphere *		Calibrate Atmosphere *	
Calibrate DEM *		Calibrate DEM *	
Check IMU Calibration		Check IMU Calibration	
AL1-12		0L I. M	



To do so, checking them opens a menu that allows the user to perform these actions, in this case, some calibrations. An example is shown below:

Fig. 235: Checklist - Actions

Мар

This widget corresponds to the map and **only appears** in this menu when the map has been **hidden** by the user.

3.5.2.2.2 Displays

Label

Depending on the type of variable selected, the appearance of the label (by default) is different.





- 1. Integer variables: Only the variable with its value is displayed.
- 2. Real variables: The units of the variable are displayed.
- 3. Bit variables: These labels have failure/success color.

Right click on the labels to access their options (Duplicate, Edit and Remove):

• **Options** \rightarrow **Edit**: This allows the user to access the Label configuration menu.

٠		Widget creator		×
(1 Widget Options			
	Choose platform *	VRef* Phase Identifier		
	Alerts	Ranges: 0	~	
	Settings		~	
	→ Next			
	2 Widget Styling			
			✓ Accep	t

Fig. 237: Label configuration

- Widget Options

This widget has **extra edit parameters** compared to the ones described in the *Widget common configuration*.


- * VRef: Users can choose any real, integer or bit variable to be displayed on the label.
- * Unit and Decimals: Attention!! These are only available with Real variables.

	Widget creator	×
Widget Options Choose platform * Selected platform	VRef*	
Unit * rad	▼	
Alerts	Ranges: 0	~

Fig. 238: Real label configuration

* Color fail/success: By default, when the bit variable is in 'fail mode', the label is red and when it is in 'success mode', it is green.

Attention!! This is only available with Bit variables. ٠ Widget creator Widget Options Choose platform * VRef * Selected platform System Error Color Success Color Fail Alerts V



* Alerts: Allows the user to set different ranges. For this range several customizations can be made:

Alerts	Ranges: 1	^
+ Number of series:	1	
Init phase	Opacity	•
Min 19	21 -	

Fig. 240: Label configuration - Alerts

- Name: An indentifier name of the range can be set.
- Background color: Changes the color of the label when the variable is in this range.
- Text color: Changes the color of the label text when the variable is in this range.
- **Opacity**: The opacity of the label can be customized in this interval.
- Start/End: Defines the start and end values of the range.
- **Remove**: Click to delete this interval.
- * **Setttings**: The 'shape' of the displayed text can be edited:

Settings	^
Override text variable	×
Align text:) Left Center Right 16	
Alıgn Value: 🔵 Left 🧿 Center 🔵 Rıght	
🗹 Show Title 🔽 Show Value 🔽 Show Units 🗹 Show range n	ame

Fig. 241: Label configuration - Settings

• **Override text variable**: The label name can be changed by typing a new one different from the variable name.

Warning: This does not rename the selected variable in the configuration, it is only the name shown in the label.

- Align text: The text of the variable can be left, center or right aligned.
- · Size text.
- Align Value: The value of the variable can be left, center or right aligned.
- Show Title/Value/Units: The title, value and units of the variable can be shown/hidden.
- Show range name: If enabled, the name assigned to the range will appear next to the variable.

Alerts

These alerts are bits variables that only appear when in 'failure mode'.

By default, they are displayed with an exclamation icon, in flashing red and with an alert sound. However, they can be customized accessing their edit menu.



Fig. 242: Alerts

By hovering the mouse cursor over the widget, the following actions appear:





- 1. Enable/Disable Loop: Users can enable/disable the sound of the alerts to be in loop, i.e. sounding continously.
- 2. Mute/Unmute all alerts: The sound of the alerts can be mute/unmute.
- 3. Options:

- Duplicate: Duplicates this widget.
- Edit: This allows the user to access the Alerts configuration menu.

٠		Widget creator
	1	Widget Options
		Choose platform * Delay (seconds) 3
		+ Add new var + Add Extended Vars
		Settings 🗸 🗸
		Add a new element alert to show in widget
		→ Next
	2	Widget Styling
		✓ Accept

Fig. 244: Alerts configuration

- Widget Options

This widget has **extra edit parameters** compared to the ones described in the *Widget common configuration*.

- * **Delay**: This is the time (in seconds) between the sounding of alerts when the loop option is enabled.
- * Add new var: Press this button to add a new alert variable. They are configured below.
- * Add Extended Vars: All bit variables of the autopilot status message will be added as alerts.

+ Add new var + Add Extended Vars	
System Power up BIT Error	~
Acquisition step missed	~
CIO Hi Overload warning	~
C1 Low Frequency	~
Power Error	~
File System Error	~
Memory allocation.	~
PDI Error	~
Stack Core 1 usage FAIL	~
GNC fail	~
	✓ Accept

Fig. 245: Alerts configuration - Extended Vars

* Add a new element alert to show in widget: When adding a variable (by clicking on the 'Add new var' button or the 'Add Extended Vars' button), the following configurable field is added to the configuration menu:

No selected	^
VRef *	fa-triangle-exclamation
🗌 Warning 🗌 Loop	× Delete
Settings	~

Fig. 246: Alerts configuration - Variables

- VRef: Users can select the desired bit variable to be displayed as an alert.
- **Icon**: Choose the icon to be displayed next to the variable. By default, it is an exclamation icon, as can be seen in the figure above.
- Warning: If enabled, the selected alert will be displayed in orange instead of red.
- Loop: If enabled, the sound of the selected alert will be looped with the delay time specified above. Otherwise, the alert sound will only play when the alert is triggered.

For example, if the delay is set to 3 seconds, the loop option is enabled and the selected variable is in fail mode, the alert sound will sound every 3 seconds.

· Delete.

* **Settings**: Here the user can modify the settings common to all alerts:

Settings	^
Align text: 💿 Left 🔷 Center 🔷 Right	
Audio File Magical bell	
► 0:00 / 0:02 → • E	
Don't add extended vars to telemetry	

Fig. 247: Alerts configuration - Settings

- · Align text: The variable text can be aligned left, centre or right.
- Audio File: Users can select the audio of the alert from the audio list. The volume and speed of the audio can be customized.
- **Don't add extended vars to telemetry**: If enabled, extended variables will not be added to the complementary telemetry. They will be read from the autopilot status message.
- **Remove**: Deletes this widget.

Some examples of alerts are shown below:




Fig. 248: Alerts example

The following figures show how these alerts have been configured:

• Stick not detected: This alert has been defined as a **warning** and its icon has been replace by another icon more related to the variable (a **joystick icon**).

Stick Not Detected Warning	^
Stick Not Detected	:k 🙎
Warning 🗌 Loop	× Delete
System Error	~
Position not fixed	~



• System Error: Although this variable has been configured as an alert, it does not appear as such. This is because it is not in 'failure mode'.

Stick Not Detected	Warning	~
System Error		^
System Error	fa-triangle-exclamatio	n 🔺
		× Delete
Position not fixed		~

Fig. 250: Alerts configuration example

• Position not fixed: This alert has not been customized, it appears with the default configuration.

Stick Not Detected	Warning 🗸 🗸
System Error	~
Position not fixed VRef* Position not fixed Warning Loop	fa-triangle-exclamation

Fig. 251: Alerts configuration example

Timer

This widget is a counter, which can also function as a countdown counter if configured as such.




Fig. 252: Timer

Right click on the widget to access its options (Duplicate, Edit and Remove).

- $Options \rightarrow Edit:$ This allows the user to access the Timer configuration menu.

Widget creator		×
1 Widget Options		
Time 00:00:00 Is countdown C		
Have milliseconds		
Options	~	
Alerts	~	
→ Next		
2 Widget Styling		
	🗸 Accept	

Fig. 253: Timer configuration

- Widget Options

This widget has **different edit parameters** compared to the ones described in the *Widget common* configuration.

- * Time: Users must enter the desired counter time. Note that if the Is countdown checkbox is enabled, this becomes the countdown time.
- * Is countdown: Enabling this option turns the widget into a countdown timer. Default is disabled.
- * Have milliseconds: If enabled, the time will be displayed with milliseconds. By default it is enabled.
- * **Options**: Users can set a warning time, color and sound for when the timer reaches the end of the set counter/countdown time.

Options	^
Warning Time 00 : 00 : 03	
Warning Color	
Audio File	
▶ 0:00 / 0:02 → ♥ :	

Fig. 254: Timer configuration - Options

- Warning Time: Time for the color and/or sound to be displayed until the end of the counter/countdown time.
- Warning Color: If enabled, this color shall be displayed flashing continuously from the time the warning time is reached until the end of the counter/countdown.
- Audio File: If enabled, the audio that users have selected from the audio list will play when the warning time is reached, sounding continuously until the end of the counter/countdown.

For example, if the audio file has a duration of 2 seconds and the warning time is set to 3 seconds, the audio will start playing for the first time from 3 seconds left until 1 second left and then play for the second time from 1 second left until the end. In other words, the audio will sound 1.5 times.

Important: If Warning Color and Audio File parameters are disabled, the warnings will be disabled.

For example, if the timer is configured as a **countdown** with a time of 8 seconds and the warning time is set to 3 seconds, the widget will be displayed with the color and/or sound defined here each of those final 3 seconds, i.e. from 3 to 0 seconds:

Fig. 255: Timer - Countdown example

* Alerts: Light and/or sound alerts can be activated every certain specified time.

Alerts	^
Time Interval 00:00:03	
Color Alert	
Audio File	
► 0:00 / 0:02 →	

Fig. 256: Timer configuration - Alerts

- **Time Interval**: The time interval for the light and sound alerts is set here.
- Color Alert: If enabled, the timer will have a light alert with the color specified here when the time interval elapses.
- \cdot Audio file: If enabled, the timer will have an audible alert with the audio specified here when the time interval elapses.


Users can select the audio of the alert from the audio list.

Important: If Color Alert and Audio File parameters are disabled, the alerts will be disabled.

An example is given below:

*	Widget creator	×
0	Widget Options	
	Time 00:00:08 Is countdown C ⁴	
	Have milliseconds	
	Options	~
	Alerts	^
	Time Interval 00:00:03 Color Alert Color Alert Audio File Audio File Maglcal bell	
	▶ 0:00 / 0:02 → ♥	
	→ Next	

Fig. 257: Timer - Alert example



3.5.2.2.3 Charts

Chart

Charts widgets allow the user to represent any variable of the system with respect to time. Thus, the user can visualize the evolution of that variable over time.

It is very useful during flight tests (gain tuning) and operations to monitor the behaviour of the platform.




Fig. 259: Chart

Right click on the chart to access its options (Duplicate, Edit and Remove).

- $Options \rightarrow Edit:$ This allows the user to access the Chart configuration menu.

	۷	Vidget creator	×
1	Widget Options		
	Title	Maximum Sample Size * 100	
	+ Number of series: 0		
	Interface settings		~
	→ Next		
2	Widget Styling		
			✓ Accept

Fig. 260: Chart configuration

- Widget Options

This widget has **extra edit parameters** compared to the ones described in the *Widget common configuration*.

- * Title: Title of the chart.
- * **Maximum Sample Size**: Maximum number of samples of the selected variable drawn in the chart. By default it is set to 100.
- * **Number of series**: Number of variables drawn in the chart. Users can add as many series as they wish to represent in the same chart.


The appearance of this series in the chart can be configured below:

+ Number of series: 1	
Select vref	^
Choose platform * Selected platform VRef *	
Auto Min Y Auto Max Y	

Fig. 261: Chart configuration - Series

- · VRef: Users can choose any real, integer or bit variable to be displayed on the chart.
- · Unit Y and Decimals: Attention!! These are only available with Real variables.
- **Color**: This is the color in which the line with the values of the series is drawn. By default, the first series is drawn in blue, the second in green, the third in yello, the fourth in red, etc.
- Auto Min/Max Y: If enabled, minimum and maximum of the Y axis of the chart are automatically adjusted.
- Min/Max Y: Minimum and maximum Y axis of the chart can be adjusted manually.
- * Interface settings:

Interface settings	^		
Horizontal space left Horizontal space right 50 50			
🗌 Show grid 🔽 Show legend 🗌 Show one axis Y			



· Horizontal space left/right: The horizontal space left/right of the chart background can be

customized. By default they are set to 50.

- **Show grid**: The grid of the chart can be shown/hidden.
- Show legend: The legend of the series can be shown/hidden on the chart.
- Show one axis Y: When more than one series is added, it is possible to show only one Y axis by enabling this option.

The following is an example of a typical chart used during operation:




Fig. 263: Chart example

The custom configuration made for this chart is as follows:

٠	Widget creator	×
0	Widget Options	
	Title Maximum Sample Size * Pitch / Desired pitch 100	
	+ Number of series: 2	
	Pitch red	~
	Desired Pitch rad	~
	Interface settings Horizontal space left Horizontal space right 50 50 Show grid Show legend Show one axis Y	^
	→ Next	
2	Widget Styling	
		Accept

Fig. 264: Chart configuration - Widget Options example

↔ Widget creator	×
+ Number of series 2	
Pitch rad Choose platform * VRef * Pitch Selected platform Decimals rad 5 Color Auto Min Y Auto Max Y Min Y 0.2 0.2	
Desired Pitch red Choose platform * Selected platform * Unit Y Tad Decimals Tad Color Auto Min Y Auto Max Y O.2 Decimals Decimals	
	✓ Accept

Fig. 265: Chart configuration - Series example

ب	Wide	get creator	×
	Widget Options		
2	Widget Styling		
	Select style Default_box_blur	A second s A second s A second secon A second seco	
	← Back		
		✓ Accept	

Fig. 266: Chart configuration - Widget Styling example

Scatter

Scatter widget allows the user to represent any variable in the system with respect to another variable.




Fig. 267: Scatter

Right click on the scatter to access its options (Duplicate, Edit and Remove).

- $Options \rightarrow Edit:$ This allows the user to access the Scatter configuration menu.

÷		v	/idget creator		×
	1	Widget Options			
		Title	- Maximum Sample Size * 100	Color	
		Axis X		~	
		Axis Y		~	
		Interface settings		~	
		→ Next			
	2	Widget Styling			
				✓ Accept	


Fig. 268: Scatter configuration

- Widget Options

This widget has **extra edit parameters** compared to the ones described in the *Widget common configuration*.

- * Title: Title of the scatter.
- * **Maximum Sample Size**: Maximum number of samples of the selected variables that are drawn in the scatter. By default it is set to 100.
- * Color: This is the color in which the values are drawn.

Widget creator		×
Axis X	^	
Auto Min X Min X Auto Max X Max X		
Choose platform * Selected platfor VRef *		
Axis Y	^	
Auto Min Y Auto Max Y Max Y		
Choose platform * VRef *		
Interface settings	^	
40 Horizontal space left 40		
✓ Show legend		
	V Acce	pt



* Axis X/Y: The user must select the variables to be plotted on both axes. The appearance of the variables in the scatter can then be modified:

- Auto Min/Max X/Y: If enabled, the minimum and maximum of the X/Y axes of the scatter are automatically adjusted.
- Min/Max X/Y: The minimum and maximum X/Y axes of the scatter can be adjusted manually.
- VRef: Users can choose any real, integer or bit variables to be displayed in the scatter.
- Unit and Decimals: Attention!! These are only available with Real variables.
- * Interface settings:
 - Horizontal space left/right: The left/right horizontal spacing of the scatter background can be customized. By default they are set to 40.
 - Show legend: The legend of the variable on the *Y* axis can be shown/hidden in the scatter.

An example is given below:




Fig. 270: Scatter example

The custom configuration made for this scatter is as follows:

٠			Widget creator		×
(0	Widget Options			
		Pttch vs Time	Maximum Sample Size *		
		Axis X		~	
		Axis Y		~	
		Interface settings		~	
		→ Next			
(2	Widget Styling			
				- Acce	pt

Fig. 271: Scatter configuration - Widget Options example

Widget creator	×
Axis X	^
🗹 Auto Min X Min X 🗹 Auto Max X Max X	
Choose platform * VRef * Selected platfor	
s T becimals 6	
Axis Y	^
Auto Min Y -0.05 Auto Max Y 0.05	
Choose platform * VRef * Selected platform	
rad Table Control of the second secon	
Interface settings	^
Horizontal space left Horizontal space right 6060	
Show legend	
	✓ Accept

÷		Widget creator
	0	Widget Options
	2	Widget Styling
		Select style Default_box_blur
		← Back
		✓ Accept

Fig. 273: Scatter configuration - Widget Styling example

Gauge

Gauge widget is a data visualisation tool that can be used to show the progress of data or display data in ranges in a precise and compact area.

This allows to display the progress of measuremetns in a circular arc or to see these numerical values in a range of colors that can have a certain meaning for the user.




Fig. 274: Gauge

Right click on the gauge to access its options (Duplicate, Edit and Remove).

- $Options \rightarrow Edit:$ This allows the user to access the Gauge configuration menu.

¢		Widget creator	×
1	Widget Options		
	Choose platform * Selected platform *	VRef *	
	Values		~
	Ranges	Ranges: 0	~
	Reference settings		~
	Pointer settings		~
	→ Next		
2	Widget Styling		
			✓ Accept


Fig. 275: Gauge configuration

- Widget Options

This widget has **extra edit parameters** compared to the ones described in the *Widget common configuration*.

- * VRef: Users can choose any real, integer or bit variable to be displayed on the gauge.
- * Unit and Decimals: Attention!! These are only available with Real variables.
- * Values:

Values		^
0 Max*	Start angle * End angle * 225 -45	



- · Min/Max: Minimum and maximum values displayed on the gauge.
- **Start/End angle**: Start and end angle of the position of the minimum and maximum values respectively.
- * **Ranges**: Allows the user to set different ranges.

Warning: The panel warns the user that for correct behaviour, ranges must not intersect.

Several customizations can be made in the different ranges:

Ranges	Ranges: 1	^
+ Number of series: 1	For correct behaviour, ranges must not intersect	
Range	Back Opacity	
0	0.1	

Fig. 277: Gauge configuration - Ranges

- Name: An identifying name for the range can be set.
- Background color: Sets the color of the gauge arc in this range.
- Opacity: The opacity of the circular arc can be customized in this range.
- · Min/Max: Defines the minimum and maximum values of the range.
- **Remove**: Click to delete this range.

* Reference settings:

Reference settings	^
Show progress ○ Show ranges ○ Not show	
Show value 🗌 Show units 🗌 Show range name	
🗌 References outside 🔽 Show ticks	
Reference Size	
Label Size Label Position	
1570	

Fig. 278: Gauge configuration - Reference settings

The gauge can be configured to display the progress of the values on the arc, to be displayed with color ranges according to the values or only with a needle indicating the value of the selected variable:

- Show Progress: Shows the progress arc of the selected variable in the gauge.
- Show Ranges: Displays the gauge with the previously defined ranges.
- \cdot Not Show: The needle indicates the value but neither the progress nor the ranges are shown in the gauge.



Fig. 279: Reference settings - 'Show Progress/Ranges' and 'Not Show' respectively

Reminder

Only one of the three options described below can be selected.

In addition, this widget is highly customizable so that users can configure it to their wishes:

- Show Value: If enabled, displays on the gauge the value of the selected variable that the needle is pointing to.
- Show Units: If enabled, displays the units of the value of the selected variable that the needle is pointing to.
- Show range name: If enabled, it displays, next to the value, the name of the range (previously defined) in which the value is in.

In addition, the color of this text will be the same as that of its corresponding range.

· References Outside: References refers to the displayed axis and its numbering.

By default, the arc axis numbering is "inside" the arc, by enabling it, it will be in the "outside" part.

- Show Ticks: Axis ticks can be shown/hidden. By default it is enabled, i.e. they are shown.
- **Reference Size**: The size of the axis numbering can be modified.
- · Reference position: The position of the axis numbering can be adjusted by the user.

The default position is 0.

- · Label Size: The size of the text value can be modified.
- · Label Position: The position of the value can be adjusted.

The default position is at 70, at the bottom of the gauge. If set to 0, the label will be in the center of the gauge.

· Color: This is the color in which the value is drawn.

Note: When '**Show Ranges**' option is selected, the color of the value is not this selected color, but is colored according to the color of range the value is in.

* Pointer settings: Here the user can configure the pointer of the gauge.

	^
Pointer Offset Center	
▼ 5	
Pointer length	
95 %	
	5 Pointer length

Fig. 280: Gauge configuration - Pointer settings

- Choose pointer: Users can choose a desired pointer from the list. If none is selected, no pointer will be drawn.
- **Pointer Offset Center**: Position of the "start" of the needle with respect to the center of the gauge. Default is set to 5.
- **Poiter width**: Width of the pointer. The default width is 6.
- **Pointer length**: Pointer length is set as a percentage of the distance between the centet and the edge of the gauge.

An example is given below:



Fig. 281: Gauge example

The custom configuration made for this gauge is as follows:

Choose platform * Selected platform	▼ VRef * Throttle	
	Decimals 2	
Values Min * 0	Max * Start angle * End angle * 1260280	^]
Ranges	Ranges: 3	~
Reference setti	ngs	~
Pointer settings	;	~
→ Next		

Fig. 282: Gauge configuration - Values example

Ranges	Ranges: 3
+ Number of series:	: 3 For correct behaviour, ranges must not intersect
Stert	Opacity
0 Min	0.2
Cruise 1	Opacity
Min 0.2	Max
Name Cruise 2	Opacity
0.7	Max

Fig. 283: Gauge configuration - Ranges example

Reference settings	^
🔵 Show progress 🧕 Sł	now ranges 🔵 Not show
🗹 Show value 🗹 Show u	nits 🔽 Show range name
🗌 References outside 🗾	Show ticks
Reference Size	Reference position Color 4 Image: Color
C Label Size	Label Position
17	25

Fig. 284: Gauge configuration - Reference settings example

Choose pointer	
6 Pointer width 95 %	

Fig. 285: Gauge configuration - Pointer settings example

Bar

Bar widget graphically displays the value of a selected variable by means of a bar. In addition, color ranges can be specified according to specific values.

The appearance of this widget is highly customisable, allowing the user to adapt it to the desired use.




Fig. 286: Bar

Right click on the bar to access its options (Duplicate, Edit and Remove).

- $Options \rightarrow Edit:$ This allows the user to access the Bar configuration menu.

٠			Widget creator		×
	1	Widget Options			
		Choose platform * Selected platform	VRef *		
		Bar options		~	
		Alerts	Ranges: 0	~	
		Interface settings		~	
		→ Next			
	2	Widget Styling			
				✓ Accer	pt

Fig. 287: Bar configuration

- Widget Options

This widget has **extra edit parameters** compared to the ones described in the *Widget common configuration*.

- * VRef: Users can choose any real, integer or bit variable to be displayed on the bar.
- * Unit and Decimals: Attention!! These are only available with Real variables.
- * Bar options:

Bar options	^
Bar Color 30 Min * 1 Max * 1	
Back	

Fig. 288: Bar configuration - Bar options

- Bar color: The color of the bar with the value can be changed here.
- · Color text: The color of the selected variable value can be modified.
- \cdot **Bar width**: The user can modify the width of the bar as desired. By default it is set to 30.
- · Min/Max: Minimum and maximum values displayed in the bar.
- **Background color**: The color of the background bar can be set here.

For example, if the value is 0, the bar will be colored with this color. But if the value is 1, this color will be covered by the bar color specified in the parameter '**Bar color**'.

* Alerts: Allows the user to set different ranges. For these ranges several customizations can be made:

Alerts	Ranges: 1	^
+ Number of s	series: 1	
Range	Opacity	
0		

Fig. 289: Bar configuration - Alerts

- · Name: An indentifier name of the range can be set.
- Background color: Sets the color of the bar for this range.
- **Text color**: Changes the color of the selected variable value in this range.
- Opacity: The opacity of the bar can be customized in this range.
- · Min/Max: Defines the minimum and maximum values of the range.
- **Remove**: Click to delete this range.
- * Interface settings:

Interface settings	^
🗹 Axis on the right 🔽 Show Axis 🗌 Horizontal bar 🗹 Show grid	
🗹 Show background 🔽 Show Value 🗹 Show Name	
Horizontal space left Horizontal space right Size Text Value 25 14	
Size Name Variable Size Text Axis 12 12	

Fig. 290: Bar configuration - Interface settings

The appearance of the bar widget can be highly customized using the following parameters:

- Axis on the right: If enabled, the axis is placed to the right of the bar, otherwise to the left. By default it is enabled.
- Show axis: If enabled, the axis of the bar is shown, otherwise it is hidden. By default it is enabled.
- **Horizontal bar**: If enabled, the bar and the axis are displayed in horizontal format, otherwise it is in vertical position. By default disabled (in vertical position).
- Show grid: If enabled, a grid with the subdivisions of the axes is shown, otherwise it is hidden. By default it is enabled.
- Show background: If enabled, the rest of the bar that is not colored by the value is shown with the color previously defined in **Bar options**. By default it is enabled.
- Show Value: If enabled, shows the value of the selected variable in the bar. By default it is enabled.
- Show Name: If enabled, the name of the selected variable is displayed at the bottom of the bar. By default it is enabled.

- **Horizontal space left/right**: The left/right horizontal spacing of the bar widget background can be customized. By default they are set to 25.
- Size Text Value: The size of the text value can be modified. Default is 14.
- Size Name Variable: The size of the selected variable name can be changed. Default is 12.
- Size Text Axis: The size of the axis text can be modified. Default is 12.

Some examples are given below:

• Example 1:



Fig. 291: Bar example 1

The custom configuration made for this bar is as follows:

	Widget creator	×
Widget Options		
Choose platform * Selected platform *	VRef * Throttle	
Unit *	2	
	Bar Width Min * Max * 50 0 1	^
Alerts	Ranges: 3	~

Fig. 292: Bar configuration - Bar options example 1

As shown in the figure above, when the background bar is hidden ('Show background' option is disabled), the '**Background color**' parameter does not appear.

Widget creator	×
Selected platform Throttle	
Unit * Decimals	
- · · 2	
Bar options	~
Alerts Ranges: 3	^
+ Number of series: 3	
Start Back. Opacity	
Min	
Cruise 1	
Min Max	
Cruise 2	
Min 1	
Interface settings	~
	✓ Accept

Fig. 293: Bar configuration - Alerts example 1

	Widget creator	×
1 Widget Options		
Choose platform * Selected platform	VRef * Throttle	
Bar options		~
Alerts	Ranges: 3	~
Interface settin AxIs on the Show backg Horizontal space I 15 Size Name Variable	right Show Axis Horizontal bar S round Show Value Show Name eft Horizontal space right 40	
14 → Next 2 Widget Styling	14	
		✓ Accept

Fig. 294: Bar configuration - Reference settings example 1

• Example 2:




Fig. 295: Bar example 2

The custom configuration made for this bar is as follows:

	Widget creator		×
Widget Options			
	/Ref *		
	Decimals		
Bar options		^	
Ber Color Ber W	idth Min * Max * 1		
Alerts	Ranges: 0	~	
Interface settings		~	
→ Next			
2 Widget Styling			
		✓ Accept	

Fig. 296: Bar configuration - Bar options example 2

As shown in the figure above, when the background bar is hidden ('Show background' option is disabled), the '**Background color**' parameter does not appear.

In addition, as there is no range specified, the color of the bar will always be the one specified in the '**Bar color**' parameter.

Choose platform *	C VRef * Throttle	
•	2	
Bar options		~
Alerts	Ranges: 0	~
Interface settings Axis on the right Show background Horizontal space left —		Show grid
5 C Size Name Variable	5 Size Text Axis 14	

Fig. 297: Bar configuration - Reference settings example 2

	Widget creator
0	Widget Options
2	Widget Styling
	Select style Default_box_blur
	← Back
	✓ Accept

Fig. 298: Bar configuration - Widget Styling example 2

Roll Tape

Roll tape widget shows the value of the selected variable with a marker always in the centre position of the widget. It is also possible to add color ranges according to the values of the variable. In addition, a second variable can be used as a reference marker.




Fig. 299: Roll Tape

Right click on the roll tape to access its options (Duplicate, Edit and Remove).

- $Options \rightarrow Edit:$ This allows the user to access the Roll Tape configuration menu.

	Widget creator	
1 Widget Options		
Choose platform *	VRef *	
Alerts	Ranges: 0	~
Secondary variable	2	~
Options		~
→ Next		
2 Widget Styling		
		✓ Accept

Fig. 300: Roll Tape configuration

- Widget Options

This widget has **extra edit parameters** compared to the ones described in the *Widget common configuration*.

- * VRef: Users can choose any real, integer or bit variable to be displayed on the roll tape.
- * Unit and Decimals: Attention!! These are only available with Real variables.
- * Alerts: Allows the user to set different ranges. For these ranges several customizations can be made:

Ranges: 1	^
rles: 1	
Opacity	•
1 -	
	Back Text Opacity

Fig. 301: Roll Tape configuration - Alerts

- Name: An identifying name can be set for the range.
- Background color: Sets the color of the roll tape for this range.
- **Text color**: Sets the color of the range name for this range.
- **Opacity**: The opacity of the roll tape can be customized in this range.
- Min/Max: Defines the minimum and maximum values of the range.
- **Remove**: Click to delete this range.
- * Secondary variable: A second variable can be added to be used, for example, as a reference.

Secondary variable	^
Enable/disable secondary variable	
VRef	
Color Offset25	

Fig. 302: Roll Tape configuration - Secondary variable

- Enable/disable secondary variable: If enabled, it is displayed as a marker.
- VRef: Users can choose any real, integer or bit variable to be displayed on the roll tape as a secondary variable.
- · Unit and Decimals: Attention!! These are only available with Real variables.
- · Color: Sets the color of the secondary variable marker.
- Offset: Horizontal position of the marker. By default it is set to 25.
- * **Options**:

	C Label decimals	
Title	2	
Range	Interval	
± 10	5	
Top spacing	Bottom spacing	
40	40	
C Left spacing	Right spacing	
40	40	

Fig. 303: Roll Tape configuration - Options

The appearance of the roll tape widget can be customized using the following parameters:

- Title: Title of the roll tape widget
- Label decimals: Decimals of the value to be displayed on the roll tape. By default it is set to 2.
- **Range** (+/-): Space between the center and the top and bottom boundaries. The default value is 10.
- Interval: Axis interval. Default is 5.
- **Top/Bottom spacing**: The top/bottom spacing of the roll tape widget background can be customized. The default value is 40.
- Left/Right spacing: The left/right horizontal spacing of the roll tape widget background can be customized. The default value is 40.
- **Toggle direction**: If enabled, the roll tape and the axis are displayed in horizontal format, otherwise it is in vertical position. By default disabled (in vertical position).
- **Toggle axis**: If enabled, the axis is positioned to the left of the roll tape, otherwise to the right. By default it is enabled.
- **Toggle text position**: If enabled, the previously defined title is positioned at the top of the widget, otherwise it is positioned at the bottom. By default disabled.

An example is given below:



Fig. 304: Roll Tape example

The custom configuration made for this roll tape is as follows:

÷	Widget creator	×
9	Widget Options Choose platform * Selected platform *MSL (Height Above Mean Sea Level)	
	Unit * m 2	
	Alerts Ranges: 3	
	+ Number of series 3	
	0 Max 46	
	CRU ALT	
	80 Max	
	HIGH ALT	
	Min Max 120 1000	

Fig. 305: Roll Tape configuration - Alerts example

Alerts	Ranges: 3	~
Secondary variable		^
Desired MSL (Heig		
 m	2	
Color Offset		
Options		~

Fig. 306: Roll Tape configuration - Secondary variable example

Alerts	Ranges: 3	~
Secondary variable		~
Options		^
ALTITUDE (MSL)	Label decimals2	
Range ± 100	50	
Top spacing 40	Bottom specing 35	
Left spacing — 50	Right spacing 40	
Toggle direction	✓ Toggle axis ✓ Toggle text position	

Fig. 307: Roll Tape configuration - Options example

3.5.2.2.4 Statics

Statics widgets **do not depend on the selected platform**, therefore the '*Choose platform*' parameter will not appear in any of the widgets described below.

Text

Text widget allows the user to insert text labels in the workspace.



Fig. 308: Text

Right click on the text to access its options (Duplicate, Edit and Remove).

- Options \rightarrow Edit: This allows the user to access the Text configuration menu.
 - Widget Options:

٠	Widget creator	×
	1 Widget Options	
	Enter a text: *	
	→ Next	
	2 Widget Styling	
	✓ Accept	

Fig. 309: Text configuration


- * Enter a text: Enter the desired text to be displayed as a label.
- Widget Styling: This widget has the 'basic' *Widget Styling* configuration described in the *Widget common* configuration.

Image

Image widget allows the user to insert an image in the workspace.

Note: A gif can also be added with this widget.





Right click on the image to access its options (Duplicate, Edit and Remove).

- $Options \rightarrow Edit:$ This allows the user to access the Image configuration menu.
 - Widget Options:

	Widget creator	×
1	Widget Options	
	Enter an https:// URL: *	
	Attach Image 🛛 🕖	
	→ Next	
2	Widget Styling	
	✓ Accept	

Fig. 311: Image configuration

- * Enter an https:// URL: Users can enter the URL of the image to be displayed.
- * Attach Image: It is possible to import an image from PC.
- Widget Styling: This widget has the 'basic' *Widget Styling* configuration described in the *Widget common configuration*.

An example is given below:




Fig. 312: Image example

As can be seen in the figure below, this image has been imported from the browse.

÷		Widget creator	×
	1	Widget Options	
		Enter an https:// URL_ *	
		https://www.pngall.com/wp-content/uploads/12/Engineer-Helmet-PNG-Image.png	
		Attach Image	
		→ Next	
	2	Widget Styling	
		✓ Accept	

Fig. 313: Image configuration - Widget Options example

٠		Widget creator
	۲	Widget Options
	2	Widget Styling
		Select style Default_box_blur
		←Back
		Accept

Fig. 314: Image configuration - Widget Styling example

Iframe

If rame widget allows the user to embed a **web page** as a widget in the workspace.

For example, useful websites could be: the windy website, the veronte operations manuals, the web application of the external radio if it is being used for operation, etc.




Fig. 315: Iframe

- 1. Reload page: Refreshes the web page embedded as a widget.
- 2. Move: Allows the user to move the widget to the desired position in the workspace.
- 3. Options:
 - Duplicate: Duplicates this widget.
 - Edit: This allows the user to access the Iframe configuration menu.
 - Widget Options:

	Widget creator	×
1	Widget Options	
	https://*	
	(*) If you use http you must enable non-secure content. (*) Problems with mixed-content.	
	→ Next	
2	Widget Styling	
	✓ Accept	

Fig. 316: Iframe configuration

* https://: Users can enter the URL of the web page to be displayed.

In order to be able to view the video recording from a gimbal and also tracking directly with the image, users must copy here the URL generated by the *Web Converter*, which converts from **RTSP** to **WebRTC**.

Warning: Pay attention to the notes in the widget!!

- Widget Styling: This widget has the 'basic' *Widget Styling* configuration described in the *Widget common configuration*.
- **Remove**: Deletes this widget.

Some examples example are given below:

• Example 1:




Fig. 317: Iframe example 1

٠		Widget creator		×
	1	Widget Options		
		https://* https://manuals.embention.com/veronte-ops/en/6.8/index.html	?	
		(*) If you use http you must enable non-secure content. (*) Problems with mixed-content. → Next		
	2	Widget Styling		
			✓ Accept	

Fig. 318: Iframe configuration example 1

• Example 2:




Fig. 319: Iframe example 2

	Widget creator	×
1	Widget Options	
	https://* https://embed.windy.com/embed2.html?lat=40.416&lon=-3.693&detailLat=40.4'	
	(*) If you use http you must enable non-secure content. (*) Problems with mixed-content.	
	→ Next	
2	Widget Styling	
	✓ Accep	t

Fig. 320: Iframe configuration example 2

Video

Video widget allows the user to insert a video in the workspace.



Fig. 321: Video

Click the button to access its options (**Duplicate**, **Edit** and **Remove**).

- $Options \rightarrow Edit:$ This allows the user to access the Video configuration menu.
 - Widget Options:

		۷	Vidget create	or	×
•	Widget Options				
	Enter a URL: *				
	✓ Autoplay✓ Muted✓ Controls				
	✓ Loop				
2	Widget Styling				
					✓ Accept

Fig. 322: Video configuration

* Enter a URL: Users can enter the URL of the video to be displayed.

Caution: The video must be in .mpa4 , .ogg, .webm or .avi format.

- * Autoplay: The video plays automatically when the user enters its URL. By default it is enabled.
- * Muted: The video can be muted/unmuted. By default it is enabled.
- * **Controls**: Video controls can be added to the widget. Controls such as* play/pause*, *mute/unmute*, *full screen*, etc. By default it is disabled.
- * Loop: Video plays continuously, like a gif. By default it is enabled.
- Widget Styling: This widget has the 'basic' *Widget Styling* configuration described in the *Widget common* configuration.

An example is given below:

Fig. 323: Video example




Fig. 324: Video configuration example


3.5.2.2.5 Inputs

Veronte Ops allows the user to modify some variables during a flight to test some parameters or to simulate a stick control.

Slider

Slider widgets allow the user to choose a certain variable and change its value by simply moving the slider to the desired value from the workspace during a flight.





Click the button to access its options (**Duplicate**, **Edit** and **Remove**).

- **Options** \rightarrow **Edit**: This allows the user to access the Slider configuration menu.

Widget creator		×
1 Widget Options		
Choose platform * Selected platform VRef *		
Values	^	
Min value * Max value * Step * 0 1 0.1		
🗌 Vertical 🔲 Invert 🗹 Show steps		
→ Next		
2 Widget Styling		
	🗸 Ассер	t

Fig. 326: Slider configuration

- Widget Options


This widget has **extra edit parameters** compared to the ones described in the *Widget common configuration*.

- * VRef: Users can choose any real, integer or bit variable to be displayed on the slider.
- * Unit: Attention!! This is only available with Real variables.
- * Values:
 - **Min/Max value**: Minimum and maximum values displayed in the slider. Defaults are 0 and 1 respectively.
 - Step: Here users must enter the step they want the slider to have. By default it is set to 0.1.
 - **Vertical**: If enabled, the slider widget is displayed in vertically, otherwise it is displayed horizontally. By default disabled (in horizontal position).

- **Invert**: If enabled, the minimum and maximum values are swapped, otherwise the minimum value is to the left of the widget and the maximum value to the right. By default disabled.
- Show steps: If enabled, the step divisions of the slider are shown when interacting with the widget, otherwise they are hidden. By default it is enabled.

An example is given below:





	Widget creator	
1	Widget Options	
	Choose platform * VRef * Selected platform • Stick Input r6	
	Unit *	
	Values	^
	Min value * Max value * Step * 0 1 0.25	
	🗌 Vertical 🔲 Invert 🔽 Show steps	
	→ Next	
2	Widget Styling	
		✓ Accept

Fig. 328: Slider configuration example

Action Button

Action Button widgets work exactly like the action buttons embedded in the Veronte Panel.



Fig. 329: Action Button

Click the button to access its options (**Duplicate**, **Edit** and **Remove**).

- **Options** \rightarrow **Edit**: This allows the user to access the Action Button configuration menu.

This widget has only one extra edit parameter compared to the ones described in Widget common configuration:


Widget creator	×
Widget Options	
Choose platform *	
→ Next	
2 Widget Styling	
	✓ Accept

Fig. 330: Action Button configuration

Widget Options → Select Event: Select the desired button event to be displayed as an action button. This
event must be previously configured as a button automation in the 1x PDI Builder software.

An example is given below:






ب		Widget creator	
	1 Widget Options		
	Choose platform *	Select Event *	
	4086	Trim Button	
	→ Next		
	A Communication of the second		
	2 Widget Styling		
			✓ Accept

Fig. 332: Action Button configuration example

Input Data

Input Data widgets allow the user to choose a certain variable and change its value by manually entering the value and sending it to the platform from the workspace during a flight.





Click the button to access its options (**Duplicate**, **Edit** and **Remove**).

• **Options** \rightarrow **Edit**: This allows the user to access the Input Data configuration menu.

Widget creator	×
1 Widget Options	
Choose platform * Selected platform	
Description	
VRef *	
→ Next	
2 Widget Styling	
	ccept

Fig. 334: Input Data configuration

- Widget Options

This widget has **extra edit parameters** compared to the ones described in the *Widget common* configuration.

- * **Description**: A description can be added to the widget by substituting the selected variable name.
- * VRef: Users can choose any real, integer or bit variable to be displayed on the widget.
- * Unit: Attention!! This is only available with Real variables.

An example is given below:



Fig. 335: Input Data example

*	Widget creator	
	1 Widget Options	
	Choose platform *	
	IAS	
	VRef* Desired IAS (Indicated Airspeed) Unit* m/s	
	→ Next	
	Widget Styling	
	✓ Accept	

Fig. 336: Input Data configuration example

Stick

Stick (Virtual stick) widgets are created to simulate a radio controller that controls the platform channels directly from the computer.




Fig. 337: Stick

On the stick display, there are 3 icons/buttons and their functions are as follows:

1. Send command enable/disable: Enables/Disables the virtual stick commands.

Warning: If the Stick is not actived, it will have no effect on the system.

- 2. Go to center: Returns the stick to the center.
- 3. Options
 - **Duplicate**: Duplicates this widget.
 - Edit: This allows the user to access the Stick configuration menu.

PLATFORM Selected platform Port Gameped 0 No gamepad Direction Label All directions Label Axis X Channel X: 1 Gamepad Axis X: 0		
0 No gamepad		
All directions Label Axis X Channel X: 1 Gamepad Axis X: 0		
Axis X Channel X: 1 Gamepad Axis X: 0		
	Axis X Channel X: 1 Gamepad Axis X: 0	~
Axis Y Channel Y: 2 Gamepad Axis Y: 1	Axis Y Channel Y: 2 Gamepad Axis Y: 1	~
Test stick Automatic: Disable Multiplier: x1	Test stick Automatic: Disable Multiplier: x1	~

Fig. 338: Stick configuration

• Widget Options

This widget has **extra edit parameters** compared to the ones described in the *Widget common configuration*.

- **Type**: Users can configure the widget stick to be used in "normal" mode, i.e. to control the **platform**, or to control a **gimbal** instead.

Widget Options		
GIMBAL	Choose gimbal * 🔹	
Gamepad	All direction	
Label		

Fig. 339: Stick configuration - Gimbal type

- Choose platform/gimbal: Depending on the type selected, the user will have to choose the platform or the gimbal for which the widget is configured.
- **Port**: As it is possible to have more than one stick configured, each transmitter must be configured on a different port.

This port must match the port configured in the **1x PDI Builder** software. For more information, see the Stick section of the **1x PDI Builder** user manual.

Important: This parameter is only available when PLATFORM type is selected.

- Gamepad: Users must select a desired gamepad from the list for which the widget is configured.

Important: If no physical gamepad (via USB) is connected to the PC, *No gamepad* option will be selected.

- **Direction**: The user has to configure the directions in which the stick can be moved, the available options are *All directions*, *Only vertical* and *Only horizontal*. By default, '*All directions*' option is selected.
- Label: If there is more than one stick widget, users can easily differentiate between them by configuring an identifying label for each one.
- Axis X/Y: X and Y axes must be configured.

Axis X	Channel X: 1 Gamepad Axis X: 0	^
Channel X 1	Gamepad Axis X ID0	
Invert axis		

Fig. 340: Stick configuration - Axis X

Axis Y	Channel Y: 2 Gamepad Axis Y: 1	^
Channel Y 2	Gamepad Axis Y ID1	
Invert axis Auto-center		

Fig. 341: Stick configuration - Axis Y

- * Channel X/Y: Select which channel is controlled by each axis. By default, channel 1 is configured for the X axis and channel 2 for the Y axis.
- * Gamepad Axis X/Y ID: Correlation of the physical gamepad axis IDs with those of the virtual stick.

Important: If no physical gamepad (via USB) is connected, this parameter has no effect on the widget. It can be left at the default value.

* **Invert axis**: If enabled, the minimum and maximum of the axis in the variable associated with this channel will be inverted.

For example, if in the Y axis, the **bottom of the axis** corresponds to a value of $\mathbf{0}$ in the *stick input r2* variable. If the **Inverted axis** is **enabled**, now the **bottom of the axis** will correspond to a value of $\mathbf{1}$ in the variable.

- * **Auto-center**: When activated, the stick automatically returns to the center position when released.
- **Test stick**: This option is used to generate stick inputs that are introduced in the system. This is a way to check how the system behaves when a stick command enters the autopilot.

Test stick	Automatic: Enable Multiplier: x1	^
Automatic circle	x1 •	

Fig. 342: Stick configuration - Test stick

* Automatic circle: An automatic circle test is activated.

* **Multiplier**: The speed of the test can be adjusted. Available options are: x1, x2, x4, x8 and x16.

An additional button appears in the widget to start/stop the test.




Fig. 343: Stick configuration - Test stick button

An example is presented below:

Fig. 344: Stick configuration - Test stick example

• Remove: Deletes this widget.

Dial Button

Dial Button widgets group different action button into a single 'drop-down' button.



Fig. 345: Dial Button

When clicked, the action buttons will appear/disappear.



Fig. 346: Dial Button - Action buttons

Right click on the widget to access its options (Duplicate, Edit and Remove).

- $Options \rightarrow Edit:$ This allows the user to access the Dial Button configuration menu.

This widget has only **one extra edit parameter** compared to the ones described in *Widget common configuration*:

*	Widget creator	×
	1 Widget Options	
	Choose platform * Selected platform	
	Select Events 🗸	
	→ Next	
	2 Widget Styling	
		ept

Fig. 347: Dial Button configuration

 Widget Options → Select Events: Select the desired button events that will be displayed as action buttons on the Dial Button. These events must be previously configured as automations in the 1x PDI Builder software.

An example is given below:



Fig. 348: Dial Button example

These action buttons can be ordered in the configuration:

*			N	Vidget creator			×
1	Widget (Choose p 4086						
	Sele	ect Ev	rents			^	
		1	Main priority button	ı	=		
		2	Secondary priority	button	=		
		ġ	Disable GNSS But	tton			
			Enable GNSS Butto	on	=		
2	<mark>→ Ne</mark> z Widget S		9				
						✓ Accep	ot

Fig. 349: Dial Button configuration example

Gimbal Buttons

Gimbal Buttons widget groups different control buttons of the selected gimbal into a single 'drop-down' button.



Fig. 350: Gimbal Buttons

When clicked, the control buttons will appear/disappear.

Right click on the widget to access its options (Duplicate, Edit and Remove).

• **Options** \rightarrow **Edit**: This allows the user to access the Gimbal Buttons configuration menu.

÷			Widget creator	×
	1	Widget Options		
		Choose Gimbal	•	
		Activate controls		~
		→ Next		
	2	Widget Styling		
				✓ Accept

Fig. 351: Gimbal Buttons configuration

- Widget Options:

- * **Choose Gimbal**: The user has to choose from the gimbal predefined list the gimbal for which the widget is configured.
- * Activate controls: Select the desired controls of the selected gimbal that will be displayed on the Gimbal Buttons.

Important: The controls shown here depend on the selected gimbal, each gimbal has its own control buttons.

Below is an example with the NextVision gimbal:




Fig. 352: Gimbal Buttons example

These control buttons can be enabled/disabled in the configuration:

*		Widget creator		×
1 w	lidget Options			
	Choose Gimbal	·		
	Activate controls		^	
	🔲 📲 Stow mode	🗌 L IR Level Decrem	IR Level Increm	
	GIR Gain Decrem	🗌 _G IR Gain Increment	🗌 🗃 IR Gain/Level re	
	Point to Coordin	Pilot View	☐ Observation	
	🗌 . <u>*</u> . GRR	🗌 🕁 Tracking	🗌 😭 EPR	
	🗌 👷 Nadir	🗌 👩 Nadir Scan	ြ [။] 2D Scan	
	🔽 👩 Snapshot	Record	Switch sensor I	
	🛃 👧 Zoom In	🛃 🗨 Zoom Out	🗹 🖑 Retract	
2 W	→ Next Vidget Styling			
			✓ Acce	pt

Fig. 353: Gimbal Buttons configuration example

Gimbal Setup

Gimbal Setup widget is a gimbal configuration panel, where the user can choose which gimbal controls can be managed from **Veronte Ops**.




Fig. 355: Gimbal Setup deployed

Note: As no controls have been configured yet, No Checks is displayed when deployed.

Click the button to access its options (**Duplicate**, **Edit** and **Remove**).

• **Options** \rightarrow **Edit**: This allows the user to access the Gimbal Setup configuration menu.

¢		Widget creator	×
	1	Widget Options	
		Choose Gimbal 🗸	
		Activate controls ~	
		→ Next	
	2	Widget Styling	
		✓ Accept	

Fig. 356: Gimbal Setup

- Widget Options:

- * **Choose Gimbal**: The user has to choose from the gimbal predefined list the gimbal for which the widget is configured.
- * Activate controls: Select the desired controls of the selected gimbal that will be displayed on the gimbal configuration panel.

Important: The controls shown here depend on the selected gimbal, each gimbal has its own controls.

Below is an example with the **NextVision gimbal**:




Fig. 357: Gimbal Setup example

These controls can be activated/deactivated in the configuration:

	Widget creator	×
1	Widget Options	
	Choose Gimbal NextVision Gimbal	
	Activate controls	^
	 Set FOV Temperature color Bitrate Configure pilot vie Laser mode Detector sele 	ected
	→ Next	
2	Widget Styling	
		✓ Accept

Fig. 358: Gimbal Setup configuration example

As can be seen in the example above, these controls can be in form of sliders, drop-down menus, etc.

Important: This will also depend on the pre-configured controls for each gimbal model.

Knob

Knob widget is similar to the *slider widget* but in circular format. It also allows the user to choose a certain variable and change its value by simply moving the circular bar to the desired value from the workspace during a flight.



Fig. 359: Knob

Right click on the widget to access its options (Duplicate, Edit and Remove).

- $Options \rightarrow Edit:$ This allows the user to access the Knob configuration menu.

÷		Widget creator		×
1	Widget Options			
	Selected platform	VRef *		
	Options			
	Min/Max		~	
	Angles		~	
	Bar		~	
	Track		~	
	Background		~	
	Text		~	
	Subtext		~	
	→ Next			
2	Widget Styling			
			🗸 Accept	

Fig. 360: Knob configuration

- Widget Options

This widget has **extra edit parameters** compared to the ones described in the *Widget common configuration*.

- * VRef: Users can choose any real, integer or bit variable to be displayed on the knob.
- * Unit: Attention!! This is only available with Real variables.
- * **Options**: This widget is highly customizable by simply modifying the following parameters:
 - \cdot **Min/Max**: Minimum and maximum values displayed in the knob. Defaults are 0 and 100 respectively.
 - Angles: Start and end angle of the position of the minimum and maximum values respectively. Defaults are -140 and 140 respectively.
 - · Bar:
 - Cap: This parameter allows users to choose whether they want the ends of the bar to be right angles or rounded.
 - \Rightarrow 100% rounded = 50% of the width parameter.
 - Width: The user can modify the width of the bar as desired. By default it is set to 20.
 - Step: Here users must enter the step by which they want the bar to move. By default it is set to 1.
 - · Color: This is the color in which the bar is drawn.
 - **Display previous bar**: If enabled, the bar stays colored at the position of the previously set value while the bar is moving to set the new value. Default is enabled.
 - · Color: Color of the previous bar.

An example is given below:

Fig. 361: Knob configuration - Display previous bar option enabled

- **Track**: This parameter refers to the bar between the minimum and maximum values defined above, which is always below the bar that indicates the desired value.
- Track cap: This parameter allows users to choose whether they want the ends of the track bar to be right angles or rounded.
 - \Rightarrow 100% rounded = 50% of the track width parameter.
- **Track width**: The user can modify the width of the track bar as desired. By default it is set to 20.
- Color: This is the color in which the track bar is drawn.
- · Background:
- · Color: Color of the knob widget background.
- **Full**: If enabled, the entire knob widget is colored with the previously defined color. Otherwise, the knob will only be colored between the previously defined start and end angles. By default it is enabled.

In the following example, the start and end angles are set to -90 and 90 respectively.



Fig. 362: Knob configuration - Full option enabled/disabled respectively

- \cdot Text: This text refers to the value of the selected variable displayed in the knob.
- \cdot **Display**: If enabled, displays on the knob the value of the selected variable. By default it is enabled.
- \cdot Size: The size of the text value can be modified. Default is 32.
- \cdot Weight: The weight of the text value can be modified. The available options go from 100 to 900, default is 700.
- Color: Color in which the value is displayed.
- Subtext: This subtext refers to the name of the selected variable displayed in the knob.
- \cdot **Display**: If enabled, displays on the knob the name of the selected variable. By default it is enabled.
- Offset: Vertical position of the selected variable name can be adjusted as desired. Default is 7.
- Size: The size of the selected variable name can be changed. By default it is set to 14.
- Weight: The weight of the selected variable name can be changed. The available options go from 100 to 900, default is 700.
- Color: Color in which the selected variable name is displayed.

An example is given below:



Fig. 363: Knob example

The configuration for this example is as follows:

ب	V	/idget creator	X
1	Widget Options		I
	Choose platform * Selected platform	VRef * Desired GS (Ground Speed)	
	 m/s		
	Options		
	Min/Max		^
	O Min	50	

Fig. 364: Knob configuration example - Variable and Min/Max option

Angles Start -90	90	^
Bar		^
Cap	20	
Step		
Color		
Display previous bar		

Fig. 365: Knob configuration example - Angles and Bar options

Track		^
O	20	
Color		
Background		^
Color		
🗹 Full		

Fig. 366: Knob configuration example - Track and Background options

Text		^
Display Size 34	Weigth	
Subtext		^
Display Offset	Size	
Weigth		
Color		

Fig. 367: Knob configuration example - Text and Subtext options

3.5.2.2.6 Flight instruments

Attitude

The attitude widget, commonly known as Primary Flight Display (PFD) or 'artificial horizon', represents graphically the attitude of the aircraft (roll and pitch).




Fig. 368: Attitude

Right click on the widget to access its options (Duplicate, Edit and Remove).

- **Duplicate**: Duplicates this widget.
- Edit: This allows the user to access the Attitude configuration menu.

This widget has two extra edit parameters compared to the ones described in the Widget common configuration.

	Widget creator	×
1	Widget Options	
	Choose platform *	
	Roll	
	VRef * Pitch	
	→ Next	
2	Widget Styling	
	✓ Accept	

Fig. 369: Attitude configuration

- Widget Options:
 - * VRef: Users can choose from the real angular variables of the system to be displayed as the roll of the widget. By default, the variable Roll is displayed.
 - * VRef: Users can choose from the real angular variables of the system to be displayed as the pitch of the widget. By default, the variable Pich is displayed.
- **Remove**: Deletes this widget.

Heading

The heading widget, commonly known as compass, usually shows the platform's yaw relative to the magnetic north.



Fig. 370: Heading

Right click on the **widget** to access its options:

- **Duplicate**: Duplicates this widget.
- Edit: This allows the user to access the Heading configuration menu.

This widget has only **one extra edit parameter** compared to the ones described in *Widget common configuration*:

*		Widget creator
	1	Widget Options
		Choose platform * VRef *
		Selected platform 👻 Yaw
		→ Next
	2	Widget Styling
		✓ Accept

Fig. 371: Heading configuration

- Widget Options \rightarrow VRef: Users can choose between the real angular variables of the system to be displayed. By default, the variable Yaw is displayed.
- **Remove**: Deletes this widget.

CHAPTER

FOUR

INTEGRATION EXAMPLES

4.1 Gimbal

The following diagram summarizes the "connection" and "elements" required to view video recording and/or command a gimbal in Veronte Ops:




Fig. 1: Gimbal connection diagram

To configure and control a gimbal from Veronte Ops, the following must be considered:

- The gimbal must be configured in the Gimbal panel.
- Use the Gimbal Buttons widget to command actions to the gimbal.
- Use the Gimbal Setup widget to configure some options of the gimbal camera video.
- To view the video recording and/or track directly with the displayed image, the Iframe widget is needed.
- Finally, if the user wants to manage the gimbal with a Veronte Ops virtual stick or a USB joystick, the *Stick widget* must also be configured.

Furthermore, it is necessary to configure the following variables in the telemetry vector of the Autopilot 1x in order to stablish a correct communication for commanding between **Veronte Autopilot 1x** \Rightarrow **Veronte Ops** \Rightarrow **Gimbal**:

- GNSS2 Number of Satellites Used in Solution
- GNSS1 Number of Satellites Used in Solution
- Longitude
- Latitude

- MSL (Height Above Mean Sea Level) Altitude
- AGL (Above Ground Level) Height
- North Ground Velocity
- East Ground Velocity
- Down Ground Velocity
- Heading
- GS (Ground Speed)
- p (Angular Velocity X Body Axis)
- q (Angular Velocity Y Body Axis)
- r (Angular Velocity Z Body Axis)
- Yaw
- Pitch
- Roll

The **Data to Vapp** telemetry vector in the **1x Autopilot** configuration (using **1x PDI Builder** software) should look like this:




Fig. 2: Gimbal - Telemetry configuration

4.2 Stick widget

Veronte Ops is able **to detect USB devices such as joysticks**. The buttons and axes of these devices can be read and configured to send stick information to **Veronte Autopilot 1x**.

Once the steps described in the **Integration examples** section of **1x PDI Builder** manual (Integration examples -> USB joystick) have been performed, configure a **Stick widget** to be connected to a USB joystick. To do so, follow the steps below:

- 1. Select the Gamepad (Index) that corresponds with the USB joystick connected to the PC.
- 2. And configure the **Gamepad Axis X/Y ID** so that the axes IDs of the virtual stick gamepad correspond to those of the physical joystick.

*		Widget creator	×
1	Widget Options		
	PLATFORM	Choose platform * Selected platform	
	Port1	Gamepad WISENET SPC-2000 (Ve 🔻	
	All directions	USB Joystick	
	Axis X Channel X:	: 1 Gamepad Axis X: 0 Auto-center ^ Gamepad Axis X ID 0	
	Invert axis Auto-center		
	Axis Y Channel Y:	: 2 Gamepad Axis Y: 1 Auto-center	
	2 Invert axis Auto-center		

Fig. 3: Virtual stick - USB joystick

Below is an example of how the stick widget works with the previous configuration:

Fig. 4: Virtual stick - USB joystick movement

For more information on the configuration of the Stick widget, please refer to the Stick widgets subsection of this

manual.

CHAPTER

FIVE

TROUBLESHOOTING

5.1 Connecting to Veronte Link

In case of having problems to connect with Veronte Link, allow all the content in the browser. To do this in Google Chrome follow the steps:

- 1. Click on $\widehat{\bullet} \rightarrow$ Site settings.
- 2. Click on **Privacy and security** \rightarrow **Insecure content** \rightarrow **Allow**.




Fig. 1: Step 1: $\fbox{ \rightarrow Site settings }$




Fig. 2: Step 2: Privacy and security \rightarrow Insecure content \rightarrow Allow

5.2 Error when changing phase

When changing phase, an **error** may occur so that the phase change does not take place and also the *current phase identifier* is **colored red** (the phase that appears is the one the platform was in before the phase change was attempted):

Fig. 3: Veronte Panel - Changing phase error

The reason for this error depends on the user's goal:

• During simulation or simple test

If this error occurs while the user is **running simulations or simple tests without all sensors connected**, it is most often because Veronte Autopilot 1x has not been configured in **PDI Mode**.

For more information on PDI Mode, visit the PDI Mode description of the 1x PDI Builder user manual.

· During flight test or operation

If this happens when the user is **not in PDI mode** (e.g. because the user is operating with the configuration finished and all sensors connected), it may be due to one of the following reasons:

- System bit is in error mode (not OK).

A list of all errors that can cause this bit to be set can be found in the 1x software manual \rightarrow Activation System Error bits section.

- Navigation attitude could not be initialized. For more information, see Navigation does not start section.

5.3 Navigation does not start

To start the navigation, the following requirements must be met:

- Correct IMU measurements.
- The **yaw** must be initialized with magnetometer measurements or with an **yaw initialization command**. To do the latter, see *Calibrate Yaw section Operation panel* of this manual.