

---

# MC110 Software Manual

*Release 6.8*

**Embention**

**2023-08-21**



## CONTENTS



To properly connect and configure a MC110 unit, **Veronte Link** and **MC110 PDI Builder** are required.

**Veronte Link:** This tool is the HUB that manages all Veronte and Embention devices that use a COM port. Here the user can check, configure and list the devices that are currently connected. Read the [Veronte Link user manual](#) to obtain more information.

**MC110 PDI Builder:** This tool is used to set all the configurable parameters. Here the user can set, tune and define the motor, control systems and sensors that are going to be used alongside the ESC. All the configuration is explained in the [MC110 PDI Builder user manual](#).

<p><b>Warning:</b> Select your software version to read any software manual.</p>
--